D2 & D2T Applications for Tool Turret/Magazine



Version 1.3 October 2015

HIWIN Mikrosystem Corp.

Contents

1.	Framewrok	1
	1.1. Hardware platform	2
	1.2. Applicable limitation	3
	1.3. Servo control system	4
2	Control Algorithm	5
2.	2.1 D2 drive	0
	2.1. D2 unve	0
	2.1.2. Digital input code	0
	2.1.2. Digital liput code	/
	2.1.3. FDL parameter	<i>1</i> 8
	2.1.4. Thinking Chart	0 Q
	2.2. DZT drive	9 Q
	2.2.1. Function	10
	2.2.3 Digital niput code	11
	2.2.4 PDI Parameter	12
	2.2.5. Timing chart	.13
	2.3. D2T drive with external I/O	. 15
	2.3.1. Function	. 15
	2.3.2. Digital input code	. 17
	2.3.3. Digital output code	. 18
	2.3.4. PDL Parameter	. 19
	2.3.5. Timing chart	. 19
3.	Wiring	. 21
•	3.1 System configuration and wiring	22
	3.1.1 System wiring diagram	22
	3.1.2 CN1 nower	23
	3.1.3 CN2 brake	26
	3.1.4 CN3 USB communication	.27
	3.1.5. CN6 control signal	.27
	3.1.6. CN13 & CN14 External I/O	. 30
	3.1.7. CN7 encoder	. 31
	3.2. Standard main power wiring	. 32
	3.2.1. AC power wiring (single-phase)	. 32
	3.2.2. AC power wiring (three-phase)	. 33
	3.3. I/O signal wiring	. 34
	3.3.1. Digital input wiring	. 34
	3.3.2. Digital output wiring	. 35
4.	Software Settings	. 37
	4.1. Installation and communication	. 38
	4.1.1. Setup file	.38
	4.1.2. Communication setup	. 39
	4.1.3. HMI main window	. 40
	4.2. Configuration center	. 43
	4.2.1. Motor configuration	. 44
	4.2.2. Encoder configuration	. 45
	4.2.3. Operation mode configuration	. 46
	4.2.4. Completing configuration procedure	. 46
	4.3. Auto phase center	. 48
	4.3.1. Method overview	. 48

	4.3.2. Pre-operation for phase initialization	48
	4.3.3. Procedure of phase initialization	49
	4.4. PDL loading and firmware update	50
	4.4.1. PDL loading	50
	4.4.2. Firmware update	52
5.	Troubleshooting	55
	5.1. Drive status indicators	56
	5.2. Errors and warnings	57
	5.2.1. Status display area on HMI	57
	5.2.2. Errors and warnings log	57
	5.3. Error codes and reactions	60
	5.4. Warning codes and reactions	63
6.	Specifications & Accessories	65
	6.1. Part numbers	66
	6.2. Motor specifications	67
	6.3. Drive dimensions	73
	6.4. Cable and Connector	76
	6.4.1. Motor cable	76
	6.4.2. Encoder cable	77
	6.5. Composition of peripheral equipment	78
	6.5.1. Communication cable and control signal cable	78
	6.5.2. Regenerative resistor	78
	6.5.3. EMC accessory part	79

Revision History:

Version Date		Applicability	Remarks
1.3 2015-10-30 D2-series drive		D2-series drive	Frist release.

1. Framewrok

1.	Framewrok				
	1.1.	Hardware platform	.2		
	1.2.	Applicable limitation	. 3		
	1.3.	Servo control system	.4		

Automatic tool change (ATC) mechanism solution of D2-series drives can meet application requirements of different number of cutter and different gear ratio of reducer. Through process description language (PDL), which is a high degree of freedom of movement and diversity program, this solution can design special functionalities based on applications of tool turret or tool magazine.

1.1. Hardware platform

Hardware platform for automatic tool change mechanism is described as following table.

Table 1-1						
Drive	D2	D2T	D2T with external I/O			
Motor	Motor with 13-bit	Motor with 17-bit	Motor with 17-bit			
WOLUI	incremental encoder	absolute encoder	absolute encoder			

1.2. Applicable limitation

			D2T with external
Drive	D2	D2T	I/O
Number of cutter	21	21	31 (default)
Digital input	9	10	10 + 24
Digital output	4 outputs: (1) Servo Ready (2) Errors (3) Homed (4) In-Position	 5 outputs of following functions: (1) Servo not Ready (2) Errors (3) Homed (4) Homing (5) Cutter offset warning (6) Cutter combination output (7) Absolute encoder battery error (8) Wrong absolute position 	 5 outputs of following functions + 12 external digital outputs: (1) Servo not Ready (2) Errors (3) Homed (4) Homing (5) Cutter offset warning (6) Cutter combination output (7) Absolute encoder battery error (8) Wrong absolute position
Jog Function	X	0	0
Homing mode	Х	O (4 kinds of homing mode)	O (4 kinds of homing mode)

D2 Drive

9 DI and 4 DO DI (Source & Sink) DO (Source & Sink)



D2T Drive

10 DI and 5 DO DI (Source & Sink) DO (Source & Sink)

Fig. 1-1

D2T Drive with external I/O



34 DI and 17 DO DI (Source & Sink) DO (Source & Sink)

1.3. Servo control system

The servo control system of this ATC solution combines standard D2-series drives with exclusive PDL for ATC system to complete drive solutions of low cost and high functionality.







Fig. 1-2

2. Control Algorithm

2.	Control Algorithm			
	2.1. D2 d	rive	6	
	2.1.1.	Function	6	
	2.1.2.	Digital input code	7	
	2.1.3.	PDL parameter	7	
	2.1.4.	Timing chart	8	
	2.2. D2T	drive	9	
	2.2.1.	Function	9	
	2.2.2.	Digital input code	10	
	2.2.3.	Digital output code	11	
	2.2.4.	PDL Parameter	12	
	2.2.5.	Timing chart	13	
	2.3. D2T	drive with external I/O	15	
	2.3.1.	Function	15	
	2.3.2.	Digital input code	17	
	2.3.3.	Digital output code	18	
	2.3.4.	PDL Parameter	19	
	2.3.5.	Timing chart	19	

2.1. D2 drive

2.1.1. Function

- (1) Number of I/O: Total up to 9 inputs and 4 outputs.
- (2) Model number: $D2-\Box \Box 23-S-\Box 0$.



- **Input:** Power connection points of 9 inputs are the common point. Based on the signal of COM+/-, input signals could be wired by using source or sink method.
- **Output:** Users can define the output signal as source or sink wiring.

I/O	PIN	Function		
	1	Start searching tool (Pos_Start)		
	12	Home sensor (Home_Sensor)		
	13	Enable (Axis enable)		
	14	Start homing (Start_Home)		
Digital Input	15	Bit 4 of command input for indexing position code		
	l6	Bit 3 of command input for indexing position code		
	17	Bit 2 of command input for indexing position code		
	18	Bit 1 of command input for indexing position code		
	19	Bit 0 of command input for indexing position code		
	01	Servo Ready		
Digital Output	O2	Errors		
Digital Output	O3	In-Position		
	O4	Homed		

Table 2-1	I/O functions	of D2 drive
	1/ O TOTTOTTO	

2.1.2. Digital input code

Table 2-2 Digital input code for D2 drive							
15	16	17	18	19	Definition		
0	0	0	0	0	-		
0	0	0	0	1	Indexing position 1		
0	0	0	1	0	Indexing position 2		
0	0	0	1	1	Indexing position 3		
0	0	1	0	0	Indexing position 4		
0	0	1	0	1	Indexing position 5		
0	0	1	1	0	Indexing position 6		
0	0	1	1	1	Indexing position 7		
0	1	0	0	0	Indexing position 8		
0	1	0	0	1	Indexing position 9		
0	1	0	1	0	Indexing position 10		
0	1	0	1	1	Indexing position 11		
0	1	1	0	0	Indexing position 12		
0	1	1	0	1	Indexing position 13		
0	1	1	1	0	Indexing position 14		
0	1	1	1	1	Indexing position 15		
1	0	0	0	0	Indexing position 16		
1	0	0	0	1	Indexing position 17		
1	0	0	1	0	Indexing position 18		
1	0	0	1	1	Indexing position 19		
1	0	1	0	0	Indexing position 20		
1	0	1	0	1	Indexing position 21		

2.1.3. PDL parameter

Table 2-3 PDL parameters for D2 drive			
Parameter Range Definition			
Pos_Num 1 ~ 21		Total number of indexing position	
Gear_Ratio	1 ~ 100	Gear ratio of reducer	

2.1.4. Timing chart

(1) Homing:



Fig. 2-2 Timing chart of homing for D2 drive

(2) Start searching tool



Fig. 2-3 Timing chart of start searching tool for D2 drive

2.2. D2T drive

2.2.1. Function

- (1) Number of I/O: Total up to 10 inputs and 5 outputs.
- (2) Model number: D2T-□□23-S-□0.



- **Input:** Power connection points of 10 inputs are the common point. Based on the signal of COM+/-, input signals could be wired by using source or sink method.
- **Output:** Users can define the output signal as source or sink wiring.

I/O	PIN	Function					
	1	Start searching tool (Pos_Start)					
	12	Home sensor (Near_Home_Sensor / Setting	_Home_Pos)				
	13	Enable (Axis enable)					
	14	Start homing (Start_Home)					
Digital	15	Bit 4 of command input for indexing position	code				
Input	16	Bit 3 of command input for indexing position code					
	17	Bit 2 of command input for indexing position code					
	18	Bit 1 of command input for indexing position code					
	19	Bit 0 of command input for indexing position	code				
	l10	Reset amplify (Reset)					
	01	Bit 0 of output code for indexing position					
Digital	O2	Bit 1 of output code for indexing position	Other status				
Digital	O3	Bit 2 of output code for indexing position	outputs				
Output	O4	Bit 3 of output code for indexing position	(see Table 2-6)				
	O5	Bit 4 of output code for indexing position					

2.2.2. Digital input code

Table 2-5 Digital input code for D2T drive					
15	16	17	18	19	Definition
0	0	0	0	0	-
0	0	0	0	1	Indexing position 1
0	0	0	1	0	Indexing position 2
0	0	0	1	1	Indexing position 3
0	0	1	0	0	Indexing position 4
0	0	1	0	1	Indexing position 5
0	0	1	1	0	Indexing position 6
0	0	1	1	1	Indexing position 7
0	1	0	0	0	Indexing position 8
0	1	0	0	1	Indexing position 9
0	1	0	1	0	Indexing position 10
0	1	0	1	1	Indexing position 11
0	1	1	0	0	Indexing position 12
0	1	1	0	1	Indexing position 13
0	1	1	1	0	Indexing position 14
0	1	1	1	1	Indexing position 15
1	0	0	0	0	Indexing position 16
1	0	0	0	1	Indexing position 17
1	0	0	1	0	Indexing position 18
1	0	0	1	1	Indexing position 19
1	0	1	0	0	Indexing position 20
1	0	1	0	1	Indexing position 21
1	1	1	1	0	CCW reversal rotation

2.2.3. Digital output code

Table 2-6 Digital output code for D2T drive							
O5	O4	O3	02	01	Definition		
0	0	0	0	0	-		
0	0	0	0	1	Indexing position 1		
0	0	0	1	0	Indexing position 2		
0	0	0	1	1	Indexing position 3		
0	0	1	0	0	Indexing position 4		
0	0	1	0	1	Indexing position 5		
0	0	1	1	0	Indexing position 6		
0	0	1	1	1	Indexing position 7		
0	1	0	0	0	Indexing position 8		
0	1	0	0	1	Indexing position 9		
0	1	0	1	0	Indexing position 10		
0	1	0	1	1	Indexing position 11		
0	1	1	0	0	Indexing position 12		
0	1	1	0	1	Indexing position 13		
0	1	1	1	0	Indexing position 14		
0	1	1	1	1	Indexing position 15		
1	0	0	0	0	Indexing position 16		
1	0	0	0	1	Indexing position 17		
1	0	0	1	0	Indexing position 18		
1	0	0	1	1	Indexing position 19		
1	0	1	0	0	Indexing position 20		
1	0	1	0	1	Indexing position 21		
1	0	1	1	0	Reserved		
1	0	1	1	1	Homing		
1	1	0	0	0	Homed		
1	1	0	0	1	Cutter offset warning		
1	1	0	1	1	Servo not Ready		
1	1	1	0	0	Absolute encoder battery error		
1	1	1	0	1	Wrong absolute position		
1	1	1	1	0	Serial Encoder Error		
1	1	1	1	1	Errors		

2.2.4. PDL Parameter

Table 2-7 PDL parameters for D2T drive					
Parameter	Range	Definition	Unit		
Pos_Num	1 ~ 21	Total number of indexing position	-		
Gear_Ratio	1 ~ 100	Gear ratio of reducer	-		
	0	Searching external sensor mode	-		
Homing_Mode	1	Manual teaching home position	-		
Secret Second val	1 2000	Mode Speed for accrebing home concer	rom		
Search_Sensor_ver	1 ~ 3000	Speed for searching nome sensor	rpm		
Search_Index_vel	1 ~ 3000	Speed for searching index	rpm		
Home_Offset_ver	1 ~ 3000	Speed for moving to nome offset	rpm		
	1 ~ 340787200	Home offset	count		
Shift_Pos_Range	131072	Cutter ossfet	count		
	0	 Indexing searching tool mode To be with command input of indexing position code. 	-		
	1	 Single-step searching tool mode As the pin of start searching tool is rising-edge triggered the motor moves one indexing position. The direction of searching tool is based on the value of Rotary_mode. 	-		
Motion_Mode	2	 Continuous single-step searching tool mode As the pin of start searching tool is triggered and keeps the same level, this mode will be performed. The direction of searching tool is based on the value of Rotary_mode. Until the pin of start searching tool is OFF, motor will stop at the nearest tool slot. 	-		
Continuous_Step_delay	100 ~ 60000	Delay time for continuous single-step mode	ms		
	0	Shortest-path searching tool	-		
Rotary Mode	1	Forward-rotation searching tool	-		
	2	Reversal-rotation searching tool	-		

2.2.5. Timing chart

(1) Homing:



Fig. 2-5 Timing chart of homing for D2T drive

(2) Indexing searching tool mode (Motion_Mode = 0):



Fig. 2-6 Timing chart of indexing searching tool mode for D2T drive

(3) Single-step searching tool mode (Motion_Mode = 1):



Fig. 2-7 Timing chart of single-step searching tool mode for D2T drive

(4) Continuous single-step searching tool mode (Motion_Mode = 2):



Fig. 2-8 Timing chart of continuous single-step searching tool mode for D2T drive

2.3. D2T drive with external I/O

2.3.1. Function

- (1) Number of I/O for D2T drive: Total up to 10 inputs and 5 outputs.
- (2) Number of I/O for external I/O module: Total up to 24 inputs and 12 outputs.
- (3) Model number: D2T-D23-K-D0.



- **Input:** Power connection points of 10 inputs are the common point. Based on the signal of COM+/-, input signals could be wired by using source or sink method.
- **Output:** Users can define the output signal as source or sink wiring.

I/O	PIN	Function						
	11	Start searc	hing tool (F	Pos_	Start)			
	12	Home sens	or (Near_l	Home	e_Sensor / Setting_Home_Pos)			
	13	Enable (Ax	is enable)					
	14	Start homin	ng (Start_H	lome)			
Disital langet	15	Bit 4 of con	nmand inp	ut for	indexing position code			
Digital Input	16	Bit 3 of con	nmand inp	ut for	indexing position code			
	17	Bit 2 of con	nmand inp	ut for	indexing position code			
	18	Bit 1 of con	nmand inp	ut for	indexing position code			
	19	Bit 0 of command input for indexing position code						
	I10	Reset amp	lify (Reset))				
	Ex_I1		Itomatic si searching tion input	ngle- tool, pins	step searching tool, manual shortest-path searching tool: (Ex_I1, Ex_I2).			
		Off	Off	Sho	ortest-path searching tool			
		Off	On	Aut	omatic single-step			
	Ex_l2	On	Off	Mai tool	nual single-step searching			
		On	On	Hor	ming			
			_	_				
External 1_ CN13 Input	Ex_l3	when oper single-step by Ex_I3.	ational mo searching Ex 13	ide is tool,	at automatic/manual the rotation direction is defined			
			On		Forward rotation			
			Off		Reversal rotation			
	Ex_l4	Setting hon	ne positior	n (Set	tting_Home_Pos)			
	Ex_l5	Manual hor - To be with	ming: forwa n I1 (Pos_S	ard ro Start)	otation. trigger.			
	Ex_l6	Manual hor - To be with	ming: reve 1 I1 (Pos_S	rsal r Start)	otation. trigger.			
	Ex_l7		·					
	Ex_l8							
	Ex_l9		od innut fu	nction				
	Ex_l10	USEI-GEIIII		ICLIOI	15			
	Ex_I11							
	Ex_l12							
	Ex_I13							
	Ex_I14							
	Ex_I15							
	Ex_I16							
External 2_	Ex_l17	User-define	d input fu	nctior	าร			
CN14 Input	Ex_l18							
	Ex_119	4						
	Ex_120	4						
	Ex_121							
	EX_122							

Table 2-8 I/O functions of D2T drive with external I/O

I/O	PIN	Function			
	Ex_l23				
	Ex_l24				
	01	Bit 0 of output code for indexing position			
	O2	Bit 1 of output code for indexing position			
Digital Output	O3	Bit 2 of output code for indexing position			
	O4	Bit 3 of output code for indexing position			
	O5	Bit 4 of output code for indexing position			
	Ex_O1	Cutter offset warning			
	Ex_O2	Reserved			
External 1_	Ex_O3	Servo not Ready			
CN13 Output	Ex_O4	Wrong absolute position			
	Ex_O5	Serial Encoder Error			
	Ex_06	Errors			
	Ex_O7				
External 2_	Ex_O8				
	Ex_O9	Lisor-defined output functions			
CN14 Output	Ex_010				
	Ex_011				
	Ex_012				

2.3.2. Digital input code

Table 2-9 Digital input	code for D2T drive with external I/O	
Table E e Bighai inpac		

15	I 6	17	18	19	Definition
0	0	0	0	0	-
0	0	0	0	1	Indexing position 1
0	0	0	1	0	Indexing position 2
0	0	0	1	1	Indexing position 3
0	0	1	0	0	Indexing position 4
0	0	1	0	1	Indexing position 5
0	0	1	1	0	Indexing position 6
0	0	1	1	1	Indexing position 7
0	1	0	0	0	Indexing position 8
0	1	0	0	1	Indexing position 9
0	1	0	1	0	Indexing position 10
0	1	0	1	1	Indexing position 11
0	1	1	0	0	Indexing position 12
0	1	1	0	1	Indexing position 13
0	1	1	1	0	Indexing position 14
0	1	1	1	1	Indexing position 15
1	0	0	0	0	Indexing position 16
1	0	0	0	1	Indexing position 17
1	0	0	1	0	Indexing position 18
1	0	0	1	1	Indexing position 19
1	0	1	0	0	Indexing position 20

1	0	1	0	1	Indexing position 21
1	0	1	1	0	Indexing position 22
1	0	1	1	1	Indexing position 23
1	1	0	0	0	Indexing position 24
1	1	0	0	1	Indexing position 25
1	1	0	1	0	Indexing position 26
1	1	0	1	1	Indexing position 27
1	1	1	0	0	Indexing position 28
1	1	1	0	1	Indexing position 29
1	1	1	1	0	Indexing position 30
1	1	1	1	1	Indexing position 31

2.3.3. Digital output code

Table 2-10 Digital output code for D2T drive with external I/O						
O5	O4	O3	02	01	Definition	
0	0	0	0	0	-	
0	0	0	0	1	Indexing position 1	
0	0	0	1	0	Indexing position 2	
0	0	0	1	1	Indexing position 3	
0	0	1	0	0	Indexing position 4	
0	0	1	0	1	Indexing position 5	
0	0	1	1	0	Indexing position 6	
0	0	1	1	1	Indexing position 7	
0	1	0	0	0	Indexing position 8	
0	1	0	0	1	Indexing position 9	
0	1	0	1	0	Indexing position 10	
0	1	0	1	1	Indexing position 11	
0	1	1	0	0	Indexing position 12	
0	1	1	0	1	Indexing position 13	
0	1	1	1	0	Indexing position 14	
0	1	1	1	1	Indexing position 15	
1	0	0	0	0	Indexing position 16	
1	0	0	0	1	Indexing position 17	
1	0	0	1	0	Indexing position 18	
1	0	0	1	1	Indexing position 19	
1	0	1	0	0	Indexing position 20	
1	0	1	0	1	Indexing position 21	
1	0	1	1	0	Indexing position 22	
1	0	1	1	1	Indexing position 23	
1	1	0	0	0	Indexing position 24	
1	1	0	0	1	Indexing position 25	
1	1	0	1	0	Indexing position 26	
1	1	0	1	1	Indexing position 27	
1	1	1	0	0	Indexing position 28	
1	1	1	0	1	Indexing position 29	
1	1	1	1	0	Indexing position 30	
1	1	1	1	1	Indexing position 31	

2.3.4. PDL Parameter

Parameter	Range	Definition	Unit
Pos_Num	1 ~ 21	Total number of indexing position	-
Gear_Ratio	1 ~ 100	Gear ratio of reducer	-
Search_Sensor_vel	1 ~ 3000	Speed for searching home sensor	rpm
Search_Index_vel	1 ~ 3000	Speed for searching index	rpm
Home_Offset_vel	1 ~ 3000	Speed for moving to home offset	rpm
Home_Offset	1 ~ 340787200	Home offset	count
Shift_Pos_Range	131072	Cutter offset	count
Continuous_Step_delay	100 ~ 60000	Delay time for continuous single-step mode	ms

Table2-2-11 D2T 擴充 I/O 機型 PDL Parameter

2.3.5. Timing chart

(1) Homing:





(2) Indexing searching tool mode



Fig. 2-11 Timing chart of indexing searching tool mode for D2T drive with external I/O

(3) Manual single-step searching tool



Fig. 2-12 Timing chart of manual single-step searching tool mode for D2T drive with external I/O

3. Wiring

3.	Wiring		21
	3.1. Syste	em configuration and wiring	
	3.1.1.	System wiring diagram	
	3.1.2.	CN1 power	23
	3.1.3.	CN2 brake	
	3.1.4.	CN3 USB communication	27
	3.1.5.	CN6 control signal	27
	3.1.6.	CN13 & CN14 External I/O	
	3.1.7.	CN7 encoder	
	3.2. Stan	dard main power wiring	
	3.2.1.	AC power wiring (single-phase)	
	3.2.2.	AC power wiring (three-phase)	
	3.3. I/O s	signal wiring	
	3.3.1.	Digital input wiring	
	3.3.2.	Digital output wiring	35

3.1. System configuration and wiring

This chapter introduces the drive configuration and functions of each part. The following figure shows the details of drive configuration.



3.1.1. System wiring diagram



Tab	le	3-1	1
TUD		0	

Item no.	Name	Description
1	AC main power cable (CN1)	L1, L2: Single-phase 200-240V AC, 50/60Hz L1, L2, L3: Three-phase 200-240V AC, 50/60Hz
2	Motor power cable (CN1)	Connection to motor, three-phase motor power (±, U, V, W)
3	Regenerative resistor (CN1)	Connection to motor regenerative resistor (optional/mounted according to actual application design) (REG-/REG+)
4	Control power cable (CN1)	For drive internal control and I/O power (L1C, L2C) L1C, L2C: Single-phase 200-240V AC, 50/60Hz
5	Brake (CN2)	Connection to brake (optional/mounted according to actual application design)
6	Mini USB communication (CN3)	Connection to PC (for setting parameters; to be removed after setting) Mini USB and the PC are used as links for monitoring, drive test runs, or writing parameters
7	Control signal (CN6)	Connection to the host controller
8	Feedback signal (CN7)	Connection to the motor encoder

3.1.2. CN1 power

The CN1 power wiring description includes single/three-phase power input, motor power output, regenerative resistor wiring, and single-phase control power input.

(1) Power wiring

Ensure that the drive has been grounded appropriately before connecting the drive to the main circuit.





Fig. 3-2 CN1 connector and installation

Table 3-2

	Signal	Function
	Oigilai	Гинскон
1	L1	AC main power, 220VAC (50/60Hz) single/three-phase
2	L2	AC main power, 220VAC (50/60Hz) single/three-phase
3	L3	AC main power, 220VAC (50/60Hz) three-phase
4	÷	Ground input of AC main power
5	Ŧ	Ground input of motor
6	U	U phase input of motor
7	V	V phase input of motor
8	W	W phase input of motor
9	REG-	Negative input of regenerative resistor
10	REG+	Positive input of regenerative resistor
11	L1C	Control power, 220VAC (50/60Hz) single-phase
12	L2C	Control power, 220VAC (50/60Hz) single-phase

(2) Motor wiring

Well grounding is needed between the drive and the motor.



Fig. 3-3

(3) Regenerative resistor wiring The regenerative resistor is mounted optionally according to the actual application design.



Fig. 3-4

Attention

- Wiring and inspection must be conducted by professional technicians.
- Turn off the power before wiring or inspection to avoid electric shock and other dangers.
- High voltage may remain in the drive after the power is turned off. Wait for a while (up to five minutes) before touching the power terminal.
- Perform the wiring appropriately and reliably to ensure stable operation and avoid injury, damage or other accidents.
- Do not connect the motor U, V or W terminal to the power source.
- The motor power terminal must be securely connected to the power source to avoid fire.
- Ensure that the drive and motor are grounded appropriately.
- Wiring must be conducted after installation of the drive and motor to avoid electric shock.
- Do not damage, pull or squeeze the wire so as to avoid electric shock.
- The drive may interfere with the operation of nearby electronic equipment. A noise filter can be used to reduce such electromagnetic interference.
- Do not attempt to modify the drive.
- Do not put the main circuit cable, I/O signal cable, or encoder cable in the same duct or bind them together. A distance of more than 30 cm must be maintained between the cables.
- The following instructions must be observed for wiring the main circuit terminals:
 - X Do not insert more than one wire in the same socket.
 - % Check there is no short circuit with any nearby wires after inserting the wire.
 - * Ensure the specified power voltage is used to avoid fire or damage.
- If the drive is to be used under poor or significantly fluctuating power conditions, ensure power is supplied within the specified voltage fluctuation range so as to avoid damage.
- Install a breaker or other safety devices to prevent external short circuits from damaging the drive.
- Appropriate isolating and sheltering measures must be taken if the drive is used in the following places to avoid adverse operation.
 - * Places exposed to static interference.
 - % Places exposed to strong electrical or magnetic fields.
 - * Places exposed to radiation.

3.1.3. CN2 brake

The brake can be wired with a relay. Refer to the wiring diagram for connection to the 24V DC brake. It is suggested that the brake power and other control power should not use the same power source.

(1) CN2 connector



Fig. 3-5

(2) Brake wiring with a relay



Fig. 3-6 Brake wiring with a relay

(3) Brake wiring without a relay



Fig. 3-7 Brake wiring without a relay

3.1.4. CN3 USB communication

Mini USB and a PC can be used as links for monitoring, performing drive test, or writing parameters. Please refer to Chapter 4.

Mini USB communication wiring diagram

Refer to HIWIN with a USB 2.0 Type A to mini-B 5-pin (1.8M) cable.



Fig. 3-8

3.1.5. CN6 control signal



SCSI 50PIN (Female)



SCSI 50PIN (Male)

Fig. 3-9

(1) CN6 pin definition:

	Table 3-3			
Pin	D2 Signal	D2T Signal	D2T with external I/O Signal	Function
1	CWL	CWL	CWL	Low-speed (500 Kpps) pulse command
3	CWL+	CWL+	CWL+	Channel 1: Pulse CW A phase
4	CWL-	CWL-	CWL-	
2	CCWL	CCWL	CCWL	Low encod (500Knno) pulse command
5	CCWL+	CCWL+	CCWL+	Channel 2: Dir CCW B phase
6	CCWL-	CCWL-	CCWL-	Chamer 2. Dir, COW, D phase
13	SG	SG	SG	Digital signal ground reference
21	A	А	A	
22	/A	/A	/A	
48	В	В	В	Output pulse of feedback (buffered encoder
49	/B	/В	/В	or emulated encoder)
23	Z	Z	Z	
24	/Z	/Z	/Z	
25	SG	SG	SG	Digital signal ground reference
19	CZ	CZ	CZ	Z phase output (open collector)
44	CWH+	CWH+	CWH+	High-speed (4 Mpps) pulse command
45	CWH-	CWH-	CWH-	Channel 1: Pulse, CW, A phase
46	CCWH+	CCWH+	CCWH+	High-speed (4 Mpps) pulse command
47	CCWH-	CCWH-	CCWH-	Channel 2: DIR, CCW, B phase
7	СОМ	СОМ	СОМ	Common port for general purpose input signal; can be either Sink or Source
33	11	11	11	
30	12	12	12	
29	13	13	13	
27	14	14	14	
28	15	15	15	General purpose input signal
26	16	16	16	(programmable function)
32	17	17	17	
31	18	18	18	
9	19	19	19	
8	N/A	110	110	
35	O1+	O1+	O1+	
34	O1-	O1-	01-	
37	O2+	O2+	O2+	
36	O2-	02-	O2-	
39	O3+	O3+	O3+	General purpose output signal
38	O3-	O3-	O3-	(programmable function)
11	O4+	O4+	O4+	
10	04-	O4-	O4-]
40	N/A	O5+	O5+	1
12	N/A	O5-	O5-	
50	FG	FG	FG	Frame ground reference

(2) System wiring diagram for pulse command

The host controller sends a pulse to the drive, which drives the motor to move a corresponding distance every time it receives a pulse. This pulse has a similar function to a position control command (P Command). The position mode receives host controller commands in three modes: Pulse/Dir, Pulse Up/Pulse Down (CW/CCW), and AqB.



3.1.6. CN13 & CN14 External I/O

CN13 and CN14 pin definition:

	Table 3-4				
CN13		CN14			
PIN	Signal	Function	PIN	Signal	Function
		Ou	tput		
1	Ex_OUT1+		1	Ex_OUT7+	
2	Ex_OUT1-		2	Ex_OUT7-	
3	Ex_OUT2+		3	Ex_OUT8+	
4	Ex_OUT2-		4	Ex_OUT8-	
5	Ex_OUT3+		5	Ex_OUT9+	
6	Ex_OUT3-	General purpose output	6	Ex_OUT9-	General purpose output
7	Ex_OUT4+	signal	7	Ex_OUT10+	signal
8	Ex_OUT4-		8	Ex_OUT10-	
9	Ex_OUT5+		9	Ex_OUT11+	
10	Ex_OUT5-		10	Ex_OUT11-	
11	Ex_OUT6+		11	Ex_OUT12+	
12	Ex_OUT6-		12	Ex_OUT12-	
	Input				
13	COM1+/-	Common port for general purpose input signal	13	COM2+/-	Common port for general purpose input signal
14	Ex_l1		14	Ex_l13	
15	Ex_l2		15	Ex_l14	
16	Ex_l3		16	Ex_l15	
17	Ex_l4		17	Ex_l16	
18	Ex_l5		18	Ex_l17	
19	Ex_l6	General purpose input	19	Ex_l18	General purpose input
20	Ex_l7	signal	20	Ex_l19	signal
21	Ex_l8		21	Ex_l20	
22	Ex_l9		22	Ex_l21	
23	Ex_I10		23	Ex_l22	
24	Ex_I11		24	Ex_l23	
25	Ex_l12		25	Ex_l24	

* There is no connection between COM1+/- and COM2+/-.



Fig. 3-11

3.1.7. CN7 encoder

Please press and pull the clamps on the both sides to remove CN7 connector.



SCR connector 10PIN (male)



Press and pull these clamps to remove CN7 connector

SCR connector 10PIN (female)

Table 3-5			
Pin	Signal	Function	
1	+5V DC	Encoder power output (+5Vdc)	
2	SG	Signal ground and +5Vdc ground	
3	PS+	Sorial aponder input	
4	PS-	Senai encoder input	
5	А		
6	/A		
7	В	Digital incremental anequar input	
8	/В	Digital incremental encoder input	
9	Z		
10	/Z		

Fig. 3-12

3.2. Standard main power wiring

Attention

- Wiring and inspection must be conducted by professional technicians.
- Turn off the power before wiring or inspection to avoid electric shock or other dangers.
- High voltage may remain in the drive after the power is turned off. Wait a while (up to five minutes) before touching the power terminal.
- Perform the wiring appropriately and reliably to ensure stable operation and to avoid injury, damage or other accidents.
- Do not attempt to modify the drive.

3.2.1. AC power wiring (single-phase)

It is recommended to use the FN2090-6-06 single-phase filter for 50W~400W AC motor, and the FN2090-10-06 single-phase filter for 750W~1KW AC motor





Table 3-6			
FN2090-6-06 filter			
Maximum continuous operating voltage	250V AC, 50/60Hz		
Operating frequency	DC to 400Hz		
Rated current	1 to 30 A@40℃		
Surge pulse protection	2kV, IEC 61000-4-5		
3.2.2. AC power wiring (three-phase)

It is recommended to use the FN3025HL-20-71 three-phase filter for D2-series drive.



Fig.	3-14
------	------

Table 3-7					
FN3025HL-20-71 filter					
Maximum continuous operating voltage	3 x 520/300V AC				
Operating frequency	DC to 60Hz				
Rated current	10 o 50A@50 [°] C				

3.3. I/O signal wiring

D2-model drive provides 9 general purpose inputs and 4 general purpose outputs on CN6 connector; while D2T-model drive provides 10 general purpose inputs and 5 general purpose outputs on CN6 connector. Users can define the function of each I/O point by using the software. In the following, the wiring examples D2-model drive are given. These examples can also be applied on D2T-model drive.

3.3.1. Digital input wiring

D2 general purpose input pins use an optical coupler input interface that is suitable for 12-24V DC voltage systems. D2 (D2T) has a total of 9 (10) general purpose inputs with a COM port suitable for Sink and Source connections. D2T drive with external I/O has 24 general inputs. COM ports of CN13 and CN14 are separated. They are suitable for Sink and Source connections.

I3 uses Axis Enable control by default and others are available for users to define HM functions based on their requirements.

(1) Input wiring





(2) Sink input wiring

A. Input via a switch or relay:



Fig. 3-16

B. Input via a transistor:



(3) Source input wiring

A. Wiring for input via switches or relays:



Fig. 3-18

B. Wiring for input via transistors:





3.3.2. Digital output wiring

D2 general purpose output pins use an optical coupler Darlington output interface that is suitable for a voltage system of less than 24V DC. D2 (D2T)-model drive has a total of 4 (5) general purpose outputs. Each output has an independent Darlington open collector circuit. The maximum allowable current is 100 mA. Users can define the function of each output by using the software.

· 01+	35
· 01-	34
· 02+	37
· 02-	36
· 03+	39
· 03-	38
• 04+	11
• 04-	10







(2) Output wiring via relays





(3) Output wiring via optical couplers



Fig. 3-23

4. Software Settings

4.	Software Settings	
	4.1. Installation and communication	
	4.1.1. Setup file	
	4.1.2. Communication setup	
	4.1.3. HMI main window	40
	4.2. Configuration center	43
	4.2.1. Motor configuration	44
	4.2.2. Encoder configuration	45
	4.2.3. Operation mode configuration	
	4.2.4. Completing configuration procedure	
	4.3. Auto phase center	
	4.3.1. Method overview	
	4.3.2. Pre-operation for phase initialization	
	4.3.3. Procedure of phase initialization	
	4.4. PDL loading and firmware update	50
	4.4.1. PDL loading	50
	4.4.2. Firmware update	52

4.1. Installation and communication

The human-machine interface (HMI) for D2-series drive is called Lightening. The communication between drive and PC is through USB connection. The Lightening graphical HMI on your PC can perform the functions including motor initialization, motor configurations, motion control, motor test runs and the corresponding parameter saving. This chapter describes how to install the product and connect it to your PC.

4.1.1. Setup file

The setup folder of the Lightening graphical HMI contains, among others, an auto execution file 'setup.exe' and a firmware folder 'dce' as shown in Fig. 4-1.



Fig. 4-1 Setup files

Please log in the HIWIN website to download the setup file. The path of this file is: "http://www.hiwinmikro.com.tw/hiwintree/Product_SubType.aspx?type=D2". Execute 'setup.exe' directly after completing downloads. The installation screen is shown in Fig. 4-2. The preset destination for the installation is "C:\mega_fabs\" for Lightening 0.177 or below, and "C:\HIWIN\" for Lightening 0.178 or above. Do not try to change this path. Press 'Start' to perform the auto installation procedure. When the setup procedure is completed, a popup window appears to show successful installation of the software as shown in Fig. 4-3. If the USB drive installation screen (Fig. 4-4) appears during the setup procedure, click 'Install' and 'OK' to finish the setup procedure.

HIWIN. company	Source: C:\mega_fabs setup.exe lightening\mega	_fabs\
	Destination: c:\mega_fabs\	

Fig. 4-2 Installation screen of the software



Fig. 4-3 Successful installation of the software



Fig. 4-4 Installation window for USB driver

The execution shortcut of the Lightening HMI program (Fig. 4-5) will appear on your PC desktop after installation. The path for this shortcut is:

"C:\mega_fabs\dce\toolswin\winkmi\lightening.exe" for Lightening 0.177 or below;

"C:\HIWIN\dce\toolswin\winkmi\lightening.exe" for Lightening 0.178 or above.



4.1.2. Communication setup

The method to communicate with drive is using USB communication.

Using USB communication

Connect the drive via USB and turn on the power before opening Lightening. The drive will automatically connect to the Lightening HMI when it is opened. If not, click 'Communication setup' in the 'Tools' menu to change the communication setup.



Fig. 4-6 Communication setup

The communication setup screen is shown below. D2 drive supports USB connections. "BPS" field shows the transmission rate and the default value is

115,200 bps (this should not be changed). The communication port is set in "Port" field. The field will display the existing port on your PC. Select the port that drive is actually connected to. Use default values in the remaining fields and the Lightening can be successfully communicated with drive.



Fig. 4-7 Connection and transfer rate settings

4.1.3. HMI main window

The HMI main window after the communication is shown in Fig. 4-8. Clicking the right key of mouse at the axis name and choosing "Rename" can modify the axis name. Users can also modify the axis name directly by clicking at the axis name.

D2 & D2T Applications for Tool Turret/Magazine v1.3

	IG, version 0.181, com9, Tools Language Ab	115200 out			
Drive Connection	d2 X	Controller: d2(0), Axis: X Motor type: AC servo Model: FRLS462X5 Axis is cofigured to: Stand-alone	Firmware version 0.034 Position Mode	* 	 Main toolbar
Axis name	Clicking the right mouse	Status Hardware Enable Input Software Enabled Servo ready		•	Status display area Error message
Properties Rename (F2) Set to default name Set all to default names	button at the axis name shows this	Cuick view Position Units Count			Quick View - signal monitoring
Connection status display area	menu.	30 Actual Current 1 Feedback Position 10 Feedback Velocity	0.000000 5 -0.795360	A_amp count count/s	area

Fig. 4-8 Main HMI window

(1) Main toolbar

The function of each button in the main toolbar is described as below.

- : Save parameters in the RAM to file.
- Load parameters in the file to RAM.
- : Save parameters in the RAM to FLASH.
- reset : Reset the drive.

(2) Status display

There are three indicators for displaying the statuses.

- Servo ready: The green light is on when the drive is enabled and goes out when the drive is disabled.
- Hardware Enable Input : The green light is on when the hardware is enabled. The drive cannot enable the motor if hardware is not enabled. Please refer to Appendix B for more information to enable hardware by using external input.
- Software Enabled: The green light is on when the software is enabled. Both hardware and software must be enabled for driving the motor. Click the 'Enable' button in the 'Performance Center' to enable the software, or click the 'Disable' button to disable the software. If there is no connection between your PC and the drive, the status of Software Enable is changed with the status of Hardware Enable. If you close Lightening when PC is connecting with drive, the Lightening HMI will query whether you want to enable or disable software after the window is closed.

(3) Drive property :

Clicking the right key of mouse at the axis name and choosing "Properties" can show the properties of this drive, as shown in Fig. 4-9.



Fig. 4-9

Note: When using Lightening 0.144 (or older versions) for connection to a D2-model drive, or using Lightening 0.180 (or older versions) for connection to a D2T-model drive, an installation error message as shown in Fig. 4-10 appears after the connection. This is because these HMI versions do not contain the firmware version (e.g. v0.006) of D2-model or D2T-model drive. Thus, Lightening cannot identify these drives. Please click 'Do nothing' and download the latest version of Lightening from the HIWIN website.



Fig. 4-10 Firmware version installation error message

4.2. Configuration center

When using a new drive or a new motor, please set up all required options according to your actual needs through 'Configuration Center'. Click 🧬 in the main toolbar to enter the Configuration Center. The position of the button is shown in Fig. 4-11.

LIGHTENING, version 0.181, c	om9, 115200			_ _ ×
Conf./Tune Tools Language	About			
🔗 🕐 नन 🛪 🔻 न	<u> </u>	김 🗐 🕯		r <mark>ese</mark> t
⊡ Drive ⊡ 0. d2 X	Controller: d2(0), Axis: X Motor type: AC servo Model:		Firmware v Ø.034	version
	Axis is cofigured to: St	and-alone	Position Mode	
	Status Hardware Enable Input Software Enabled Servo ready Last error Last warning Quick View Position Units			
	30 Actual Current	-	0.000000	A amp
	1 Feedback Position		0	count
	10 Feedback Velocity	-	0.00000	count/s
Communication ok	C:\HIWIN	\dce\lightening	.dce -> d2(0) , C:\HIWIN	ldce\d2\pdI00\

Fig. 4-11 Main functions screen

The following steps must be finished when using D2 drive to drive a motor:

- (1) Motor type: Set the type and all related parameters of the motor.
- (2) Encoder parameters: Set the type and the resolution of the encoder.
- (3) Operation mode: Set the operation mode of the drive.

The setup procedure is described step-by-step in the following sections.

4.2.1. Motor configuration

D2 drive supports AC servo motors. The motor configuration page is at the first page of the Configuration Center. The options are listed below Hill Motors. For the motor with serial encoder, users do not set motor parameters at this page, since the motor parameters are already stored in the encoder. Fig. 4-12 is the motor configuration page for Lightening 0.178 or above.

🔗 Configuratio	on center				
Motor	Encoder	Mode			
	s servo FRLS05XX5.mot FRLS10XX5.mot FRLS202X5.mot FRIMI1K2X5.mot FRIMI1K2X5.mot FRIMS202X5.mot FRIMS202X5.mot	Motor type: AC servo Motor Model Name: 1 Peak Current 7.5 Continuous Ct 2.5 Torque Consta 0.529999 Resistance (Li 3.5 Inductance (Li 13 Pole Number: 10 Motor Peak Tim 10 Moment of Inei 2.7e-5	PRLS 102X5	Manufacturer: HIWIN Load level LU3 Mass reference 50 kg Screw Pitch: 1 mm Gear Ratio: 1	- ZeroTune parameter setup area
				ок Саг	ncel

Fig. 4-12 Motor parameter settings for Lightening 0.178 or above

AC servo motor settings

(1) Motor parameters

Click on a HIWIN AC servo motor model. The parameters for the selected motor are displayed and can be set.

(2) Operation parameters

- Screw Moment of Inertia: the rotational inertia of the screw used. Unit: (Kg·m2).
- Load Mass: the mass to be loaded. Unit: Kg.
- Screw Pitch: the pitch of the ball screw (i.e. the linear movement amount of the screw in a revolution). Unit: mm
- Gear Ratio: the ratio of the gear teeth number at the load end to the gear teeth number at the drive end.

(3) ZeroTune parameters

- Servo loop gains can be easily set without complex procedures with this feature. By just selecting load level for a motor, stable velocity response can be achieved. Even beginners with no knowledge about servo control can easily drive a motor.

- Load level: the weight level of load. There are five levels, LV1~LV5. When this parameter shows "Tuned", it means the gain is not set by ZeroTune, and is modified by Auto tune or manual tune.
- Mass reference: the maximum reference weight corresponding to the selected level. Unit: Kg. Table 4-1 shows the maximum reference weight at the different combination of motor power and load level.

Motor power	LV1	LV2	LV3	LV4	LV5
50W,100W	5kg	15kg	30kg	45kg	60kg
200W,400W	10kg	25kg	50kg	75kg	100kg
750W,1KW	20kg	50kg	80kg	110kg	140kg

Setting correct operation parameters for motor helps to calculate suitable values of driving parameters, and thus successfully drive the motor.

4.2.2. Encoder configuration

The drive normally receives a feedback signal from the position encoder to perform servo control. The 13-bit encoder setup page is shown in Fig. 4-13; while The 17-bit encoder setup page is shown in Fig. 4-14. Please select or input the correct type and parameters of the encoder on this page.

Note:

If a HIWIN series AC servo motor is adopted, users just need to select the correct motor model. The program will automatically create a link to the encoder parameters applicable to this motor after the motor model selection.

🔗 Configuration center	r					
Motor E	ncoder	Mode				
Hiw Encoders	mized Rotay I 10000 cnte En Lin Oul C Sca Em	In type AC servo coder type: DIGITAL coder Model Name I 90999 Creations near Resolution: (9.1 ur neoder output put Resolution: 196 Use buffred encoder Invert Use emulated encoder Invert utated index radius:	1285 833 88884 ounts / Rev miCounts 8888 Counts/ ar er ercoder count = 1.8 counts	Manufacturer: 200 Power-on Time: 200 Rev Emulated index inter fill lated index jitter fill	HIVIN ms Coulput in every revolution. ed encoder output ter: I counts	
				ок	Cancel	

Fig. 4-13 13-bit encoder settings interface

🔗 Configuration c	enter	
Motor	Encoder	Mode
		Motor type: AC servo Encoder type: absolute Encoder model name: HQRH0011C701 Manufacturer: HIWIN
		Encoder resolution: 131072 counts/rev Linear resolution: 0.00762939 um/counts
		Encoder output Output resolution: 131072 counts/rev © Use buffered encoder Invert © Use emulated encoder Scalling: 1 encoder count = 1 emulated index output in every revolution.
		Emulated index radius: 1.3 counts Emulated index jitter filter 1 counts
		OK Cancel

Fig. 4-14 17-bit encoder settings interface

There is a variety of resolution parameters commonly used with HIWIN motor on Encoder settings page. Besides, users can enter parameters for any third-party encoder in the customized settings field on the same page.

4.2.3. Operation mode configuration

The algorithm of tool turret and tool magazine uses PDL with I/O. Hence, the mode should be set to stand-alone mode.

Motor Encoder		Mode	
- Primary Ope	ration Mode		
C Velocity Mode			
C Force/	Torque Mode Alone Mode		
Verday Mode Force/Torque Mode Stand-Alone Mode			

Fig. 4-15 Stand-Alone mode

4.2.4. Completing configuration procedure

After completing four parameter-setting steps above for the motor, encoder, hall sensor and operation mode, click 'OK' at the bottom of the screen. A window, as shown in Fig. 4-16, shows the parameters before and after the settings for comparison. After confirming the settings, click 'Send to RAM' to send the parameters to the drive. The screen returns to the Configuration Center if 'Cancel' is clicked.

Note:

When using a new drive without initialization, the 'OK' bottom at the end of configuration center is disabled and cannot be clicked. After motor parameters,

encoder parameters, and operation mode are set, the 'OK' bottom becomes enabling and has function.



Fig. 4-16 Completion of the configuration procedure

To retain this set of parameters, click ('Save to Flash') in the main HMI window to save the parameters in the flash memory. Parameters saved in the flash memory will be retained even if the drive is turned off.

To save the parameters to a file on your PC, click 🛃 ('Save Parameters from Amplifier RAM to File') to save the parameters to a file. The file extension is *.prm.

4.3. Auto phase center

4.3.1. Method overview

Click 🖸 in the main toolbar of main HMI window to open the auto phase center. The drive provides the following two phase initialization methods.

(1) STABS

This mode is used in the phase initialization of 17-bit serial encoders. I

Auto phase center	
View Details	
Enabled Phase Initialized Servo ready 1. Auto gain tuning Evocute	Phase initialization mode: STABS

Fig. 4-17 For motors with HIWIN 17 encoder and so on.

(2) LSWIR

This method features a hall sensor built in with the wire-saving incremental encoder.

🕐 Auto phase center		X
View Details		
Enabled Phase Initialized Servo ready	Phase initialization mode: LSWIR	
1. Auto gain tuning		
Execute		

Fig. 4-18 For motors with wire-saving encoder

4.3.2. Pre-operation for phase initialization

- * Confirm the connection to the motor is correct.
- * Confirm the encoder signal is correct.
- X Confirm the drive can receive the hardware excitation signal ('Hardware Enable')
- * Confirm if the motor overheat signal is connected.
- % Confirm the AC main power has been turned on.

4.3.3. Procedure of phase initialization

In this section, the operational flow of the LSWIR method is given. As for the STABS method, it can use the same flow of the LSWIR.

Step	Graphical (HMI) description	Operation
1	Auto phase center View Details Enabled Phase initialization mode: LSUIR Auto phase center Execute	Phase initialization method: If user selects that motor of model number ninth digit is 5. Lightening will automatically set LSWIR.
2	Auto phase center View Details Phase initialization mode: LSWIR Phase initialization Servo ready Lato gain luning Execute Phase initialized Phase initialized Servo ready Execute Phase initialized Servo ready Image: Auto tune Now motor is already enabled. To avoid incorrect gain tuning, please check if motor is far from hard stop. If No, please proceed Auto tuning. If Yes, please proceed Auto tuning. Gain is tuned Proceed Close	 Phase initialization and auto tune: Click the 'Execute' button, as in the left figure, to start the phase initialization. The 'auto tune' window pops up when the initialization is complete. Use and b to drive the motor and keep it operating continuously. Confirm that the motor has moved far from the stop. After the motor has moved, click the 'Proceed' button to start the auto tune. Click the 'Close' button to close the window after the tuning has been completed. Now the auto phase initialization is complete and test run functions can be performed. ** Note: Hardware enable needs to be triggered for this step. ** Note: Observe whether the Phase initialized and Servo ready lights are green to check if the phase initialization was executed successfully and if the servo close-loop control is readv. ** Note: The Gain is tuned status indicator flashes green during the auto gain process. The auto tuning is complete when it is continuously lit green or not continuously lit red. In this case, close the auto tune window and repeat Step 2.
3	Auto phase center View Details E Toggle Direction Phase initialization mode: LSWIR Phase Initialization Servo ready SMCL mode It is about to disable motor. For Z axis application of AC servo motor, if no brake is built in, clicking on Toggle may make axis falling. Toggle Cancel	If in the previous step, user finds that the positive moving direction is not according to expectation, it is possible to reverse the direction definition. Please use the "Toggle Direction" as shown in the left screen shots, and then carry out the previous step again.

4.4. PDL loading and firmware update

4.4.1. PDL loading

Step 1. Open PDL and click 🛃.			
LIGHTENING, version 0.168B, com17 (USB), 115200			
<u>Conf/Tune Tools Language A</u> bout			
🔗 🕐 🖅 🛪 🌹 📅 🛃	월 🛃 🛄	r <mark>ese</mark> t	

Fig. 4-19

Step 2. Click Edit bottom to open PDL edit page.

PDL 🔲 🛛 🔀				
Compile	Edit	Boot		
Compile no zip	Verify	Normal		
Load	Compare code only	File		
Compare mode	Compare	Close		
State Normal mode (PORT A)				
S1 id 0 tamuz DELFIN0335				
File c:\mega_fabs\dce\tamuz\pd100\main0.pd1				

Fig. 4-20

🔀 user.pdl PDL debug ver 3.59	×
<u>File Edit Yiew Options Macro H</u> elp	
◇ ◇ ※ 砲 ●, 茄 角 倉 → ● 地 10 Ⅲ 団 壱 師 恭	
● X 10 10 12 11 🔿 📷 🖬 🚧 13 13 12	
FILES USER may write is PDL code here	<
<	
c:\mega_fabs\dce\tamuz\pd100\user.pd1	1/
Fig. 4-21	

Step 3. After loading PDL program or completing coding, click "Compile" icon (
When the compilation is finished, click "Send to slave" bottom and then click "Yes" bottom.

D2 & D2T Applications for Tool Turret/Magazine v1.3



Fig. 4-22



Step 4. After PDL is sent to slave, the following window will close automatically, and the PDL loading is successful.

Compile		Edit	Boot
Compile no	zip	Verify	Normal
Load		Compare code only	File
Compare m	lode	Compare	Close
tate		DEI DI HAGOE]
S1 id 0 d2 DELFIN0335 File C:\HIWIN\dce\d2\pd100\main0.pd1			
lear page: ldrsses: Ø	page 4 , 1320000, W	start address: 32000 rite 26170 words	Ø

Fig. 4-24

4.4.2. Firmware update

To update the drive's firmware, click "Tools" on the HMI main window and select "Upgrade/Downgrade firmware..." as shown in Fig. 4-25. After clicking "Upgrade/ Downgrade firmware...", the window of "Upgrade/Down grade firmware" will appear, as shown in Fig. 4-26.



Fig. 4-26 Upgrade/Downgrade firmware

To update the firmware in the window of *Upgrade/Downgrade firmware*, please follow the steps below.

- Step 1. Click the left key of mouse on the firmware version, which needs to be updated, and highlight it with white letters on the blue background.
- Step 2. Click "File" at the left corner of window and select "Update selected firmware to amplifier" to open a dialog box, as shown in Fig. 4-27.



Fig. 4-27

Step 3. Click **Confirm** to open the window of "Auto load programs". The firmware will be loaded to drive automatically, as shown in Fig. 4-28.

Auto load programs	
d2: Test if PDL need complilation No need PDL compilation 0: d2 Go to boot mode	Image: Second
Image: S1 id 0 d2 DELFIN0335	I load AL_Core I load AL_Appl
File C:\mega_fabs\dce\d2\pd100\main0.pd1 Clear page: page4 , start address: 320000 Addrsses: 00320000, Write 24390 words	Run
	Verify DB Close

Fig. 4-28

Step 4. After the firmware is updated, the window of Fig. 4-29 appears. Click the **Conform** button.



Fig. 4-29

Note: Suppose that the power-off occurs or the communication between PC and drive breaks during the firmware being loaded to drive. After the drive is power-on again or the communication is built again, Lightening will stay at the "Boot mode", as shown in Fig. 4-30. Please contact the franchised dealer to assist excluded this problem.

C LIGHTENING, version 0.178, com Conf./Tune Tools Language Al	9,115200 pout	
S 🕄 🕫 🛪 🌹 📅	김 🗧 🔛	r <mark>ese</mark> t
E-HWIN Amplifier ☐- ∅ 0. d2	Controller: d2(0), Axis: <boot mode=""> Motor type: Boot mode Modet: Boot mode</boot>	Firmware version Boot mode
	Axis is cofigured to: Boot mode Status Hardware Enable Input Software Enabled Servo ready Last error Last warning Cutck view Position Units count 30 Actual Current Boi 1 Feedback Position Boi	ot mode A_amp ot mode count
	10 Feedback Velocity	ot mode count/s
d2(0) is in BOOT mode	C V-HWRVdceVightening-dce	 d2(0) , C.VHWIN/dce/d2/pdf00

Fig. 4-30

5. Troubleshooting

5.	Troubleshooting	. 55
	5.1. Drive status indicators	. 56
	5.2. Errors and warnings	. 57
	5.2.1. Status display area on HMI	. 57
	5.2.2. Errors and warnings log	. 57
	5.3. Error codes and reactions	. 60
	5.4. Warning codes and reactions	. 63

5.1. Drive status indicators

The status indicator of drive is a LED lamp located at the front panel. It displays the current status of drive. The statuses are described in the table below:



Status indicator

Status indicator	Status of the drive	
No light	The drive is not connected to the power source.	
Both red and green lamps flash	The drive is booting.	
Flash green	The motor is not power-on.	
Light green	The motor is power-on.	
Flash green and light red	The motor is not power-on and an error occurs.	

Note: The status indicator looks like orange when both red and green lamps are on.

Fig. 5-1

5.2. Errors and warnings

5.2.1. Status display area on HMI

When an error is identified, D2 drive will start the protection mechanism and show the message of last error in the "Last error" area, as shown in Fig. 5-2. Users can use this message to adjust and confirm the error of drive. When any incident needs to be warned during the operation, the drive will show the warning message in the "Last warning" area.

LIGHTENING, version 0.181, com9	, 115200		
Conf./Tune Tools Language Ab	pout		
🔗 🕐 🖅 🛪 🌹 📆	🚽 🗧 🛃 🛄	r <mark>ese</mark> t	
⊡	Controller: d2(0), Axis: X Motor type: AC servo Model: FRLS402X5	Firmware version 0.034	
	Axis is cofigured to: Stand-alone Positi	on Mode	
	Status		
	Soliwale Enabled		
	Last error		
	-Last warning-		
	Quick view		
	30 Actual Current 🔍 0.00	0000	A_amp
	1 Feedback Position v 5		count
	10 Feedback Velocity -0.7	95360	count/s
Communication ok	C:\HIWIN\dce\lightening.dce -> d	2(0), C:\HIWIN\dce\d2\p	dI00\

Fig. 5-2 Status display area

5.2.2. Errors and warnings log

When D2 drive detects the identified error or warning, it will store them in the *Errors* and *Warnings Log*, besides displaying in the error/warning display area on the HMI main screen, as shown in Fig. 5-2. The steps to open the window of *Errors* and *Warnings Log* are shown in Fig. 5-3.

.

Configuration center Auto phase center					
	1/0 💶	2	🛃 🛄	r <mark>ese</mark>	<mark>s</mark> t
Performance center Advanced gains Application center Protection center I D0 center Errors and Warnings Log	Controlle Status Status Laster Coutck Vie Position Count 30 Ac	er. d2(0), Axis: X Motor type: AC servo Model: FRLS202X1 Axis is cofigured to Stand- lardware Enable Input fortware Enabled bervo ready roor arning W Units tual Current edback Position	alone Positic	Firmware version Ø. 022 n Mode 000 00	A_amp count

Fig. 5-3 Open the Errors and Warnings Log

Lightening provides this function to prevent that users might lose the displayed error or warning message reported by D2 drive. All error and warning messages occurring after the drive is power-on and the occurring number of them are recorded in the *Errors and Warnings Log*. The time log of the *Errors and Warnings Log* is shown in Fig. 5-4. All occurred errors and warnings are recorded in the "Type of error/warning" column based on the chronological order, and the time of each event is recorded in the "Time (seconds)" column.

A Errors and Warnings Log				
Time Log	Statistics			
NOTE: The time sho	own below is calculated from the b	eginning of a reset or 24\	/dc turning on of the amp	lifier.
Type of error/wa	rning		Time (seconds)	
E06 Motor may b	e disconnect		23	
W05 Servo volta	ge big		23	
Double-Clicking at t will show help text for	he error or warning message or trouble shooting	ReFresh	lear History Save t	o bd-file

Fig. 5-4 Errors and Warnings Log

The statistics of the *Errors and Warnings Log* is shown in Fig. 5-5. The numbers of the occurred errors and warnings (*Frequency*) are also recorded in this log. With this information, users can understand the occurring frequency of each error and warning, and can take appropriate reactions.

A Errors and Warnings Log		
Time Log Statistics		
Errors		
Type of error	Frequency	^
E01 Motor short	0	
EU2 Over voltage	U	
E04 Encoder Error	0	
E05 Soft thermal threshold reached	ů N	=
E06 Motor may be disconnect	1	
E07 Amplifier over temperature	0	
E08 Motor over temperature	0	
E09 Under voltage	0	
E10 5V for encoder card fail	U	
E11 Filase line ender communication error	0	~
	Ŭ	
Type of warning	Frequency	
VVU1 Left SVV limit	U	
W02 Right SVV Infit	0	L
W04 Right HW limit	ŏ	1
W05 Servo voltage big	1	=
W06 Position error warning	0	
W07 Velocity error warning	0	
W08 Current Limited	0	
VVU9 Acceleration Limited	U	
W11 Both HW limits are active	0	
W12 I2T Warning	0	~
Double-Clicking at the error or warning message	Clear History Save to txt-file	
will show help text for trouble shooting		

Fig. 5-5 Statistics of the Errors and Warnings Log

If users want to know the content of error or warning event, they can double click the event name of error or warning to get the "Help tips" dialog box, as shown in Fig. 5-6. In this example, click "E06 Motor may be disconnect" to open the dialog box of E06, which shows the possible cause and solution for this error.

A Errors and Warnin	ings Log				
Time Log	Statistics				
NOTE: The time sho	own below is calculated from the beginning of a reset or 24Vdc turning on of the amplifier.				
Type of error/warning Time (seconds) E06 Motor may be disconnect 23 W05 Servo voltage big 23					
E06 Motor may be disconnect Help tips					
Motor cable is not connected or improper connection. Please check motor power cable is connected to drive correctly. 確定					
Double-Clicking at the will show help text for	the error or warning message ReFresh Clear History Save to bt-file				

Fig. 5-6 Help tips window of the Errors and Warnings Log

5.3. Error codes and reactions

No.	Errors	LCD error codes	Reactions
			Motor power cable short is detected.
1	Motor short (over current) detected	E01 SHORT	 After the power-off, remove the UVW connector at the drive and check whether the short circuit happens between UVW and ground. The motor might be burned out if the short circuit occurs. Measure the resistances between each line of motor's UVW to make sure that they are close to the specification. If the line resistance is much lower than the specifications, the motor might be burned out. Separate the motor from the motor power cable and use a multimeter to check if the motor power cable is short.
			DC bus voltage exceeds limit.
2	2 Over voltage E0. detected OVE	E02 OVERV	When the motor sustains a heavy load and operates at a high speed, this error may occur if the counter electromotive force exceeds the voltage limit. A regenerative resistor can be used to solve this problem. The used regenerative resistor must conform to the load and motion specifications.
			Position error exceeds the set maximum position error window.
3	Position error too big	E03 PEBIG	 The gain is tuned inappropriately. Confirm that Application center-> Protection-> maximum pos error is set appropriately. The motion of motor is obstructed. Check if the load is too heavy. The guideway has not been maintained for a long time. The cable trays are too tight. W05 SVBIG happens continuously before E03 occurs. If the used power is 110 V, please change it to 220 V.
			Position feedback signal is incorrect or the encoder reports error via its corresponding connection pin.
4	Encoder error	E04 ENCOD	 Check that all connectors of the encoder are connected firmly. Check that the encoder is wired correctly. If a digital encoder is used, this error may occur due to the external interference. Check that the encoder has an anti-interference twisted wire and shield or is equipped with an iron core.

No.	Errors	LCD error codes	Reactions
			Overcurrent protection. (The software detects over- temperature of the motor.)
5	Soft-thermal threshold reached	E05 SWHOT	 Confirm that the continuous current and peak current of motor conforming to the motor's specifications during the motion. The motion of motor is obstructed. This error can be eliminated by resetting and re-enabling the drive, but it may recur if the output current exceeds the specified value due to the load and motion parameters. Reduce the speed, acceleration or deceleration. The motor model name or current parameter of motor is set incorrectly.
			Motor power cable is not connected or improper connection.
6	Motor maybe disconnected	maybe E06 nected UVWCN	 Check that the connector of UVW power cable is connected firmly. Check that the motor model name is set correctly.
			Drive exceeds maximum operating temperature.
7	Amplifier over temperature	er E07 e D.HOT	 Check that the position where the drive is installed is well ventilated. Check that the ambient air temperature is not too high. Wait for the down of the temperature inside the drive. The load is too heavy or the operation cycle of drive is too high. A cooling fin can be mounted if needed.
			The input voltage of AC main power is too low.
8	Under voltage detected	E09 UND.V	Confirm that the L1 and L2 of drive are connected to a 100 or 220 Vac power source. Use a multimeter to make sure that there is a 100 or 220 Vac power input.
			False 5V dc power to encoder.
9	5V for encoder card fail	V for encoder E10 card fail V5ERR	 Remove the connectors of CN6, CN7, and motor power cable from D2 drive. Check whether E10V5ERR still occurs or not. If yes, please contact the manufacturer to repair and check. If no, please check if the short circuit happens and modify the wiring. Do not hot-plug CN6 and CN7 connectors of D2 drive.
	Phase	F11	Motor phase initialization error. The 17-bit encoder cable is connected to the motor with 13-bit encoder.
10	initialization error	PHINI	 Check that the UVW motor power cable is connected to the drive. Check that the encoder cable is connected to the drive.

D2 & D2T Applications for Tool Turret/Magazine v1.3

No.	Errors	LCD error codes	Reactions
			Serial encoder communication error.
11	Serial Encoder Communicatio n Error	E12 SER.E	 Check that the encoder cable is connected to drive. Check that the encoder cable conforms to the specification of motor.
		E 40	Hall signal of wire-saving encoder fails.
12 Hall se errc	Hall sensor error	HAL.E	Check that the encoder cable is connected to the drive correctly.
13	Current control error	ent control E15 error CURER	The control of current loop is incorrect.
			Please check whether motor model is set correctly, the gain of the current loop (Kp) is properly set, the CG is properly set, and the encoder wire is installed well.
	Hybrid deviation too big	Hybrid deviation too big	Under dual loop control architecture, hybrid deviation exceeds the threshold.
14			Please check whether linear encoder parameter is correct, the directions of the linear and the rotary encoder are matching, or the linear encoder has noise problems. Please check if the coupling and the gear are installed well, or the pitch tolerance and the backlash of the screw are small enough.
15	HFLT	E19	The drive fault signals are inconsistent.
15 inconsister error	error	HFLT	Please check the grounding.

5.4. Warning codes and reactions

No.	Errors	LCD error codes	Reactions
1	Left SW limit	W01 SWLL	Motor reached left software limit position and is prohibited to move further toward left direction.
2	Right SW limit	W02 SWRL	Motor reached right software limit position and is prohibited to move further toward right direction.
			Left hardware limit switch is triggered and motor is prohibited to move further toward left direction
3	Left HW limit	W03 HWLL	 If the erroneous trigger occurs without any connection from hardware limit to drive. It is recommended to disable the hardware limit function. If the hardware limit is not triggered, please check connection and whether activation logic is correct.
			Right hardware limit switch is triggered and motor is prohibited to move further toward right direction.
4 Right HW limit	W04 HWRL	 If the erroneous trigger occurs without any connection from hardware limit to drive. It is recommended to disable the hardware limit function. If the hardware limit is not triggered, please check connection and whether activation logic is correct. 	
5	Servo voltage big	ervo voltage W05 big SVBIG	The PWM output of drive exceeds the limit and the current output cannot be increased any more. The error code E03 PEBIG will happen if this warning occurs repeatedly under the position control.
			 Change the power source to 220 V if 110 V is used currently. Decrease the speed, acceleration or deceleration.
			Position error exceeds the set position error warning window.
6	Position error warning	Position error W06 warning PE	 Check if common gain is properly tuned. Check if the warning window is not set too small. When the motor is not implemented lubrication beyond the maintenance period, it may also cause this phenomenon.
			Velocity error exceeds the set velocity error warning window.
7	Velocity error warning	W07 VE	 Check if common gain is properly tuned. Check if the warning window is not set too small. When the motor is not implemented lubrication beyond the maintenance period, it may also cause this phenomenon.

No.	Errors	LCD error codes	Reactions
8	Current W08	The current has been saturated and reaches the peak current of motor. If this warning occurs repeatedly, E05 SWHOT may occur.	
	Limited	CUR.L	(1) Decrease the speed, acceleration or deceleration.(2) Reduce the load.
0	Acceleration	eration W09	The motor has reached the protection setting value of acceleration when it operates at the position or velocity mode.
5	Limited	ACC.L	To increase the acceleration, set a higher protection value for acceleration or deceleration.
10 Velocity Limited	Velocity	elocity W10 mited VEL.L	The motor has reached the protection setting value of velocity when it operates at the velocity or torque mode.
	Limited		To increase the velocity, set a higher protection value for velocity.
			Both left and right hardware limits have been triggered.
11	Both HW limits active	oth HW W11 its active BOTH	 If the erroneous trigger occurs without any connection from hardware limit to drive. It is recommended to disable the hardware limit function. If the hardware limit is not triggered, please check connection and whether activation logic is correct.
			Homing fails.
12	Homing fail	W13 HOM.E	 Check if left and right limit sensors, near home sensor, and index signal are installed correctly. Check if values of time out and search end stop current are set well.
13	Pulse command	W14	Under position mode, the command conflict occurs when the drive is simultaneously receiving pulse command and homing.
	conflict	ng HOM.C	Please do not send pulse command and start the built-in homing feature at the same time.
14	Absolute encoder battery warning	W15 BAT.E	The absolute encoder battery voltage is too low. Please replace the battery.
15	Wrong	W16	The absolute position is wrong from the encoder. Please reset the home position.
15	position	position ABS.W	Please to check the statues of encoder battery.

6.Specifications & Accessories

6.	Spec	cifications & Accessories	65
	6.1.	Part numbers	66
	6.2.	Motor specifications	67
	6.3.	Drive dimensions	73
	6.4.	Cable and Connector	76
		6.4.1. Motor cable	76
		6.4.2. Encoder cable	77
	6.5.	Composition of peripheral equipment	78
		6.5.1. Communication cable and control signal cable	78
		6.5.2. Regenerative resistor	78
		6.5.3. EMC accessory part	79

6.1. Part numbers

	Motor	Drive
	FRLS052□5XX∆	D2-0123-S-A0
50W	FRLS052□4XX∆	D2T-0123-S-A5
	FRLS052□4XX∆	D2T-0123-K-A5
	FRLS102□5XX∆	D2-0123-S-A0
100W	FRLS102□4XX∆	D2T-0123-S-A5
	FRLS052□4XX∆	D2T-0123-K-A5
	FRLS202□5XX∆	D2-0423-S-B0
200W	FRLS202□4XX∆	D2T-0423-S-B5
	FRLS052□4XX∆	D2T-0423-K-B5
	FRLS402□5XX∆	D2-0423-S-B0
400W	FRLS402□4XX∆	D2T-0423-S-B5
	FRLS052□4XX∆	D2T-0423-K-B5
	FRLS752□5XX∆	D2-1023-S-C0
750W	FRLS752□4XX∆	D2T-1023-S-C5
	FRLS052□4XX∆	D2T-1023-K-C5
	FRLS1K2□5XX∆	D2-1023-S-C0
1KW	FRLS1K2□4XX∆	D2T-1023-S-C5
	FRLS052□4XX∆	D2T-1023-K-C5

Table 6-1 Part numbers

Note :

- (1) The 9-bit of motor model name denotes encoder type, where 5 is for 13-bit incremental encoder and 4 is for 17-bit absolute encoder.
- (2) In the motor model name, □ is for brake option, XX is for frame size, and △ is for shaft specification.

6.2. Motor specifications

AC 50W (low inertia and small capacity)

Motor parameter	Symbol	Unit	FRLS05200A40		
Drive input voltage	V	V	AC 220		
Rated power	W	W	50		
Rated torque	T _c	N.m	0.16		
Rated current	I _c	A (rms)	0.9		
Peak max. torque	Tp	N.m	0.48		
Peak max. current	l _p	A (rms)	2.7		
Rated speed	ω _c	rpm	3000		
No load max. speed	ω_{p}	rpm	4500		
Torque constant	Kt	N.m / A _{rms}	0.178		
Back EMF constant	K _e	V _{rms} / k _{rpm}	10.74		
Resistance (line to line)	R	Ω	4.7		
Inductance (line to line)	L	mH	4.7		
Inertia of rotating parts (with brake)	J	kg-m ² (×10 ⁻⁴)	0.02 (0.022)		
Weight (with brake)	М	kg	0.45 (0.58)		
Motor insulation grade	Class A (UL)				
Motor protection	Total enclosed, self-cooled, IP65 (Except for shaft and connector)				
Insulation resistance	10 MΩ, DC 500V				
Insulation strength	AC1500V, 60 sec				
Brake specifications					
Brake keep torque (min.)	T _b	N.m	0.3		
Brake exciting current	Ab	A	0.25		
Brake voltage	V	V	DC 24 ± 10%		
Brake pull-in time (max.)	t _o	ms	30		
Brake release time (max.)	t _r	ms	20		

Torque-Speed Curve



Dimensions



■ AC 100W (low inertia and small capacity)

Motor parameter	Symbol	Unit	FRLS10200A40		
Drive input voltage	V	V	AC 220		
Rated power	W	W	100		
Rated torque	T _c	N.m	0.32		
Rated current	I _c	A (rms)	0.9		
Peak max. torque	Tp	N.m	0.96		
Peak max. current	l _p	A (rms)	2.7		
Rated speed	ω _c	rpm	3000		
No load max. speed	ω_{p}	rpm	4500		
Torque constant	K _t	N.m / A _{rms}	0.356		
Back EMF constant	K _e	V_{rms} / k_{rpm}	21.98		
Resistance (line to line)	R	Ω	8		
Inductance (line to line)	L	mH	8.45		
Inertia of rotating parts (with brake)	J	kg-m ² (×10 ⁻⁴)	0.036 (0.038)		
Weight (with brake)	М	kg	0.63 (0.76)		
Motor insulation grade	Class A (UL)				
Motor protection	Total enclosed, self-cooled, IP65 (Except for shaft and connector)				
Insulation resistance	10 MΩ, DC 500 V				
Insulation strength	AC1500V, 60 sec				
Brake specifications					
Brake keep torque (min.)	T _b	N.m	0.3		
Brake exciting current	A _b	А	0.25A		
Brake voltage	V	V	DC24±10%		
Brake pull-in time (max.)	t _o	ms	30		
Brake release time (max.)	t _r	ms	20		

Torque-Speed Curve



Dimensions


■ AC 200W (low inertia and small capacity)

Motor parameter	Symbol	Unit	FRLS2020060		
Drive input voltage	V	V	AC 220		
Rated power	W	W	200		
Rated torque	T _c	N.m	0.64		
Rated current	I _c	A (rms)	1.7		
Peak max. torque	Tp	N.m	1.92		
Peak max. current	l _p	A (rms)	5.1		
Rated speed	ω _c	rpm	3000		
No load max. speed	ω_{p}	rpm	4500		
Torque constant	K	N.m / A _{rms}	0.38		
Back EMF constant	K _e	V_{rms} / k_{rpm}	23		
Resistance (line to line)	R	Ω	4.3		
Inductance (line to line)	L	mH	13		
Inertia of rotating parts (with brake)	J	kg-m ² (×10 ⁻⁴)	0.17 (0.21)		
Weight (with brake)	М	kg	0.95 (1.5)		
Motor insulation grade		Class A (UL)			
Motor protection	Total enclosed, self-cooled, IP65 (Except for shaft and connector)				
Insulation resistance	10 MΩ, DC 500V				
Insulation strength	AC1500V, 60 sec				
Brake specifications					
Brake keep torque (min.)	T _b	N.m	1.3		
Brake exciting current	A _b	А	0.32		
Brake voltage	V	V	DC 24 ± 10%		
Brake pull-in time (max.)	t _o	ms	30		
Brake release time (max.)	t _r	ms	20		

■ Torque-Speed Curve



Dimensions



AC 400W (low inertia and small capacity)

Motor parameter	Symbol	Unit	FRLS4020060		
Drive input voltage	V	V	AC 220		
Rated power	W	W	400		
Rated torque	T _c	N.m	1.27		
Rated current	I _c	A (rms)	2.5		
Peak max. torque	Tp	N.m	3.81		
Peak max. current	l _p	A (rms)	7.5		
Rated speed	ω _c	rpm	3000		
No load max. speed	ω_{p}	rpm	4500		
Torque constant	K	N.m / A _{rms}	0.51		
Back EMF constant	K _e	V_{rms} / k_{rpm}	31.9		
Resistance (line to line)	R	Ω	3.5		
Inductance (line to line)	L	mH	13		
Inertia of rotating parts (with brake)	J	kg-m ² (×10 ⁻⁴)	0.27 (0.31)		
Weight (with brake)	М	kg	1.31(1.86)		
Motor insulation grade		Class A (UL)			
Motor protection	Total enclosed, self-cooled, IP65 (Except for shaft and connector)				
Insulation resistance	10 MΩ, DC 500V				
Insulation strength	AC1500V, 60 sec				
Brake specifications					
Brake keep torque (min.)	T _b	N.m	1.3		
Brake exciting current	A _b	А	0.32		
Brake voltage	V	V	DC 24 ± 10%		
Brake pull-in time (max.)	to	ms	30		
Brake release time (max.)	t _r	ms	20		

■ Torque-Speed Curve



Dimensions



■ AC 750W (medium inertia and small capacity)

Motor parameter	Symbol	Unit	FRMS7520080		
Drive input voltage	V	V	AC 220		
Rated power	W	W	750		
Rated torque	T _c	N.m	2.4		
Rated current	I _c	A (rms)	5.1		
Peak max. torque	T_{p}	N.m	7.2		
Peak max. current	l _p	A (rms)	15.3		
Rated speed	ω_{c}	rpm	3000		
No load max. speed	ω_{p}	rpm	4500		
Torque constant	K _t	N.m / A _{rms}	0.47		
Back EMF constant	K _e	V_{rms} / k_{rpm}	28.4		
Resistance (line to line)	R	Ω	0.813		
Inductance (line to line)	L	mH	3.4		
Inertia of rotating parts (with brake)	J	kg-m ² (×10 ⁻⁴)	1.4 (1.46)		
Weight (with brake)	М	kg	2.66 (3.32)		
Motor insulation grade		Class A (UL)			
Motor protection	Total enclosed, self-cooled, IP65 (Except for shaft and connector)				
Insulation resistance	10 MΩ, DC 500V				
Insulation strength	AC1500V, 60 sec				
Brake specifications					
Brake keep torque (min.)	Τ _b	N.m	2.4		
Brake exciting current	Ab	A	0.358		
Brake voltage	V	V	DC 24 ± 10%		
Brake pull-in time (max.)	to	ms	45		
Brake release time (max.)	t _r	ms	10		

Torque-Speed Curve



Dimensions



AC 1KW (medium inertia and medium capacity)

Motor parameter	Symbol	Unit	FRMM1K2□□13□		
Drive input voltage	V	V	AC 220		
Rated power	W	W	1000		
Rated torque	T _c	N.m	4.77		
Rated current	I _c	A (rms)	5.1		
Peak max. torque	T_{p}	N.m	14.3		
Peak max. current	l _p	A (rms)	15.3		
Rated speed	ω_{c}	rpm	2000		
No load max. speed	ω_{p}	rpm	3000		
Torque constant	K _t	N.m / A _{rms}	0.94		
Back EMF constant	K _e	V _{rms} / k _{rpm}	54.7		
Resistance (line to line)	R	Ω	0.81		
Inductance (line to line)	L	mH	8		
Inertia of rotating parts (with brake)	J	kg-m ² (×10 ⁻⁴)	7.6 (8.7)		
Weight (with brake)	М	kg	5.4 (6.2)		
Inertia of rotating parts (with brake)	Class A (UL)				
Weight (with brake)	Total enclosed, self-cooled, IP65 (Except for shaft and connector)				
Motor insulation grade	10 MΩ, DC 500V				
Motor protection	AC1500V, 60 sec				
Brake specifications					
Brake keep torque (min.)	Τ _b	N.m	10		
Brake exciting current	Ab	A	0.56		
Brake voltage	V	V	DC 24 ± 10%		
Brake pull-in time (max.)	t _o	ms 80			
Brake release time (max.)	t _r	ms	30		

■ Torque-Speed Curve



With key





6.3. Drive dimensions

■ A frame [D2(T)-01□□-S-A□]

■ B frame [D2(T)-04□□-S-B□]



Fig. 6-1



Fig. 6-2

66.2

■ C frame [D2(T)-10□□-S-C□] 179.9 Unit: mm 227.4 4 60 6.5 28 ±0. 1.5 IC 165.5 ±0.1 173.5 T Ģ 4 47 4-Ø4.4 D2-DNN48A



■ A frame with external I/O [D2T-01□□-K-A□]









■ B frame with external I/O [D2T-04□□-K-B□]



Unit: mm



Fig. 6-5

■ C frame with external I/O [D2T-10□□-K-C□]



Unit: mm



6.4. Cable and Connector

6.4.1. Motor cable

Table 6-2						
Part Output power		Туро	Longth	Part No.		
name				Bendable type*		
			3 m	HVPS04AA03MB		
			5 m	HVPS04AA05MB		
	5000 ~ 75000	D2-DI N01A	7 m	HVPS04AA07MB		
			10 m	HVPS04AA10MB		
			3 m	HVPM04BA03MB		
Motor			5 m	HVPM04BA05MB		
cable			7 m	HVPM04BA07MB		
		DZ-DLNUZA	10 m	HVPM04BA10MB		
	1KW / 2KW		3 m	HVPM04CA03MB		
			5 m	HVPM04CA05MB		
			7 m	HVPM04CA07MB		
		D2-DLN03A	10 m	HVPM04CA10MB		
50\\/			3 m	HVPS06AA03MB		
		Þ	5 m	HVPS06AA05MB		
	5000 ~ 75000		7 m	HVPS06AA07MB		
		D2-DLN04A	10 m	HVPS06AA10MB		
Motor			3 m	HVPM06BA03MB		
cable			5 m	HVPM06BA05MB		
with brake		▝▁▇▋▆▁▁ੑੑੑੑੑੑੑੑੑੑੑਗ਼ੑੑੑੑੑੑੑੑੑੑੑਗ਼ੑੑੑੑੑੑੑੑੑੑੑੑ	7 m	HVPM06BA07MB		
		D2-DLN05A	10 m	HVPM06BA10MB		
	1KW / 2KW		3 m	HVPM06CA03MB		
			5 m	HVPM06CA05MB		
			7 m	HVPM06CA07MB		
			10 m	HVPM06CA10MB		

*For the moving application, the bendable-type cable is suggested, e.g., robot.

6.4.2. Encoder cable

Table 6-3						
Part Output power		Туро	Longth	Part No.		
name		туре	Length	Bendable type*		
			3 m	HVE13IAB03MB		
			5 m	HVE13IAB05MB		
	5000 ~ 75000	D2-DLN07A	7 m	HVE13IAB07MB		
			10 m	HVE13IAB10MB		
			3 m	HVE13IBB03MB		
13-bit			5 m	HVE13IBB05MB		
cable			7 m	HVE13IBB07MB		
		UZ-DLNUGA	10 m	HVE13IBB10MB		
			3 m	HVE13ICB03MB		
			5 m	HVE13ICB05MB		
			7 m	HVE13ICB07MB		
		D2-DLN09A	10 m	HVE13ICB10MB		
			3 m	HVE17IAB03MB		
	50W ~ 750W		5 m	HVE17IAB05MB		
		D2-DLN10A	7 m	HVE17IAB07MB		
			10 m	HVE17IAB10MB		
			3 m	HVE17IBB03MB		
17-bit			5 m	HVE17IBB05MB		
encoder cable			7 m	HVE17IBB07MB		
		DZ-DENTIA	10 m	HVE17IBB10MB		
	ΤΚVV / 2ΚVV		3 m	HVE17ICB03MB		
			5 m	HVE17ICB05MB		
			7 m	HVE17ICB07MB		
		D2-DLN12A	10 m	HVE17ICB10MB		

*For the moving application, the bendable-type cable is suggested, e.g., robot.

6.5. Composition of peripheral equipment

6.5.1. Communication cable and control signal cable



6.5.2. Regenerative resistor

Table 6-5

Part name	Model	Description	L1 (mm)	L2 (mm)	W (mm)	H (mm)
Regenerative	RG1	68 Ω Rated power: 100W Peak power: 500W (050100700001)	165±2	150±2	40±0.5	20±0.5
resistor	RG2	120 Ω Rated power: 300W Peak power: 1500W (050100700009)	215±2	200±2	60±0.5	30±0.5





6.5.3. EMC accessory part

Part name	Model	Description	Quantity
D2 EMC accessory pack for single-phase	D2-EMC1	Single-phase filter FN2090-6-06 (for 50W to 400W) - Rated current: 6 A - Leakage current: 0.67mA	1
		EMI core KCF-130-B	2
	D2-EMC3	Single-phase filter FN2090-10-06 (for 750W to 1KW) - Rated current: 10 A - Leakage current: 0.67mA	1
		EMI core KCF-130-B	2
D2 EMC accessory pack for three-phase	D2-EMC2	Three-phase filter FN3025HL-20-71 - Rated current: 20 A - Leakage current: 0.4mA	1
		EMI core KCF-130-B	2



© HIWIN Mikrosystem Corp.