HIWIN. MIKROSYSTEM



PM Series Incremental Position Measurement System

User Manual

Related Documents

Through related documents, users can quickly understand the positioning of this manual and the correlation between manuals and products. Go to HIWIN MIKROSYSTEM's official website → Download → Manual Overview for details (https://www.hiwinmikro.tw/Downloads/ManualOverview EN.htm).

Approvals

Approvals				
	EU Directives			
Integration Standards	Emissions	EN-61000-6-4:2007/A1:2011		
	Immunity	EN 6100-6-2:2005		
PM Series Incremental Position	EU Directives			
Measurement System Model	C€	RoHS Directive		
PM-00-00-T-00	✓	✓		
PM-00-00-00-C-00	✓	✓		
PM-00-00-G-00-00	√	✓		

Note:

EN: Europäische Norm = European standard

Table of Contents

1.	Gen	eral infor	mation	1-1
	1.1	Re	evision history	1-2
	1.2	Ak	oout this manual	1-3
	1.3	G	eneral precautions	1-4
	1.4	Sa	afety instruction	1-5
	1.5	Co	ppyright	1-7
	1.6	Ma	anufacturer information	1-7
	1.7	Pr	oduct monitoring	1-7
2.	Bas	ic safety	information	2-1
	2.1	O	verview	2-2
	2.2	Ва	asic safety notices	2-2
	2.3	Re	easonably foreseeable misuse	2-3
		2.3.1	Environment factors	2-3
		2.3.2	Personal factors	2-3
	2.4	Co	onversions and modifications	2-3
	2.5	Re	esidual risks	2-4
	2.6	Pe	ersonnel requirements	2-4
	2.7	Pr	otective equipment	2-5
		2.7.1	Personal protective equipment	2-5
	2.8	La	abels on PM series incremental position measurement system	2-5
3.	Prod	duct desc	pription	3-1
	3.1	PI	M series incremental position measurement system description	3-2
	3.2	M	ain components of PM series incremental position measurement system	3-3
		3.2.1	Technical specifications of scale (PS08 series)	3-3
		3.2.2	Technical specifications of readhead	3-4
		3.2.3	Specifications of signal	3-6
	3.3	Oı	rder code	3-7
		3.3.1	Scale	3-7
		3.3.2	Readhead	3-8
4.	Trar	nsport an	d setup	4-1
	4.1	De	elivery	4-2
	4.2 Transport to the installation site			4-2
	4.3	Re	equirements at the installation site	4-3
		4.3.1	Recommended accuracy for installation surface	4-3

		4.3.2	Dimensions of PM series incremental position measurement system	4-4
	4.4	Sto	orage	4-7
	4.5	Un	npacking and setup	4-8
5.	Ass	embly and	d connection	5-1
	5.1	Me	echanical installation	5-2
		5.1.1	Scale installation	5-3
		5.1.2	Readhead installation	5-5
	5.2	Ele	ectrical installation	5-6
		5.2.1	Port types of readhead	5-7
		5.2.2	Configuration of signal receiver	5-11
6.	Con	nmissionir	ng	6-1
	6.1	Co	ommissioning	6-2
7.	Maiı	ntenance	and cleaning	7-1
	7.1	Ma	aintenance	7-2
	7.2	Cle	eaning	7-2
8.	Disp	osal		8-1
	8.1	Wa	aste disposal	8-2
		8.1.1	Readhead	8-2
9.	Trou	ıbleshooti	ing	9-1
	9.1	Tro	oubleshooting	
		9.1.1	Readhead	9-2
10.			tion of incorporation	
	10.1	De	eclaration of incorporation	10-2
11.		Appendi	ix	11-1
	11.1		ossary	
	11.2	. Un	nit conversion	11-3
	11.3	Tol	lerances and hypotheses	11-5
		11.3.1	Dimensional tolerances	11-5
		11.3.2	Geometric tolerances	
	11.4	- Op	otional accessories	11-6


(This page is intentionally left blank.)

1. General information

1.	General i	information	1-1
	1.1	Revision history	1-2
	1.2	About this manual	1-3
	1.3	General precautions	1-4
	1.4	Safety instruction	1-5
	1.5	Copyright	1-7
	1.6	Manufacturer information	1-7
	1.7	Product monitoring	1-7

1.1 Revision history

The version of the manual is also indicated on the bottom of the front cover.



Release Date	Version	Applicable Product	Revision Contents
Oct. 30 th , 2024	1.0	PM series incremental position measurement system	First edition.

General information

1.2 About this manual

This manual aims to assist users to operate PM series incremental position measurement system. The content of this manual contains introduction, sizing, installation, troubleshooting, maintenance, waste disposal and appendix. Before using the product, please carefully read through this manual, and follow the general precautions and safety instruction to ensure normal operation of the product.

1.3 General precautions

Before using the product, please carefully read through this manual. HIWIN MIKROSYSTEM is not responsible for any damage, accident or injury caused by failure in following the installation instructions and operating instructions stated in this manual.

- Before installing or using the product, ensure there is no damage on its appearance. If any damage is found after inspection, please contact HIWIN MIKROSYSTEM or local dealers.
- Carefully read through the specification noted on the product label or technical document, and check if the product is used with the power supply specified in the product requirement. Install the product in accordance with the specification and instructions stated in this manual. HIWIN MIKROSYSTEM is not responsible for any damage, accident or injury caused by the usage of incorrect power supply.
- Do not subject the product to shock or place it in risky locations. HIWIN MIKROSYSTEM is not responsible for any damage, accident or injury caused by improper usage.
- Do not disassemble or modify the product on your own. The design of the product has been verified by structural calculation, simulation analysis and actual testing. HIWIN MIKROSYSTEM is not responsible for any damage, accident or injury caused by disassembly or modification done by users without authorization.
- Avoid using magnetic tools, screws, magnetic storage devices, or precision instruments to contact the scale. HIWIN MIKROSYSTEM is not responsible for any damage, accident or injury caused by this.
- If an error or any abnormal conditions occur in the product, please refer to chapter 9 and follow the instructions for troubleshooting. The product can only be repaired by qualified technician from HIWIN MIKROSYSTEM. HIWIN MIKROSYSTEM is not responsible for any damage, accident or injury caused by human factors.
- If the information of registration does not match with your purchasing or if there are any questions related to the product, please contact the sales representatives of HIWIN MIKROSYSTEM or agents or dealers.

HIWIN MIKROSYSTEM offers 1-year warranty for the product. The warranty does not cover damage caused by improper usage (refer to the precautions and instructions stated in this manual) or natural disaster.

1.4 Safety instruction

- Carefully read through this manual before installation, transportation, maintenance, and examination.
 Ensure the product is correctly used.
- Carefully read through electromagnetic (EM) information, safety information, and related precautions.
- Safety precautions in this manual are classified into "DANGER," "WARNING," and "CAUTION."

ADANGER

Imminent danger!

Indicates that death or severe personal injury will result if proper precautions are not taken.

MARNING

Potentially dangerous situation!

Indicates that death or severe personal injury may result if proper precautions are not taken.

△CAUTION

Potentially dangerous situation!

Indicates that property damage or environmental pollution can result if proper precautions are not taken.

Warning Signs



Warning!



Electrostatic-sensitive device.



Do not scratch the scale with sharp objects.



Keep magnetic objects away from the scale.



Do not band the scale.



When storing the scale, the radius should not be smaller than 50 mm.

Mandatory Signs



Refer to user manual!



Disconnect before carrying out maintenance or repair.



Wear protective gloves!



Wear safety footwear!

ADANGER

Do not use the product in explosive zones.

WARNING

During operation, do not touch any movable parts (e.g., readhead) to avoid bruising, rubbing, abrasing, and seizing of limbs or clothes.



- Since the readhead is sensitive to static electricity, please be careful. Without proper ESD protection, do not touch the cables or the pins of connectors.
- Do not perform wiring work or disconnect electrical connections when power on.
- Perform wiring work in power off state only.
- Check all the cables and plug connections before switching on the device.

ACAUTION

- Do not scratch the scale with sharp objects.
- Keep magnetic objects away from the scale.
- Do not band the scale.



When storing the scale, the radius should not be smaller than 50 mm.



Before installation, check if the readhead has transport damages. Do not install damaged readhead.



Do not apply excessive force to the product.

Do not drop the product.

- Magnetic objects (e.g., screwdriver) cannot be in contact with the scale.



- Since the scale consists of magnetic substance, keep it away from strong magnetic materials and strong magnetic fields during usage and installation to prevent malfunction.
- Stay at least 5 cm away from the magnetic field strength of 5000 gauss to prevent the position measurement system from disruption.

1.5 Copyright

This user manual is protected by copyright. Any reproduction, publication in whole or in part, modification or abridgement requires the written approval of HIWIN MIKROSYSTEM.

Note:

HIWIN MIKROSYSTEM reserves the right to change the contents of this manual or product specifications without prior notice.

1.6 Manufacturer information

Table 1.6.1 Manufacturer's details

Corp.	HIWIN MIKROSYSTEM CORP.
Address	No.6, Jingke Central Rd., Taichung Precision Machinery Park, Taichung
Address	40852, Taiwan
Tel.	+886-4-23550110
Fax	+886-4-23550123
Sales E-mail	business@hiwinmikro.tw
Customer Service E-mail	service@hiwinmikro.tw
Website	http://www.hiwinmikro.tw

1.7 Product monitoring

Please inform HIWIN MIKROSYSTEM about the following contents:

- Accidental risk assessment.
- Potential source of danger involving person and property.
- Anything in this user manual which is difficult to understand.

HIWIN. MIKROSYSTEM

ME08UE01-2410

General information

PM Series Incremental Position Measurement System User Manual

(This page is intentionally left blank.)

2. Basic safety information

2.	Basic	safety in	nformation	2-1
	2.1	Ove	erview	2-2
	2.2	Bas	sic safety notices	2-2
	2.3	Rea	asonably foreseeable misuse	2-3
	2	2.3.1	Environment factors	2-3
	2	2.3.2	Personal factors	2-3
	2.4	Cor	nversions and modifications	2-3
	2.5	Res	sidual risks	2-4
	2.6	Per	rsonnel requirements	2-4
	2.7	Pro	otective equipment	2-5
	2	2.7.1	Personal protective equipment	2-5
	2.8	Lab	pels on PM series incremental position measurement system	2-5

Basic safety information

PM Series Incremental Position Measurement System User Manual

2.1 Overview

This chapter is for the safety of everyone who works with, assembles, installs, operates, maintains or disassembles position measurement system. Failure to comply with the following information could be dangerous!

Position measurement system is a magnetic distance measuring system for positioning tasks with linear movement within an automated system. It is mainly used in linear motors. Position measurement system may only be used as described for the intended purpose, and it must not be used outdoors or in hazardous areas where there is a risk of explosions.

MARNING

Danger due to strong magnetic fields!

2.2 Basic safety notices

- Stay vigilant for safety when using the product. Immediately report if there is an emergency.
- Users need to maintain a good mental state. Do not use the product without clear consciousness.
- Do not run or play in the workspace.
- It is necessary to understand chemical related to the product such as alcohol and lubricants. Mark them on the bottles to prevent accidental ingestion.
- Be sure to configure fire extinguishers and install automatic sprinklers in the operating environment to avoid fire that causes casualties and property loss.
- It is strictly forbidden to store flammable substances in the working area, smoking is prohibited in the place.

2.3 Reasonably foreseeable misuse

2.3.1 Environment factors

The product is in contact with magnetic objects.

WARNING

Danger of serious or fatal injuries!

- ♦ Before and during all assembly, disassembly or repair work, the position measurement system or the higher-level system must be de-energized and it must be ensured that the mains connection cannot be re-established by other persons!
- Position measurement system must not be used in potentially explosive atmospheres.
- Position measurement system may only be used and operated indoors.

2.3.2 Personal factors

- Operation performed by untrained or unauthorized personnel.
- Persons who have not fully read and understood this user manual.
- Not follow the instructions in this user manual intentionally or carelessly while using the product.
- Operate the product without clear consciousness or under the influence of drugs or alcohol.

2.4 Conversions and modifications

- Do not disassemble the product on your own without authorization. If there are any special requests, please contact HIWIN MIKROSYSTEM.
- Do not tear the product label.

2.5 Residual risks

If users operate the product with instructions in the user manual, risks can be effectively controlled and reduced. Please refer to the relevant chapters for risks and warnings of the management and operation.

If users still have doubts about the product after reading the manual, please contact the sales representatives of HIWIN MIKROSYSTEM, there will be professionals to assist you.

2.6 Personnel requirements

Users must read the product manual carefully, be authorized or have knowledge of the product, and must be familiar with safety equipment and regulations.

Untrained personnel can cause personal injury, serious damage to the machine or to the product.

- Configuration, adjustment, installation, and maintenance can only be performed by trained staff.
- These professionals must be able to identify the hazards that may be caused by mechanical, electrical, or electronic equipment.

Professionals are those who are familiar with the safety guidelines of electrical and automation technology when carrying out configuration tasks, who are able to adjust, ground, and label circuits and equipment/systems according to safety standards.

2.7 Protective equipment

2.7.1 Personal protective equipment

Table 2.7.1.1

Operation Phase	Personal Protective Equipment	Description
Transport,		Wear safety shoes to prevent the risk of the injury caused by the falling product.
maintenance and cleaning		Wear latex gloves when wiping the product with alcohol.

2.8 Labels on PM series incremental position measurement system

The label affixed on the product and package provides detailed information on product specification.



Figure 2.8.1 Shipping label of readhead




Figure 2.8.2 Shipping label of scale

Note:

- 1. Before using the product, check if the label matches the specification.
- 2. The contents on the shipping label will vary according to the selected specification.
- 3. The shipping label of scale will be directly printed on the scale.

HIWIN. MIKROSYSTEM

ME08UE01-2410

Basic safety information

PM Series Incremental Position Measurement System User Manual

(This page is intentionally left blank.)

3. Product description

3.	Pro	duct descr	iption	3-1
	3.1	PM	series incremental position measurement system description	3-2
	3.2	Ма	in components of PM series incremental position measurement system	3-3
		3.2.1	Technical specifications of scale (PS08 series)	3-3
		3.2.2	Technical specifications of readhead	3-4
		3.2.3	Specifications of signal	3-6
	3.3	Ord	der code	3-7
		3.3.1	Scale	3-7
		3.3.2	Readhead	3-8

3.1 PM series incremental position measurement system description

PM series incremental position measurement system mainly consists of readhead and scale. The readhead types are divided into T type, C type and PG type. T type is equipped with LEDs to assist installation, while C type and PG type can be combined with guideway to greatly save installation space. Scale belongs to PS08 series, with an accuracy level of 8 µm and a maximum length of 30 m. This system has the characteristics of high accuracy and high repeatability. Besides, it is oil-proof, dust-proof, waterproof, and quick and easy to assemble.

Table 3.1.1

	Product	Diagram
	T type readhead	
PM series	C type readhead	
	PG type readhead	

3.2 Main components of PM series incremental position measurement system

This product consists of readhead and scale. The information of technical specifications is as follows.




Figure 3.2.1

3.2.1 Technical specifications of scale (PS08 series)

System specification

Table 3.2.1.1

Feature	Technical Data	Additional Information
Pole pitch	2 mm	-
Accuracy	±8 μm/m	20°C
Maximum length of scale	30 m	-

Mechanical specification

Table 3.2.1.2

Feature	Technical Data	Additional Information
Scale width	10+0.2 mm	-
Scale thickness	1.72±0.1 mm	with cover strip
Weight	60 g/m	-

Product description

■ Environmental specification

Table 3.2.1.3

Feature	Technical Data	Additional Information
Operating temperature	-20°C~80°C	-
Storage temperature	-20°C~80°C	-
Relative humidity	0~100%	condensation allowed
Expansion coefficient	(11±1)×10 ⁻⁶ /K	-
International protection marking	IP67	

3.2.2 Technical specifications of readhead

System specification

Table 3.2.2.1

Feature	Technical Data	Additional Information			
Resolution	2 mm	Analog			
Resolution	1 μm	Digital			
Repeatability	±1 µm	unidirectional			
Reference point signal	1 pulse/pole pitch or independent reference point	-			
Maximum valacity (anacd)	15 m/s	Analog			
Maximum velocity (speed)	7 m/s	Digital			
Installation gap	0.5±0.3 mm	-			

■ Electrical specification

Table 3.2.2.2

Feature	Technical Data	Additional Information				
Power supply	5 V ±5%	DC voltage				
Current consumption	<50 mA	-				
Voltage drops	7.3 mV/m	-				
Output signal	SIN/COS 0.6~1.2 Vp-p	Analog				
Output signal	5 V TTL/RS422	Digital				
RoHS directive	Qualified	-				

■ Environmental specification

Table 3.2.2.3

Feature	Technical Data	Additional Information
Operating temperature	-25°C~80°C	-
Storage temperature	-25°C~80°C	-
Relative humidity	0~100%	condensation allowed
International protection marking	IP67	IEC60529
Vibration resistance	300 m/s² (50 Hz~2000 Hz)	IEC60068-2-6
Shock resistance	1000 m/s² (11 ms)	IEC60068-2-27
Maximum external magnetic field	±5 mT	-
ECM protection	EN61000-6-2	-
ECM protection	EN61000-6-4	-

■ Mechanical specification

Table 3.2.2.4

Feature	Technical Data	Additional Information
	45×12×14 mm	T type
	38×22×8.1 mm	C type
	H20: 43×39×24.4 mm	
Size	H25: 46.4×39×29.5 mm	
	H30: 58×39×35 mm	PG type
	H35: 68×39×39 mm	
	H45: 82×39×49 mm	
	32 g	T type
Weight	30 g	C type
	115 g	PG type

3.2.3 Specifications of signal

For PM series incremental position measurement system, there are two kinds of signal formats, analog signal and digital signal.

Analog signal




Figure 3.2.3.1

■ Digital signal




Figure 3.2.3.2

3.3 Order code

Select suitable PM series incremental position measurement system based on requirement.

3.3.1 Scale

Table 3.3.1.1 Model explanation of scale

Code	1	2	3	4	-	5	6	7	8	-	9	-	10	11	12
Example	Р	S	0	8	-	1	0	0	0	-	С	-	1	0	
1, 2: Scale	PS	PS													
3, 4: Accuracy	08: :	3: ±8 μm/m													
5, 6, 7, 8: Length	100: 100 mm 3000: 3000 mm (Max)														
9: Index (Optional)	S: N	one						С	: Inde	X					
10, 11, 12: Index position								1	0: 10 :	•		mer's	requi	ireme	nt

3.3.2 Readhead

■ T type, C type readhead

Table 3.3.2.1 Model explanation of T type, C type readhead

Code	1	2	-	3	4	-	5	6	-	7	8	-	9	-	10	11		
Example	Р	М	-	1	0	-	0	3	-	0	D	-	Т	-	1	0		
1, 2: Readhead	PM	PM																
3, 4: Resolution	00:	00: Pole pitch (Analog) 10: 1 μm (Digital)																
5, 6: Cable length	P5: 0.5 m 01: 1 m 02: 2 m 25: 25 m (Max)																	
7: Connector option	1: S 3: D 4: 1	0: Flying Lead 1: SCSI 20 Pin 3: D-sub 15 Pin 4: 17 Pin Circular Plug (M17) 6: D-sub VGA 15 Pin									0: Flying Lead 1: SCSI 20 Pin 3: D-sub 15 Pin 4: 17 Pin Circular Plug (M17) 6: D-sub VGA 15 Pin 7: D-sub 9 Pin 8: SCR 10 Pin							
8: Output signal	pitcl	A: Analog output and digital index/pole pitch*1 I: Analog output and one digital index*2								pitch*1								
9: Housing	T: T type (with LED) C: C type																	
10, 11: Reserved code	10: Standard																	

Note:

^{*1} With PS08-XXXX-S-00.

^{*2} With PS08-XXXX-C-XX.

■ PG type readhead

Table 3.3.2.2 Model explanation of PG type readhead

Code	1	2	-	3	4	-	5	6	-	7	8	-	9	-	10	11	-	12	13		
Example	Р	М	-	1	0	-	0	3	-	0	D	-	G	-	2	0	-	1	0		
1, 2: Readhead	РМ	PM																			
3, 4: Resolution	00:	00: Pole pitch (Analog) 10: 1 μm (Digital)																			
5, 6: Cable length	01: 02:	P5: 0.5 m 01: 1 m 02: 2 m 25: 25 m (Max)																			
7: Connector option	1: 5 3: [4: 1	0: Flying Lead 1: SCSI 20 Pin 3: D-sub 15 Pin 4: 17 Pin Circular Plug (M17) 6: D-sub VGA 15 Pin									0: Flying Lead 1: SCSI 20 Pin 3: D-sub 15 Pin 4: 17 Pin Circular Plug (M17) 6: D-sub VGA 15 Pin 7: D-sub 9 Pin 8: SCR 10 Pin										
8: Output signal	A: Analog output and digital index/pole pitch*1 I: Analog output and one digital index*2								þ	D: Digital output and digital index/pole pitch*1 E: Digital output and one digital index*2											
9: Housing	G:	PG t	уре																		
10, 11: Guideway system	25: 30: 35: 45:	H20 H25 H30 H35 H45																			
12, 13: Reserved code	10:	Star	ndar	d																	

Note:

^{*1} With PS08-XXXX-S-00.

^{*2} With PS08-XXXX-C-XX.

HIWIN. MIKROSYSTEM

ME08UE01-2410

Product description

PM Series Incremental Position Measurement System User Manual

(This page is intentionally left blank.)

4. Transport and setup

4.	Trar	nsport and	d setup	4-1					
	4.1	De	livery	4-2					
	4.2	Tra	ansport to the installation site	4-2					
	4.3	Re	Requirements at the installation site						
		4.3.1	Recommended accuracy for installation surface	4-3					
		4.3.2	Dimensions of PM series incremental position measurement system	4-4					
	4.4	Sto	orage	4-7					
	4.5	Un	packing and setup	4-8					

Transport and setup

PM Series Incremental Position Measurement System User Manual

4.1 Delivery

Transport the product in the original unopened packaging.

4.2 Transport to the installation site

Keep the product away from strong magnetic materials and strong magnetic fields, or the scale and the accuracy will be affected.

ACAUTION

- Do not apply excessive force to the product.
- ◆ Do not drop the product.
- ◆ Magnetic objects (e.g., screwdriver) cannot be in contact with the scale.

4.3 Requirements at the installation site

This section explains the installation interface and dimension definitions of PM series incremental position measurement system.

△CAUTION

• Before installation, check if the readhead has transport damages. Do not install damaged readhead.

4.3.1 Recommended accuracy for installation surface

The sectional view of the base of the installation platform and the recommended tolerances are shown as follows.




Figure 4.3.1.1

4.3.2 Dimensions of PM series incremental position measurement system

■ T type readhead




Figure 4.3.2.1

■ C type readhead






Figure 4.3.2.2



*1: HIWIN provide drawings for encoder housing. For details, please contact HIWIN.


Figure 4.3.2.3

PG type readhead




 $\ensuremath{\mathrm{\%}}$ Note:These dimensions are suitable for HIWIN PGH20 linear guideway.

Figure 4.3.2.4



**Note:These dimensions are suitable for HIWIN PGH25 linear guideway.

Figure 4.3.2.5




Note: About dimension for PG type of 30/35/45/55, for details, please contact HIWIN.

Figure 4.3.2.6


4.4 Storage

Store and keep the readhead and the scale with caution. Please note the following:


- Store the readhead in the original unopened packaging.
- Prevent the readhead from physically harmful influences, including dust, heat, and humidity.
- Do not damage the connection via mechanical or thermal shock.



Operating temperature -25°C~80°C



Storage temperature -25°C~80°C



Waterproof

	△CAUTION				
8	◆ Do not scratch the scale with sharp objects.				
	Keep magnetic objects away from the scale.				
0	◆ Do not band the scale.				
	♦ When storing the scale, the radius should not be smaller than 50 mm.				
	Hydrochloric acid, Alcohol, Seawater, Antifreeze, Brake oil, Engine oil				
	Carbon tetrachloride, Heptane, Vapor, Turpentine, Trichloroethylene, Kerosene, Toluene				
X	◆ Do not directly touch the connector, or the generated static electricity may affect the function.				
CONF.	◆ Do not plug or unplug the connector when the power is on.				

4.5 Unpacking and setup

Keep away from magnetic objects when unpacking the product. The unpack procedure of the product is as follows:

- Step1. Ensure the quantity and the specification on the label are correct.
- Step2. Carefully unpack the carton and keep the product away from magnetic objects.
- Step3. Preserve the carton after unpacking, send it back if there are any problems. If there are no questions, deal with the packaging environmentally friendly.
- Step4. Wear an electrostatic wristband first. Carefully take out the product and inspect if the product inside is correct without any damage on the surface. Users can take a photo to record. During the process, avoid the direct contact with the adapters or bare wires.
- Step5. Carefully transport the product and avoid heavy drops and dents.

5. Assembly and connection

5.	Ass	embly and	d connection	5-1
	5.1	Ме	echanical installation	5-2
		5.1.1	Scale installation	5-3
		5.1.2	Readhead installation	5-5
	5.2	Ele	ectrical installation	5-6
		5.2.1	Port types of readhead	5-7
		5.2.2	Configuration of signal receiver	5-11

5.1 Mechanical installation

This section explains the installation of incremental position measurement system. Refer to chapter 4 for the installation dimensions and specifications.

MARNING

Danger due to electrical voltage!

Dangerous currents may flow before and during assembly, disassembly and repair work.

- ◆ Before and during all assembly, disassembly or repair work, the position measurement system or the higher-level system must be de-energized and it must be ensured that the mains connection cannot be re-established by other persons!
- ◆ Observe the assembly instructions of the other system components (e.g., linear motor, servo drive)!

ACAUTION

Possible damage to position measurement system!

Scale must not be exposed to strong magnetic fields. Magnetic dust can falsify the measuring signal or damage the position measurement system.

- Keep the distance between the position measurement systems and the permanent magnets of linear motor axes!
- ◆ Be cautious when using dial gauge holders (e.g., to align the profile rails)!
- Avoid strong shocks (e.g., use of a hammer)!
- ◆ Do not use the system in environments with magnetic dust (e.g., graphite dust)!

ACAUTION

Possible damage to position measurement system!

Magnetic chips or other foreign objects may stick to the scale. This can destroy the mechanics of the readhead.

Check the gap between the scanning unit and the scale regularly and keep it free!

5.1.1 Scale installation

ACAUTION

- When installing the scale, ensure there is no strong magnetic field or magnetic objects around it to prevent degaussing.
- ◆ Stay at least 5 cm away from the magnetic field strength of 5000 gauss to prevent the position measurement system from disruption.

To prevent the scale from skew, use the installation fixture and follow the steps below for installation.

Step 1: Clean the installation surface.




Figure 5.1.1.1

Step 2: Tear off the double-sided tape of the scale.




Figure 5.1.1.2

Step 3: Use the installation fixture to paste the scale on the installation surface.




Figure 5.1.1.3

Note:

The installation fixture here is for demonstration only. Different readhead has its corresponding installation fixture. Refer to section 11.4 for details.

Step 4: Clean the surface of the scale.




Figure 5.1.1.4

Step 5: Tear off the double-sided tape of the cover strip.




Figure 5.1.1.5

Step 6: Paste the cover strip on the scale.




Figure 5.1.1.6

5.1.2 Readhead installation

Standard installation gap: 0.5±0.3 mm

Specifications of offset angle: Refer to chapter 4.

All readheads must follow the signal outlet specifications:

Do not bend the signal cable when the outlet is smaller than 30 mm, and the minimum bending radius is 40 mm. The static limit radius of the signal cable is 25 mm.




Figure 5.1.2.1 Specifications of outlet and bending radius for readhead

Note:

Here takes T type readhead as the demonstration. The signal outlet specifications of all readheads are the same.

5.2 Electrical installation

This section explains the wiring method and the pin definition of connectors.

MARNING

Since the readhead is sensitive to static electricity, please be careful. Without proper ESD protection, do not touch the cables or the pins of connectors.



- Do not perform wiring work or disconnect electrical connections when power on.
- Perform wiring work in power off state only.
- Check all the cables and plug connections before switching on the device.

AWARNING

Danger due to electrical voltage!

Dangerous currents may flow before and during assembly, disassembly and repair work.

- ◆ Ensure the system (e.g., linear motor axis) is properly earthed via the PE rail in the switch cabinet before connecting the electrical power supply!
- ♦ Electrical currents can also flow when the motor is not moving. Never disconnect electrical connections while they are live. In unfavorable cases, electric arcs can occur and injure persons and damage contacts!
- ◆ Observe the assembly instructions of the other system components (e.g., linear motor, servo drive)!

5.2.1 Port types of readhead

All the port types provided below can be used with PM series.

Refer to the model description in section 3.3.

All the specifications can use flying lead. The diagram and the pin definition are as follows.



Figure 5.2.1.1 Flying lead

Table 5.2.1.1

Function	Signal		Wire Color	Elving Lood	
Function	Analog	Digital	Wife Color	Flying Lead	
Power supply	5 V	DC	Brown	Brown	
Power supply	GI	ND	White	White	
	SIN+	A+	Green	Green	
Outroot simus!	SIN-	A-	Yellow	Yellow	
Output signal	COS+	B+	Blue	Blue	
	COS-	B-	Red	Red	
Reference point	REF+	Z+	Violet	Violet	
signal	REF-	Z-	Gray	Gray	
Shield	Shielding		Shielding	Shielding	

■ SCSI 20 Pin



Figure 5.2.1.2 SCSI 20 Pin

Table 5.2.1.2

Function	Signal		Wire Color	Connector [Male] (SCSI 20 Pin)	
	Analog Digita			Analog	Digital
Dower ounnly	5 V DC GND		Brown	3	3
Power supply			White	2	2

Function	Signal		Wire Color	Connector [Male] (SCSI 20 Pin)	
	Analog	Digital		Analog	Digital
	SIN+	A+	Green	16	4
Output signal	SIN-	A-	Yellow	17	5
	COS+	B+	Blue	18	6
	COS-	B-	Red	19	7
Reference point signal	REF+	Z+	Violet	8	8
	REF-	Z-	Gray	9	9
Shield	Shielding		Shielding	Case / I	Housing

■ D-sub 15 Pin



Figure 5.2.1.3 D-sub 15 Pin

Table 5.2.1.3

Function	Signal		Wire Color	Connector [Male] (D-sub 15 Pin)	
	Analog	Digital		Analog	Digital
Dower gupply	5 V	DC	Brown	4	7
Power supply	GN	ND	White	12	2
	SIN+	A+	Green	9	14
Output signal	SIN-	A-	Yellow	1	6
Output signal	COS+	B+	Blue	10	13
	COS-	B-	Red	2	5
Reference point signal	REF+	Z+	Violet	3	12
	REF-	Z-	Gray	11	4
Shield	Shielding		Shielding	Case / I	Housing

■ D-sub VGA 15 Pin



Figure 5.2.1.4 D-sub VGA 15 Pin

Table 5.2.1.4

Function	Signal		Wire Color	Connector [Male] (D-sub VGA 15 Pin)	
	Analog	Digital		Analog	Digital
Dower ounnly	5 V	DC	Brown	1	1
Power supply	GN	ND	White	2	2
	SIN+	A+	Green	11	3
Output signal	SIN-	A-	Yellow	12	9
Output signal	COS+	B+	Blue	13	4
	COS-	B-	Red	14	10
Reference point signal	REF+	Z+	Violet	7	7
	REF-	Z-	Gray	8	8
Shield	Shielding		Shielding	Case / I	Housing

■ D-sub 9 Pin



Figure 5.2.1.5 D-sub 9 Pin [Female]

Table 5.2.1.5

Function	Signal		Signal	Connector [Male] (D-sub 9 Pin)
	Analog	Digital	ÿ	Digital
Dower ounnly	5 V	DC	Brown	2
Power supply	GN	ND	White	1
	SIN+	A+	Green	3
Output signal	SIN-	A-	Yellow	8
Output signal	COS+	B+	Blue	4
	COS-	B-	Red	7
Reference point	REF+	Z+	Violet	5
signal	REF-	Z-	Gray	9
Shield	Shielding		Shielding	Case / Housing

■ SCR 10 Pin




Figure 5.2.1.6 SCR 10 Pin

Table 5.2.1.6

Function	Signal		Signal	Connector [Male] (SCR 10 Pin)
	Analog	Digital	ÿ	Digital
Dower ounnly	5 V	DC	Brown	1
Power supply	GN	ND	White	2
	SIN+	A+	Green	5
Output signal	SIN-	A-	Yellow	6
Output signal	COS+	B+	Blue	7
	COS-	B-	Red	8
Reference point signal	REF+	Z+	Violet	9
	REF-	Z-	Gray	10
Shield	Shielding		Shielding	Case / Housing

■ 17-Pin Circular Plug



Figure 5.2.1.7 17-Pin Circular Plug

Table 5.2.1.7

Function	Signal		Signal	Connector [Male]
1 diletion	Analog	Digital	Signal	(17-Pin Circular Plug)
Dower aunnly	5 V DC		Brown	4/5
Power supply	GND		White	12 / 13
Output signal	SIN+	A+	Green	9
	SIN-	A-	Yellow	1
	COS+	B+	Blue	10
	COS-	B-	Red	2

Function	Signal		Signal	Connector [Male]	
Function	Analog	Digital	Signal	(17-Pin Circular Plug)	
Reference point	REF+	Z+	Violet	3	
signal	REF-	Z-	Gray	11	
Shield	Shielding		Shielding	Case / Housing	

5.2.2 Configuration of signal receiver

For readhead, there are two kinds of signal outputs, analog signal and digital signal. The configurations of signal receiver are shown in the following figure.




Figure 5.2.2.1

Table 5.2.2.1

Signal	Description
SIN+ / COS+	Analog signal, sender, + output
SIN- / COS-	Analog signal, sender, - output
A, B, Z	Digital signal, sender, + output
$\overline{A}, \overline{B}, \overline{Z}$	Digital signal, sender, - output

HIWIN. MIKROSYSTEM

ME08UE01-2410

Assembly and connection

PM Series Incremental Position Measurement System User Manual

(This page is intentionally left blank.)

6. Commissioning

6.	Commission	oning	. 6-1
	6.1	Commissioning	. 6-2

Commissioning

6.1 Commissioning

After proper installation and wiring, users can make the incremental position measurement system operate normally by switching on the operating voltage. Besides, observe the assembly instructions of the other system components (e.g., linear motor, servo drive)!

The following sequence must be observed when commissioning position measurement system:

- Connect readhead.
- Apply supply voltage.
- Do not exceed the operating voltage, otherwise the readhead may be destroyed!
- Check output signal (e.g., with an oscilloscope).

7. Maintenance and cleaning

7. I 7	Maintena	Maintenance and cleaning				
	7.1	Maintenance	. 7-2			
	7.2	Cleaning	. 7-2			

7.1 Maintenance

Position measurement system works without making contact and thus in principle maintenance-free. However, it must be regularly checked for dirt and, if necessary, cleaned with a suitable cleaning agent (e.g., alcohol). Dirt particles between the readhead and the scale can destroy position measurement system.

MARNING

Danger due to electrical voltage!

Dangerous currents may flow before and during assembly, disassembly and repair work.

- ◆ Ensure the system (e.g., linear motor axis) is properly earthed via the PE rail in the switch cabinet before connecting the electrical power supply!
- ♦ Electrical currents can also flow when the motor is not moving. Never disconnect electrical connections while they are live. In unfavorable cases, electric arcs can occur and injure persons and damage contacts!
- Observe the assembly instructions of the other system components (e.g., linear motor, servo drive)!

7.2 Cleaning

If the surface of the scale is dirty, gently wipe it with a soft cloth to avoid excessive cleaning of the scale. Besides, regularly check the gap.

△CAUTION

- Obstacle removal and maintenance can only be performed by HIWIN MIKROSYSTEM technicians or authorized dealers, and with appropriate protective equipment.
- ◆ Do not perform any maintenance actions while the motor is running. The controller must stop the motor first
- ◆ Turn off the power and the main switch of the machine (refer to the machine manufacturer's instructions for operation).

8. Disposal

8.	Disposal.			
	8.1	Was	te disposal	8-2
	8.1.	1	Readhead	8-2

PM Series Incremental Position Measurement System User Manual

Disposal

8.1 Waste disposal

8.1.1 Readhead

The electronic components of readhead contain materials which are environmentally harmful but also recyclable. Therefore, when the readhead has reached end-of-life or is out of service, please recycle it according to the environmental protection guidelines of the country/region. Do not discard it at will.

9. Troubleshooting

9.	Troubles	Troubleshooting9			
	9.1	Troubleshooting	9-2		
	9.1	1 Readhead	Q_2		

9.1 Troubleshooting

9.1.1 Readhead

When the readhead cannot normally operate or is incorrectly installed, check the following items for troubleshooting based on the used readhead.

■ T type readhead

Table 9.1.1.1

Light	Troubleshooting
Green light	Normal operation. There is no need to do troubleshooting.
Red light	Check if the installation gap between readhead and scale meets the specification.
No light	Check if the readhead connects to the power supply.

■ C type, PG type readhead

- 1. Check if the readhead connects to the power supply.
- 2. Check if the readhead is correctly connected to the servo drive.
- 3. Check if the installation gap between readhead and scale meets the specification.
- 4. Ensure the offset angle of readhead does not exceed the specification. Refer to section 5.1.2.
- 5. Use magnetic analysis card to check if the magnetic poles of scale have been demagnetized, making the readhead fail to sense the position.

If the problem is still not solved, please contact the customer service of HIWIN MIKROSYSTEM or send the readhead back to the factory for repairs through the dealers.

10. Declaration of incorporation

10.		Declaration of incorporation	10-1
	10.1	Declaration of incorporation	10-2

10.1 Declaration of incorporation

HIWIN. MIKROSYSTEM

大銀微系統股份有限公司 台灣40852台中市精密機械園區 精科中路6號

Tel: +886-4-23550110 Fax: +886-4-23550123

HIWIN MIKROSYSTEM CORP.

No.6, Jingke Central Rd., Precision Machinery Park, Taichung 40852, Taiwan www.hiwinmikro.tw business@hiwinmikro.tw

Declaration of Conformity

according to EMC directive 2014/30/EU

Name and address of the manufacturer:

HIWIN MIKROSYSTEM CORP., No.6, Jingke Central Rd., Taichung Precision Machinery Park, Taichung 408226, Taiwan

Description and identification of the product:

Product

Position Measurement Systems

Identification

Series: PM

The object of the declaration described above is in conformity with the relevant Union harmonization legislation Directives.

2011/65/EU RoHS directive

References to the relevant harmonized standards used or references to the other technical specifications in relation to which conformity is declared

EN 61000-6-2:2005	Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial
EN 61000-6-2:2005/AC:2005	environments
EN 61000-6-4:2007	Electromagnetic compatibility (EMC) - Part 6-4: Generic standards - Emission standard for
EN 61000-6-4:2007/A1:2011	industrial environments

This declaration of conformity is issued under the sole responsibility of the manufacturer.

Taichung 408226, Taiwan

10.08.2024

Szu, Kou-I, General manager

(Place, Date)

(Surname, first name, and function of signatory)

(Signature

11. Appendix

11.		Appendi	x	11-1
	11.1	Glo	ossary	11-2
	11.2	Un	it conversion	11-3
	11.3	Tol	erances and hypotheses	11-5
		11.3.1	Dimensional tolerances	11-5
		11.3.2	Geometric tolerances	11-5
	11.4	Op	tional accessories	11-6

11.1 Glossary

Incremental

Incremental position measurement cannot report the absolute position when the power is on. It must read the reference home position first before calculating the position. Incremental position signal can count in both directions to increase or decrease relative position information.

Accuracy

It is the closeness of the actual value to the measured position.

Resolution

It is the minimum measurement of step output for incremental position measurement system. This is the shortest distance of which the position measurement moves for the output to change by one count.

■ Repeatability

It is the ability to report the same position each time when the position measurement reaches a specific point on the axis. Sometimes it is also called reproducibility, scatter, or precision.

Hysteresis

It is the time delay in response to a change via input.

■ International Protection Marking

Also known as Ingress Protection Rating or IP code, it is defined in the international standard IEC60529. This defines the tightness of the electrical enclosure.

International Protection Marking has two numbers: the first number represents the dustproof level (0~6), and the second number represents the waterproof level (0~9). For example, IP68 means that the dustproof level is 6, and the waterproof level is 8.

■ Terminal resistor

The terminal resistor is a resistor connected in parallel to a pair of communication cables at both ends of the line network, which can absorb the reflected waves on the network and effectively increase the signal strength. It is used to shield signal reflections, stabilize and adjust signals. The terminal matching resistance value is related to the impedance characteristics of the cable, and it has nothing to do with the cable length. The terminal resistance is generally between 100~140 ohm, and the typical value is 120 ohm.

11.2 Unit conversion

To convert the unit in column B to the unit in column A, multiply by the corresponding figure in the table.

Mass

			E	3	
		g	kg	lb	oz
	g	1	0.001	0.0022	0.03527
_	kg	1000	1	2.205	35.273
A	lb	453.59	0.45359	1	16
	oz	28.35	0.02835	0.0625	1

Linear velocity

		В					
		m/s	cm/s	mm/s	ft/s	in/s	
	m/s	1	100	1000	3.281	39.37	
	cm/s	0.01	1	10	3.281 x 10 ⁻²	0.3937	
Α	mm/s	0.001	0.1	1	3.281 x 10 ⁻³	3.937 x 10 ⁻²	
	ft/s	0.3048	30.48	304.8	1	12	
	in/s	0.0254	2.54	25.4	8.333 x 10 ⁻²	1	

■ Force

			В	
		N	lb	oz
	N	1	0.2248	3.5969
Α	lb	4.4482	1	16
	oz	0.2780	0.0625	1

Appendix

■ Length

	В						
		m	cm	mm	μm	ft	in
	m	1	100	1000	1000000	3.281	39.37
	cm	0.01	1	10	10000	3.281 x 10 ⁻²	0.3937
_	mm	0.001	0.1	1	1000	3.281 x 10 ⁻³	3.937 x 10 ⁻²
Α	μm	1 x 10 ⁻⁶	1 x 10 ⁻⁴	0.001	1	3.281 x 10 ⁻⁶	3.937 x 10 ⁻⁵
	ft	0.3048	30.48	304.8	304800	1	12
	in	0.0254	2.54	25.4	25400	8.333 x 10 ⁻²	1

■ Temperature

		В							
		°C	°F						
^	°C	1	(°F - 32) x 5 / 9						
Α	°F	(°C x 9 / 5) + 32	1						

Magnetic field

		В								
		Т	mT	G						
	Т	1	1000	10000						
Α	mT	1 x 10 ⁻³	1	10						
	G	1 x 10 ⁻⁴	0.1	1						

■ Voltage

В							
		V	mV				
^	V	1	1000				
Α	mV	0.001	1				

■ Current

		В							
		A mA							
^	А	1	1000						
Α	mA	0.001	1						

11.3 Tolerances and hypotheses

11.3.1 Dimensional tolerances

The dimensional tolerances for the product drawing are shown in the following table.

Table 11.3.1.1 Dimensional tolerances table (Unit: mm)

<6	6~30	30~120	120~300	300~600	600~1200	1200~2400	>2400	
±0.1	±0.2	±0.3	±0.4	±0.5	±0.8	±1.0	±1.5	

11.3.2 Geometric tolerances

The geometric tolerances are excerpted from JIS B 0021 (1998), as the following table shows.

Table 11.3.2.1 Geometric tolerances table

Type of Tolerance		Symbol	Definition
Form	Straightness tolerance	_	It refers to the range value of the line body that deviates from the geometric line.
tolerance	Flatness tolerance		It refers to the range value of the plane body that deviates from the geometric plane.
Orientation tolerance	Parallelism tolerance	//	It refers to the range value of a geometric line or geometric plane that should remain perpendicular and deviate from a geometric line or geometric plane, which is perpendicular to the datum line or datum plane.
	Perpendicularity tolerance		It refers to the range value of a line or plane that should have a theoretically correct angle, a geometric line or geometric plane that deviates from a theoretically correct angle relative to a reference line or plane.

11.4 Optional accessories

This product can be equipped with the accessories based on requirement.

Signal transfer cable

Various signal transfer cables are provided, which can be used with other brands of counters. Product model:

Table 11.4.1

Code	1	2	3	-	4	5	-	6	7	-	8	-	9
Example	S	Т	С	-	Р	5	-	3	3	-	Α	-	0
1, 2, 3: Signal transfer cable	STC:	STC: Signal Transfer Cable											
4, 5: Cable length	P5: 0.5 m :: 01: 1 m :: 10: 10 m (Max)												
6: Left side connector type (female) (with copper pillar)	0: Flying Lead 3: D-sub 15 Pin 4:17 Pin Circular Plug (M17) 6: D-sub VGA 15 Pin						3: 4: 6:	0: Flying Lead 3: D-sub 15 Pin 4: 17 Pin Circular Plug (M17) 6: D-sub VGA 15 Pin 7: D-sub 9 Pin					
7: Right side connector type (male)	0: Flying Lead 1: SCSI 20 Pin 3: D-sub 15 Pin 4: 17 Pin Circular Plug (M17) 6: D-sub VGA 15 Pin						1: 3: 4: 6: 7:	0: Flying Lead 1: SCSI 20 Pin 3: D-sub 15 Pin 4: 17 Pin Circular Plug (M17) 6: D-sub VGA 15 Pin 7: D-sub 9 Pin 8: SCR 10 Pin (Female)					
8: Signal format	A: Analog					D	D: Digital						
9: Reserved code	0: Standard 1: With metal tube												



Figure 11.4.1 Signal transfer cable

■ Installation fixture

This facilitates the installation and ensures the parallelism of scale's installation. Product model:




Figure 11.4.2 Installation fixture

■ End clamp

This ensures that the scale can be used in harsh environments.

Product model: PSF-01




Figure 11.4.3 End clamp

■ Magnetic analysis card

With this, the incremental track and absolute track of scale can be easily determined.

Product model: MVF-03



Figure 11.4.4 Magnetic analysis card