# **HIWIN**<sub>®</sub> MIKROSYSTEM



# Standard Dual-Axis Linear Motor Stage SSA

**User Manual** 

# **Related Documents**

The figure and table of the documents related to the product are shown below. Refer to these documents as required.



Product			Doc. Name	Doc. No.	Content
		НІМС	Installation Guide	MH07UE01-000	Provides detailed information on installing and connecting HIMC motion controller.
		НІМС	iA Studio User Guide	MH01UE01-0000	Provides detailed information on the human machine interface operation of HIMC motion controller.
	HIMC	НІМС	Modbus TCP User Guide	MH02UE01-000	Provides detailed information on the way Modbus TCP communication protocol applied to HIMC motion controller.
Controller	Motion Controller	НІМС	HMPL User Guide	MH06UE01-000	Provides detailed information on HMPL library of HIMC motion controller.
		НІМС	API Reference Guide	MH05UE01-000	Provides detailed information on API library of HIMC motion controller.
		HIOM	Installation Guide	MH03UE01-0000	Provides detailed information on installing and connecting HIOM (HIWIN mega-ulink IO module).
		ETA3	Installation Guide	MH09UE01-000	Provides detailed information on installing and connecting ETA3 (HIMC remote module).
			E1 Series Servo Drive User Manual	MD09UE01	Provides detailed information on selecting, installing, connecting, setting, performing test run for, tuning, and monitoring E1 series servo drive.
			E2 Series Servo Drive User Manual	MD28UE01	Provides detailed information on selecting, installing, connecting, setting, performing test run for, tuning, and monitoring E2 series servo drive.
			E Series Servo Drive Thunder Software Operation Manual	MD12UE01-000	Provides detailed information on the human machine interface operation of E series servo drive.
	E Series Servo Drive		E Series Servo Drive Gantry Control System User Manual	MD22UE01-0000	Provides detailed information on the usage of E series servo drive gantry control system.
			E Series Servo Drive Electronic Cam Control System User Manual	MD27UE01-000	Provides detailed information on the usage of E series servo drive electronic cam control system.
			E Series Servo Drive Multi- Motion Function User Manual	MD32UE01-0000	Provides detailed information on the usage of E series servo drive multimotion function.
Servo Drive			MPI Library Reference Manual	MD19UE01-000	Provides detailed information on MPI library of E series servo drive and D series servo drive.
			MPI Examples	MD18UE01-0000	Provides detailed information on MPI examples of E series servo drive and D series servo drive.
			API Library Reference Manual for Servo Drives	MD23UE01-0000	Provides detailed information on API library of E series servo drive and D series servo drive.
			PDL Examples for E Series Servo Drive	MD25UE01-000	Provides detailed information on PDL examples of E series servo drive.
		Comm	E Series Servo Drive EtherCAT(CoE) Communications Command Manual	MD08UE01-000	Provides detailed information on the way EtherCAT communication protocol applied to E series servo drive.
	Communication Manuals	E1 Series Servo Drive MECHATROLINK-III Communication Command Manual	MD24UE01-0000	Provides detailed information on the way MECHATROLINK-III communication protocol applied to E1 series servo drive.	
		nuals	E1 Series Servo Drive PROFINET Communication Command Manual	MD02UE01-000	Provides detailed information on the way PROFINET communication protocol applied to E1 series servo drive.

Product			Doc. Name	Doc. No.	Content	
			E2 Series Servo Drive Replacement Guide	MD34UE01-0000	Provides detailed information on the way of replacing E1 series servo drive and D1 series servo drive with E2 series servo drive.	
		P	Application Note E1 PROFINET Drive Complete Setup with Siemens TIA Portal	MD30UE01-0000	Provides detailed information on the operation of PLC software TIA Portal when E1 PROFINET drive is used with Siemens S7 series PLC.	
		Application Manuals	Application Note E1 MECHATROLINK-III Drive Complete Setup with YASKAWA MPE720	MD31UE01-0000	Provides detailed information on the operation of machine controller software MPE720 when E1 MECHATROLINK-III drive is used with YASKAWA MP3000 series machine controller.	
		uals	Function Blocks Application Manual E Series EtherCAT Drive with OMRON Sysmac Studio	MD35UE01-0000	Provides detailed information on the usage of application function blocks when E series EtherCAT drive is used with OMRON Sysmac Studio.	
			Function Blocks Application Manual E Series EtherCAT Drive with KEYENCE KV STUDIO	MD36UE01-0000	Provides detailed information on the usage of application function blocks when E series EtherCAT drive is used with KEYENCE KV STUDIO.	
		D1 Se	ervo Drive User Manual	MD20UE01	Provides detailed information on selecting, installing, connecting, setting, performing test run for, tuning, and monitoring D1 servo drive.	
		D2 Se	D2 Series Servo Drive User Manual		MD07UE01	Provides detailed information on selecting, installing, connecting, setting, performing test run for, tuning, and monitoring D2T servo drive.
Servo Drive	D Series Servo Drive	D2T-LM Series Servo Drive User Manual		MD11UE01-0000	Provides detailed information on selecting, installing, connecting, setting, performing test run for, tuning, and monitoring D2T-LM servo drive.	
Servo Drive		MPI Library Reference Manual		MD19UE01-0000	Provides detailed information on MPI library of E series servo drive and D series servo drive.	
		MPI Examples		MD18UE01-0000	Provides detailed information on MPI examples of E series servo drive and D series servo drive.	
			brary Reference Manual for Drives	MD23UE01-000	Provides detailed information on API library of E series servo drive and D series servo drive.	
		PDL Examples for D-series Drives User Manual		MD13UE01-000	Provides detailed information on PDL examples of D series servo drive.	
	Linear Motor	Linea	Motor User Manual	MP99UE01-000	Provides detailed information on selecting, installing, and connecting linear motor.	
		DMN Series Direct Drive Motor User Manual		MR01UE01-0000	Provides detailed information on selecting, installing, and connecting DMN series direct drive motor.	
Motor		DMT Series Direct Drive Motor User Manual		MR03UE01-0000	Provides detailed information on selecting, installing, and connecting DMT series direct drive motor.	
IVIOLOI	Direct Drive Motor	DMY :	Series Direct Drive Motor User al	MR04UE01-0000	Provides detailed information on selecting, installing, and connecting DMY series direct drive motor.	
		DMS Series Direct Drive Motor User Manual		MR05UE01-0000	Provides detailed information on selecting, installing, and connecting DMS series direct drive motor.	
		DMR Manu	Series Direct Drive Motor User al	MR06UE01-0000	Provides detailed information on selecting, installing, and connecting DMR series direct drive motor.	

Product		Doc. Name	Doc. No.	Content
	Torque Motor	Torque Motor User Manual	MW99UE01-0000	Provides detailed information on selecting, installing, and connecting torque motor.
	AC Servo Motor	AC Servo Motor User Manual	MC03UE01-000	Provides detailed information on selecting, installing, and connecting AC servo motor.
	IM-1 Series Spindle Motor	IM-1 Series Spindle Motor User Manual	MS01UE01-000	Provides detailed information on selecting and installing IM-1 series spindle motor.
Linear Motor	Standard Single-Axis Linear Motor Stage	Standard Single-Axis Linear Motor Stage User Manual	MM06UE01-0000	Provides detailed information on selecting, installing, and connecting standard single-axis linear motor stage.
Stage	Standard Dual-Axis Linear Motor Stage	Standard Dual-Axis Linear Motor Stage User Manual	MM18UE01-0000	Provides detailed information on selecting, installing, and connecting standard dual-axis linear motor stage.
Actuator	Linear Actuator	Linear Actuator User Manual	MA99UE01-000	Provides detailed information on selecting, installing, and connecting linear actuator.

(This page is intentionally left blank.)

# **Table of Contents**

1.	Genera	al information	1-1	
	1.1	Revision history	1-2	
	1.2	About this manual	1-3	
	1.3	General precautions	1-3	
	1.4	Safety instruction	1-4	
	1.5	Copyright	1-10	
	1.6	Manufacturer information	1-10	
	1.7	Product monitoring	1-10	
2.	Basic	safety information	2-1	
	2.1	Overview	2-2	
	2.2	Basic safety notices	2-2	
	2.3	Reasonably foreseeable misuse	2-2	
	2.4	Conversions and modifications	2-3	
	2.5	Residual risks	2-3	
	2.6	Personnel requirements	2-3	
	2.7	Protective equipment	2-4	
	2	Personal protective equipment	2-4	
	2	Protective equipment on the LMSSA2X	2-5	
	2.8	Labels on LMSSA2X	2-5	
3.	Product description			
	3.1	LMX2S description	3-2	
	3.2	Main components of LMSSA2X	3-3	
	3.3	Order code	3-4	
	3.4	Linear motors	3-5	
	3.5	Positioning measurement system	3-6	
	3.6	Limit switches (Standard)	3-7	
	3.7 Cable chain (Standard)		3-8	
	3.8 Orthogonality		3-9	
4.	Transp	port and setup	4-1	
	4.1	Delivery	4-2	
	4.2	Transport to the installation site	4-2	
	4.3 Requirements at the installation site		4-4	
	4	.3.1 Ambient conditions	4-4	
	4	Safety equipment to be provided by the operator	4-5	
	4.4	Storage	4-5	
	4.5 Unpacking and setup			
5.	Assem	Assembly and connection		


	5.1	Me	echanical installation	5-2
		5.1.1	Mechanical mounting	5-2
		5.1.2	Assembling LMSSA2X	5-3
		5.1.3	Assembling the moved load	5-4
	5.2	Ele	ectrical installation	5-5
		5.2.1	Power supply and controller selection	5-8
		5.2.2	Connecting iron-core/ironless motors	5-11
		5.2.3	Connecting the linear positioning measurement system	5-11
		5.2.4	Connecting the limit switch	5-13
6.	Com	missionin	ng	6-1
	6.1	Sw	vitch on LMSSA2X	6-2
	6.2	Pro	ogramming	6-4
7.	Main	itenance a	and cleaning	7-1
	7.1	Ма	aintenance	7-2
		7.1.1	Linear motor	7-6
		7.1.2	Positioning measurement system	7-6
		7.1.3	Electromechanical components	7-6
		7.1.4	Linear guideways	7-7
		7.1.5	Cleaning	7-12
		7.1.6	Test run	7-12
8.	Disp	osal		8-1
	8.1	Wa	aste disposal	8-2
9.	Trou	bleshooti	ng	9-1
	9.1	Tro	publeshooting	9-2
10.	Decl	aration of	f Incorporation	10-1
11.	Appe	endix		11-1
	11.1	Glo	ossary	11-2
	11.2	Un	it conversion	11-5
	11.3	Tol	lerances and hypotheses	11-6
		11.3.1	Tolerances	11-6
		11.3.2	Hypotheses	11-6
	11.4	Su	pplementary formula	11-7
		11.4.1	Start Motor Sizing	11-7
		11.4.2	Linear Motor Sizing Example	11-13
		11.4.3	Sizing a Regen Resistor	11-14
	11.5	Ор	otional accessories	11-20
	11 6	Cu	istomer request form	11-21

# 1. General information

1.	General	information	1-1
	1.1	Revision history	1-2
	1.2	About this manual	1-3
	1.3	General precautions	1-3
	1.4	Safety instruction	1-4
	1.5	Copyright	1-10
	1.6	Manufacturer information	1-10
	1.7	Product monitoring	1-10

# 1.1 Revision history

The version of the manual is also indicated on the bottom of the front cover.



Release Date	Version	Applicable Product	Revision Contents
Oct. 20 <sup>th</sup> , 2023	1.0	Standard Dual-Axis Linear Motor Stage	First edition.
Apr. 23 <sup>th</sup> , 2024	1.1	Standard Dual-Axis Linear Motor Stage	<ol> <li>Vbus Updates. (Table 5.2.1.2)</li> <li>V type is changed to E type and D type is added. (Table 5.2.3.2) (Table 3.7.1) (Table 3.7.2) (Table 3.5.1)</li> </ol>

#### 1.2 About this manual

This manual is to help users operate the Standard Dual-Axis Linear Motor Stage , which are referred to as LMSSA2X in the manual. The contents include introduction, selection, interface design, installation, troubleshooting, maintenance and waste disposal, and appendices. Please read through this manual for correctly operating LMSSA2X.

# 1.3 General precautions

Before using the product, please carefully read through this manual. HIWIN MIKROSYSTEM is not responsible for any damage, accident or injury caused by failure in following the installation instructions and operating instructions stated in this manual.

- Before installing or using the product, ensure there is no damage on its appearance. If any damage is found after inspection, please contact HIWIN or local distributors.
- Do not disassemble or modify the product. The design of the product has been verified by structural calculation, computer simulation and actual testing. HIWIN is not responsible for any damage, accident or injury caused by disassembly or modification done by users.
- Ensure the wiring is not damaged and can be normally connected.
- Keep children away from the product.
- Anyone with psychosomatic illness or insufficient experience should not use the product alone. The supervision of managers or product docents is definitely needed.

If the login information does not match your order, please contact HIWIN or local distributors.

HIWIN offers 1-year warranty for the product. The warranty does not cover damage caused by improper usage (refer to the precautions and instructions stated in this manual) or natural disaster.

#### 1.4 Safety instruction

- Carefully read through this manual before installation, transportation, maintenance and examination.
   Ensure the product is correctly used.
- Carefully read through electromagnetic (EM) information, safety information and related precautions before using the product.
- Safety precautions in this manual are classified into "DANGER", "WARNING" and "CAUTION".

# **■ A**DANGER

Imminent danger!

Indicates that death or severe personal injury will result if proper precautions are not taken.

# **WARNING**

Potentially dangerous situation!

Indicates that death or severe personal injury may result if proper precautions are not taken.

# **ACAUTION**

Potentially dangerous situation!

Indicates that property damage or environmental pollution can result if proper precautions are not taken.

#### **Warning Signs**



No access for people with active implanted cardiac devices.



Substance hazardous to the environment!



Warning!



Warning of crushing of hands!



Warning of electricity!



Warning of hot surface!



Warning of magnetic field!

#### **Mandatory Signs**



Wear head protection!



Refer to user manual!



Wear protective gloves!



Disconnect before carrying out maintenance or repair.



Wear safety footwear!



Lifting point.

Basic safety notices

# **ADANGER**

Danger from strong magnetic fields!



Strong magnetic fields around linear motor systems pose a health risk to a person with implants (e.g. cardiac pacemakers) that are affected by magnetic fields.

Anyone with implants that are affected by magnetic fields should maintain a safe distance of at least 500 mm from linear motor systems (trigger threshold for static magnetic fields of 0.5 mT as per directive 2013/35/EU).

# **MARNING**

Risk of Linear motor operate.

When incorrectly operated and in the case of a fault, the motor can overheat resulting in fire and smoke. This can result in severe injury or death. Further, excessively high temperatures destroy motor components and result in increased failures as well as shorter service lives of motors.



- Operate the motor according to the relevant specifications.
- ♦ Allow the forcer to cool down sufficiently (in a 25°C room temperature) before working around the product to avoid burns.
- When an abnormal smell, noise, smoke, or vibration is detected, please turn off the power immediately.

# **ACAUTION**

Risk of physical damage to watches and magnetic storage media.



Strong magnetic forces may destroy watches and magnetizable data storage media near to the linear motor system!

◆ Do not bring watches or magnetizable data storage media close to (<300 mm) the linear motor systems!

Transport to the installation site

# **MARNING**

Risk of crushing from forcer housing!



Danger of injury from crushing and damage to the linear motor system caused by movement of the forcer housing due to gravity, as it does not feature brakes in its standard version.

◆ Ensure that each transportation safety devices are well fixed before transportation. In most cases, the devices are made in red.

# **WARNING**

Danger from heavy loads!

Lifting heavy loads may damage your health.



- ◆ For system's weight over 20 kg, use a hoist of an appropriate size when positioning heavy loads!
- ◆ Check applicable occupational health and safety regulations when handling suspended loads!
- Assembly and connection

# **A**DANGER

Danger from electrical voltage!

Before and during assembly, disassembly and repair work, dangerous currents may flow.



- Work may only be carried out by a qualified electrician and with the power supply disconnected!
- ◆ Before carrying out work on the linear motor system, disconnect the power supply and protect it from being switched back on!

## **ADANGER**

Risk of crushing from strong forces of attraction!



There is a risk of crushing from the strong forces of attraction emitted by the stators, as they are assembled with opposing polarity!

- Assemble the stators carefully!
- Do not place fingers or objects between the stators!

# **MARNING**



Risk of crushing from forcer housing!

Danger of injury from crushing and damage to the linear motor system caused by movement of the forcer housing due to gravity, as it does not feature brakes in its standard version.

♦ Ensure that the linear motor system does not exceed 1° horizontal deviation!

# **MARNING**

Risk of crushing from the forcer!



Danger of injury from crushing and damage to the forcer through uncontrolled movements during assembly.

◆ Ensure that the forcer is locked in place during assembly using transportation safety devices!

# **WARNING**

Risk of crushing from strong forces of attraction!



Danger of injury from crushing and damage to the forcer or stator caused by very strong forces of attraction.

• Ensure that the forcer only comes close to the stator when the linear guideways can absorb the forces!


# **WARNING**

Danger from heavy loads!

Lifting heavy loads may damage your health.

- Use a hoist of an appropriate size when positioning heavy loads which are over 20 kg!
- ♦ Check applicable occupational health and safety regulations when handling suspended loads!
- ◆ To transport the linear axis, hoist it at the points designated A and B!





Electrical connection

# **ADANGER**

Danger from electrical voltage!



If linear motors are incorrectly grounded, there is a danger of electric shock.

 Before connecting the electrical power supply, ensure that the linear motor system is correctly grounded.

# **▲**DANGER

Danger from electrical voltage!

Electrical currents may flow even if the motor is not moving.



- Ensure that the linear motor system is disconnected from the power supply before the electrical connections are detached from the motors.
- ◆ After disconnecting the drive amplifier from the power supply, wait at least 5 minutes before touching live parts or breaking connections.
- ♦ For safety reasons, measure the voltage in the intermediate circuit and wait until it has fallen below 40V.
- Switch on the linear motor system

# **WARNING**

Risk of crushing from strong forces of attraction!



Strong magnetic forces may attract steel or iron objects from the linear motor system and cause crushing!

- ◆ No heavy (> 1 kg) or large (> 0.01 m²) steel or iron objects should be introduced by hand into the immediate surrounding area (50 mm) of the magnet track!
- Use suitable tools only.

# **MARNING**

Risk of crushing from moving forcer housing!



The forcer housing may cause damage to parts through its movement at the end position of the machine.

◆ The operator should provide protective equipment to prevent from reaching into the danger area of the machine!

# **AWARNING**



Risk of burns!

The motor heats up during operation and thus touching the motor can lead to burns!

◆ Provide protective devices and warning notices at the motor!

Maintenance and cleaning

#### **ADANGER**

Danger from electrical voltage!

Before and during maintenance and cleaning, dangerous currents may flow.



- Work may only be carried out by a qualified electrician and with the power supply disconnected!
- ◆ Before carrying out work on the linear motor system, disconnect the power supply and protect it from being switched back on!

# **AWARNING**

Risk of crushing from moving parts!



The forcer housing may cause damage to parts through its movement at the end position of the machine.

◆ The operator should provide protective equipment to prevent from reaching into the danger area of the machine!

# **MARNING**

Risk of burns!



The motor heats up during operation and thus touching the motor can lead to burns!

◆ After disconnecting the drive amplifier from the power supply, wait at least 5 minutes before removing the cover and touching the motor.

#### **MARNING**

Unauthorized repairs on the system



- Unauthorized work on the system creates the risk of injuries and may invalidate the warranty.
- ◆ The system must only be serviced by specialist personnel!

# 1.5 Copyright

This user manual is protected by copyright. Any reproduction, publication in whole or in part, modification or abridgement requires the written approval of HIWIN MIKROSYSTEM.

#### Note:

HIWIN MIKROSYSTEM reserves the right to change the contents of this manual or product specifications without prior notice.

#### 1.6 Manufacturer information

Table 1.6.1 Manufacturer's details

Corp.	HIWIN MIKROSYSTEM CORP.
Address	No.6, Jingke Central Rd., Taichung Precision Machinery Park, Taichung 40852, Taiwan
Tel.	+886-4-23550110
Fax	+886-4-23550123
Sales E-mail	business@hiwinmikro.tw
Customer Service E-mail	service@hiwinmikro.tw
Website	http://www.hiwinmikro.tw

#### 1.7 Product monitoring

Please inform HIWIN MIKROSYSTEM, the manufacturer of LMSSA2X, of:

- Accidents
- Potential sources of danger in LMSSA2X
- Anything in this user manual which is difficult to understand

# 2. Basic safety information

2.	Basi	c safety i	information	2-1
	2.1	O۱	verview	. 2-2
	2.2	Ва	asic safety notices	. 2-2
	2.3	Re	easonably foreseeable misuse	. 2-2
	2.4	Co	onversions and modifications	. 2-3
	2.5 Residual risks		esidual risks	. 2-3
	2.6	Pe	ersonnel requirements	. 2-3
	2.7	Pr	rotective equipment	. 2-4
		2.7.1	Personal protective equipment	. 2-4
		2.7.2	Protective equipment on the LMSSA2X	. 2-5
	2.8	La	abels on LMSSA2X	2-5

#### 2.1 Overview

LMSSA2X are designed to be installed and operated on a horizontal surface, combined with a two-axis linear motor system to achieve precise positioning in time and position in space. LMSSA2X must not be used outdoors or in hazardous areas where there is a risk of explosion. All linear motor systems may only be used for the specified purpose.

- LMSSA2X must be operated within its specified performance limits (see technical information and the approval drawing).
- Reading through the user manual and compliance with the maintenance and repair regulations are necessary for the intended use of LMSSA2X.
- Any other use of the LMSSA2X shall be considered as contrary to the intended use.
- Use only original spare parts from HIWIN MIKROSYSTEM.

#### 2.2 Basic safety notices

We assume that

- operating staff are trained in the safe operation practices for LMSSA2X and have read and understood this user manual in full;
- maintenance staff maintain and repair the LMSSA2X in such a way that they pose no danger to people, property or the environment.

#### 2.3 Reasonably foreseeable misuse

LMSSA2X must not be operated:

- Outdoors
- In potentially explosive atmospheres

#### 2.4 Conversions and modifications

Modifications of the LMSSA2X are not permitted! Please contact HIWIN MIKROSYSTEM for special request.

#### 2.5 Residual risks

- Normal operation of LMSSA2X constitutes no residual risks.
- Warnings about risks that may arise during maintenance and repair work are provided in the relevant sections.

## 2.6 Personnel requirements

Only authorized persons may carry out work on LMSSA2X! They must be familiar with the safety equipment and regulations before starting work (See table 2.6.1).

Table 2.6.1 Personnel requirements

Activity	Qualification	
Normal operation	Trained personnel	
Cleaning	Trained personnel	
Maintenance	Trained specialist personnel of the operator or manufacturer	
Repairs	Trained specialist personnel of the operator or manufacturer	

## 2.7 Protective equipment

#### 2.7.1 Personal protective equipment

# **ACAUTION**

Risk of noise.

The information below will enable the user of the machine to make a better evaluation of the hazard and risk.

- ◆ Equivalent A-weighted Sound pressure level according to EN ISO 3746: 70.5 dB (A)
- Uncertainty, K in decibels: 4.0 dB (A) according to EN ISO 4871



The emission levels are not necessarily safe working levels. While there is a correlation between the emission and exposure levels, this cannot be used reliably to determine whether or not further precautions are required.

Factors that influence the actual level of exposure of the workforce include the characteristics of the work room, the other sources of noise, the number of machines, other adjacent processes, and the length of time for which an operator is exposed to the noise. Also, the permissible exposure level can vary from country to country.

Table 2.7.1.1 Personnel requirements

Operating phase	Personal protective equipment			
	When in the vicinity of LMSSA2X, the following personal protective equipment			
	is required:			
Normal operation	(1). Safety shoes			
	(2). Protective helmet			
	(3). Protective gloves			
	When cleaning LMSSA2X, the following personal protective equipment is			
	required:			
Cleaning	(1). Safety shoes			
	(2). Protective helmet			
	(3). Protective gloves			
	When carrying out operation, maintenance, repairs and cleaning of LMSSA2X,			
	the following personal protective equipment is required:			
Maintenance and repairs	(1). Safety shoes			
	(2). Protective helmet			
	(3). Protective gloves			

#### 2.7.2 Protective equipment on the LMSSA2X

- LMSSA2X are fitted with position dampers.
- After every movement, these position dampers must be tested at the end positions and, if necessary, replaced.
- The machine may not be operated without position dampers or when dampers are damaged!

#### 2.8 Labels on LMSSA2X




Figure 2.8.1 Warning symbols and plate – here for LMSSA2X

Table 2.8.1 Warning symbols

Pictogram	Type and source of danger	Protective measures
^		Keep out of the machine's area of movements!
	Danger from movements!	Prevent unauthorized access to the danger
		area!
^		Anyone whose health may be endangered by
<b>/</b> 0\	Danger from strong magnetic fields!	strong magnetic fields must keep a safe
		distance (0.5 m) from the linear motor system!

Note: Stator labels are provided with the machine.

# HIWIN. MIKROSYSTEM

MM18UE01-2404

Basic safety information

Standard Dual-Axis Linear Motor Stage User Manual

(This page is intentionally left blank.)

# 3. Product description

3.	Produc	Product description			
	3.1	LMSSA2X description	3-2		
	3.2	Main components of LMSSA2X	3-3		
	3.3	Order code	3-4		
	3.4	Linear motors	3-5		
	3.5	Positioning measurement system	3-6		
	3.6	Limit switches (Standard)	3-7		
	3.7	Cable chain (Standard)	3-8		
	3.8	Orthogonality	3-9		

## 3.1 LMSSA2X description

LMSSA2X is composed of two single-axis linear motors. Therefore, it continues the advantages of SSA with short delivery time, easy installation and high cost performance.

Table 3.1.1 shows LMSSA2X with a travel range of 200 to 500 mm, which can be used in automation, electronics, and semiconductor industries. These LMSSA2X are usually installed and operated in a horizontal position. If you have different requirements, please contact HIWIN MIKROSYSTEM.

Table 3.1.1 LMSSA2X

Туре	LMSSA2X-10S100-13S200	LMSSA2X-13S300-20S300
LMSSA2X		

Note: HIWIN MIKROSYSTEM continually improves its product offerings, and listed options may be replaced at any time. Please refer to the most recent edition HIWIN MIKROSYSTEM of the product guide for the latest product information at https://www.hiwinmikro.tw/en.

# 3.2 Main components of LMSSA2X





Figure 3.2.1 Main components of LMSSA2X

Table 3.2.1 Main components of LMSSA2X

Pos.	Components	Remark
1	Upper axis linear motor	Cable chains are not replaceable
2	Transition Board	
3	Lower axis linear motor	Cable chains are not replaceable
4	Extension Cable	

#### 3.3 Order code



Note: HIWIN MIKROSYSTEM continually improves its product offerings, and listed options may be replaced at any time. Please refer to the most recent edition of the product guide for the latest product information at <a href="https://www.hiwinmikro.tw/en">https://www.hiwinmikro.tw/en</a>.

#### 3.4 Linear motors

A linear motor consists of two components, the forcer (primary part) with coils and the stator (secondary part) with permanent magnets. The coils carrying alternating current generate a magnetic field that changes over time and interacts with the steady magnetic field of the stator. The resulting force is used to generate linear motion. The linear motor components are supplied as separate parts.

Table 3.4.1 Linear motor type

	Symbol	Unit	10S100	13S200	20\$300
Continuous force	F <sub>c</sub>	N	103	205	362
Continuous current	I <sub>c</sub>	A <sub>rms</sub>	2.1	4.2	3.9
Peak force(1s)	$F_p$	N	289	579	1023
Peak current(1s)	$I_p$	A <sub>rms</sub>	6.3	12.7	11.8
Attraction force	F <sub>a</sub>	N	481	963	1926
Resistance(line to line,25°C)	R <sub>25</sub>	Ω	8.4	4.1	6.8
Resistance(line to line,120°C)	R <sub>120</sub>	Ω	11.6	5.7	9.4
Inductance (line to line)	L	mH	37.1	18.5	33
Pole pair pitch	2т	mm	30		
Thermal switch	-	-	3PTC SNM	120 In Series (for h	igh voltage)
Maximum DC bus voltage	-	$V_{DC}$	325 (star	ndard)/600 (for high	voltage)

MM18UE01-2404

#### 3.5 Positioning measurement system

# **△**CAUTION



Damage caused by scratching!

The measuring scale of the optical measuring system may be damaged by improper handling.

♦ Handle the measuring scale with care!

# **ACAUTION**

Damage to the magnetic positioning measurement system!



Strong magnetic fields and vibrations can damage the magnetic positioning measurement system.

- ♦ Protect the magnetic positioning measurement system against strong magnetic fields!
- Protect the magnetic positioning measurement system against strong vibrations!


The distance travelled is measured by a high-resolution positioning measurement system that is mounted on the base. Depending on its type, the linear motor system features an optical or a magnetic positioning measurement system. The installed positioning measurement system is fully cabled and is connected to the controller via a separate connector (see technical Information and approval drawing).

Table 3.5.1 Positioning measurement system selection

Order code	Power supply		Power supply Resolution[µm]		Interface	
А	5V 150mA		0.1 (suggested value)	Incremental	1 Vpp (analog)	
К	5V 200mA 5V 35mA		0.1	Incremental	TTL (digital)	
D/E			1 (suggested value)	Incremental	TTL (digital)	

# 3.6 Limit switches (Standard)

Depending on the type, a few optical or inductive switches generate a signal to the controller upon reaching the end of the travel distance. The limit switches are supplied pre-wired and operational.



D-Sub 9Pin(F)	Color	Signal	Label	Note
1	Yellow	2-A	2-OUT	Positive limit
2	White	-	-	Power(-)
3	Grey	3-A	3-OUT	Near home
6	Blue	+	+	Power(+)
7	Red	1-A	1-OUT	Negative limit
Case	Shield	GND		GND

Figure 3.6.1 pin assignment (standard)

# 3.7 Cable chain (Standard)

Table 3.7.1 and table 3.7.2 show the information for motor and readhead lines. HIWIN MIKROSYSTEM has configured the most suitable combination of chains according to the wire material.

Table 3.7.1 Information of motor cable

Order code	Voltage	Weight (g/m)	Outer diameter (mm)	Bend radius (moved)(mm)	Bend radius (fixed)(mm)
105100	Standard	71	6.2	47	25
10S100	High voltage	140	9.2	69	37
125200	Standard	79	7.5	38	23
13S200	High voltage	140	9.2	69	37
205200	Standard	46	7.5	38	23
20S300	High voltage	140	9.2	69	37

Table 3.7.2 Information of encoder cable

Encoder code	Weight (g/m)	Outer diameter (mm)	Bend radius (moved)	Bend radius (fixed)
А	26	4.25	30	10
D/E	26	5	38	20
K	26	4.25	30	10

## 3.8 Orthogonality

In order to achieve better orthogonality performance, the assembly will be adjusted according to the following techniques.

- (1) Place the upper axis in the center of the stroke and place the square gauge above it.
- (2) Move the upper axis back and forth by 200mm to make the sides of the square gauge parallel.
- (3) Move the lower axis back and forth by 200mm and adjust the angle of the upper axis to make the sides of the square gauge parallel.
- (4) Fix the upper and lower axis, and verify the orthogonality is in accordance with the specification again.




Figure 3.8.1 Orthogonality correction

# HIWIN. MIKROSYSTEM

MM18UE01-2404

<u>Product description</u> Standard Dual-Axis Linear Motor Stage User Manual

(This page is intentionally left blank.)

# 4. Transport and setup

4.	Trar	ransport and setup		
	4.1	•	elivery	
	4.2	Tr	ansport to the installation site	4-2
	4.3 Requirements at the installation		equirements at the installation site	4-4
		4.3.1	Ambient conditions	4-4
		4.3.2	Safety equipment to be provided by the operator	4-5
	4.4	St	orage	4-5
	4.5	Ur	npacking and setup	4-5

#### 4.1 Delivery

LMSSA2X are supplied fully assembled, function tested and ready for connection. To prevent damage arising during transport, LMSSA2X are provided with transportation safety devices and shipping devices.

#### 4.2 Transport to the installation site

# **▲** DANGER

Danger from strong magnetic fields!



Strong magnetic fields around linear motor systems pose a health risk to a person with implants (e.g. cardiac pacemakers) that are affected by magnetic fields.

Anyone with implants that are affected by magnetic fields should maintain a safe distance of at least 500 mm from linear motor systems (trigger threshold for static magnetic fields of 0.5 mT as per directive 2013/35/EU).

# **MARNING**

Risk of crushing from forcer housing!



Danger of injury from crushing and damage to the linear motor system caused by movement of the forcer housing due to gravity, as it does not feature brakes in its standard version.

• Ensure that each transportation safety devices are well fixed before transportation. In most cases, the devices are made in red.

# **WARNING**

Danger from heavy loads!

Lifting heavy loads may damage your health.



- For system's weight over 20 kg, use a hoist of an appropriate size when positioning heavy loads!
- Check applicable occupational health and safety regulations when handling suspended loads!

# **ACAUTION**

Risk of physical damage to watches and magnetic storage media.



Strong magnetic forces may destroy watches and magnetizable data storage media near to the linear motor system!

◆ Do not bring watches or magnetizable data storage media into the vicinity (<300 mm) of the linear motor systems!

# **ACAUTION**

Damage of the linear motor system!

XY-axis positioning stages may be damaged by mechanical loading.

- No heavy load on the cover!
- ◆ Lift the linear motor system using the shipping devices (figure 4.2.1)!



- For longer linear motor system, provide additional protection of the center section.
- Ensure that the linear motor system does not bend as this could permanently damage accuracy.
- During transport, do not transport any additional loads on the linear motor system!
- Secure the linear motor system and components against tilting!

Note: Electrical equipment is designed to withstand to protect against the effects of transportation, and storage temperature within a range of -25°C to +55°C and for short periods not exceeding 24 hours at up to +70°C.

- Steps to transport LMSSA2X:
  - (1). Disconnect power supply.
  - (2). Disconnect stage cables.
  - (3). Remove the payload.
  - (4). To transport LMSSA2X, hoist it at the points designated A and B (figure 4.2.1).
  - (5). Ensure even load distribution while lifting.




Figure 4.2.1 Hoisting and transporting

# 4.3 Requirements at the installation site

#### 4.3.1 Ambient conditions

Table 4.3.1.1 Ambient condition requirement

Area of use	For indoor use only	
Temperature	0 °C to 40 °C	
Humidity	< 80%RH (non-condensing)	
Altitude	< 1000m	
Installation site	Flat, dry, vibration-free	
Protection class	No interference from corrosive solvent or strong magnetic	
Grounding	Plant power grounding line conforms to international requirements	

- (1). Avoid exposing to direct sunlight or heat rays.
- (2). Away from electric magnetic interference source sites, such as welding, discharge machine.

#### 4.3.2 Safety equipment to be provided by the operator

Possible safety equipment/measures:

- Personal protective equipment in accordance with regional regulations
- Zero-contact protective equipment
- Mechanical protective equipment

### 4.4 Storage

## **ADANGER**

Danger from strong magnetic fields!



Strong magnetic fields around linear motor systems pose a health risk to a person with implants (e.g. cardiac pacemakers) that are affected by magnetic fields.

Anyone with implants that are affected by magnetic fields should maintain a safe distance of at least 500 mm from linear motor systems (trigger threshold for static magnetic fields of 0.5 mT as per directive 2013/35/EU).

#### Note:

- (1). Store the linear motor system in its transport packaging.
- (2). Only store the linear motor system in dry, frost-free areas with a corrosion-free atmosphere.
- (3). Clean and protect used linear motor system before storage.
- (4). When storing the linear motor system, attach signs warning of magnetic fields.

## 4.5 Unpacking and setup

# **ACAUTION**



Damage of attachments!

Attachments may be damaged by mechanical loading.

♦ Secure and move the linear motor system using the suspension points provided!

- (1). LMSSA2X may only be installed and operated indoors.
- (2). LMSSA2X is designed exclusively for horizontal installation. During installation, the linear motor system must not exceed an angle of 1° as it does not feature a parking brake.

### **HIWIN**<sub>®</sub> MIKROSYSTEM

MM18UE01-2404

Transport and setup

Standard Dual-Axis Linear Motor Stage User Manual

- Steps to unpack and install LMSSA2X:
  - (1). Remove protective film.
  - (2). Carefully transport LMSSA2X on the shipping devices provided to the specified installation site.
  - (3). Ensure that the maintenance points are easily accessible.
  - (4). Dispose of packaging in an environmentally friendly way.

# 5. Assembly and connection

5.	Asse	embly and	connection	5-1
	5.1	Med	chanical installation	5-2
		5.1.1	Mechanical mounting	5-2
		5.1.2	Assembling LMSSA2X	5-3
		5.1.3	Assembling the moved load	5-4
	5.2 Electrical installation		ctrical installation	5-5
		5.2.1	Power supply and controller selection	5-8
		5.2.2	Connecting iron-core/ironless motors	5-11
		5.2.3	Connecting the linear positioning measurement system	5-11
		5.2.4	Connecting the limit switch	5-13

### 5.1 Mechanical installation

### 5.1.1 Mechanical mounting




Figure 5.1.1.1 LMSSA2X assembly

- (1). To maintain accuracy, the mounting surface should be flat.
- (2). The stage base is precision machined and verified for flatness prior to stage assembly at the factory.
- (3). The accuracy is measured on granite plane before shipment.

Table 5.1.1.2 LMSSA2X assembly dimensions (H)

(Effective travel of upper axis)	Dimensions(mm)		
(effective travel of lower axis)	LMSSA2X-10S100-13S200	LMSSA2X-13S200-20S300	
200x200			
250x250			
300x300		200 ±0.4	
350x350	185 ±0.4		
400x400			
400x450			
400x500			

#### 5.1.2 Assembling LMSSA2X

- The steps for the assemble of LMSSA2X:
  - (1). Remove the shipping devices.
  - (2). Remove the transportation safety device from the forcer housing.
  - (3). Remove the upper cover plate if the mounting holes are inaccessible.
  - (4). Drill mounting holes in the mounting surface in accordance with scale drawing (see Technical Information and Approval Drawing).
  - (5). Clean mounting surface.
  - (6). Place the mounting bolts into the mounting holes, tighten them, and apply torque. (See Table 5.1.2.1).
  - (7). If the cover was removed, install them back.

- (1). Secure the screws with retaining rings to prevent them from accidentally coming loose!
- (2). After assembling the moved load, please design another transportation safety device to lock the forcer housing in place during transport.
- (3). The mounting hole of the short travel part will be covered, you can remove the hard stop on the moving part to solve the problem.




Figure 5.1.2.1 Assembling LMSSA2X – here for LMSSA2X-10S100-13S200

Table 5.1.2.1 Mounting torque

Туре	Mounting	Screw Size	Torque (kgf-cm)
LMSSA2X-10S100-13S200	top	M5	90
LIVISSAZA-103100-133200	bottom	M6	135
LMSSA2X-13S200-20S300	top	M5	90

#### 5.1.3 Assembling the moved load

- Steps to assemble the moved load:
  - (1). Clean the mounting surface on LMSSA2X that is to receive the load.
  - (2). Clean the mounting surface of the load.
  - (3). Position the load over the corresponding mounting holes on the mounting surface (see technical information and approval drawing).
  - (4). Place the mounting bolts in the mounting holes and tighten them in a spiral motion from inside to outside with a torque screws (See table 5.1.2.1).
  - (5). Check the free movement of the load over the entire travel distance.

Note: After assembling the moved load, please design another transportation safety device to lock the forcer housing in place during transport.

### 5.2 Electrical installation

# **ADANGER**

Danger from electrical voltage!



If linear motors are incorrectly grounded, there is a danger of electric shock.

◆ Before connecting the electrical power supply, ensure that the linear motor system is correctly grounded.

# **A**DANGER

Danger from electrical voltage!

Electrical currents may flow even if the motor is not moving.



- Ensure that the linear motor system is disconnected from the power supply before the electrical connections are separated from the motors.
- ◆ After disconnecting the drive amplifier from the power supply, wait at least 5 minutes before touching live parts or breaking connections.
- ♦ For safety reasons, measure the voltage in the intermediate circuit and wait until it has fallen below 40V.

- (1). Observe the separate assembly instructions of the drive!
- (2). The supply voltage is based on the drive. Please consult the manufacturer's separate operating instructions for detailed information.
- (3). Supplied with cabling ready for operation.
- (4). All necessary connections via three connectors of each axis.




Figure 5.2.1 Electrical connection for E1 drive




Figure 5.2.2 Electrical connection for E2 drive

## 5.2.1 Power supply and controller selection

The continuous current, peak current and bus voltage must be considered while selecting a power supply. In addition, the resonance effect which can be induced in motors by some drive systems must be taken into account. Motors are assembled with several individual coils connected in series. Each one of these coils has an inductance in series and a stray capacitance to the ground. The LC network obtained possesses a resonant frequency, so when an electrical oscillation is applied to the phase inputs (in particular the PWM frequency), the neutral point of the motor can oscillate with very high amplitudes with respect to the ground, and the insulation can be damaged as a consequence of these oscillations. This phenomenon is more obvious in motors with a large number of poles (such as Linear motors).

- When selecting power supply, please check the conditions below:
  - (1). 325 V DC controller: peak voltages < 750 V p (phase to ground), voltage gradient < 8 kV/µs.

(Table 5.2.1.1 & Figure 5.2.1.3)

(2). 750 V DC controller: peak voltages < 1000 V p (phase to ground), voltage gradient < 11 kV/µs.

(Table 5.2.1.2 & Figure 5.2.1.4)

The cable between the controller and the motor will generate a reflected wave due to the impedance mismatch between the cable and the motor, and the reflected voltage will be superimposed with the subsequent input voltage, causing the voltage to rise. This phenomenon will be more obvious when the motor cable is longer. If the length of the cable between the controller and the motor is longer than 10 m, it is necessary to measure voltages at the motor terminals to ensure they are lower than specified above. If the measured value is greater, a dV / dt filter must be inserted between the controller and the motor for protection.

- (1) For the maximum motor operation voltage, please refer to "Linear Motor Technical Information", which can be downloaded from the official website.
- (2) Peak voltages and dV / dt gradients generated by the power supply must not exceed the values below (as well as neutral point):




Figure 5.2.1.1 Voltage schematic




Figure 5.2.1.2 Rising time  $t_r$  definition

Table 5.2.1.1 (A: Standard) series voltage limitation of power supply and neutral point

Item	Mounting	
$V_{bus}$	Max. 325 Vdc	
$V_{peak.\ to\ ground}^+$	< 750 $V_p$ (phase to ground)  @ PWM frequency	
$\left V_{peak.\ to\ ground}^{-}\right $	< 750 $V_p$ (phase to ground)  @ PWM frequency	
Voltage and disease IVV ( Iv)	< $8kV/\mu s$ (instantaneous)  If it is difficult to obtain instantaneous voltage gradient, the	
Voltage gradient  dV/dt	following formula can be used to estimate (Figure 5.2.1.2) : $  dV/dt  = \left  (90\%V_{pp} - 10\%V_p)/t_r \right  $	




Figure 5.2.1.3 Voltage oscillation schematic (325 V\_DC controller)

Table 5.2.1.2 (B:High voltage) Series voltage limitation of power supply and neutral point

Item	08S/10S/13S/18S/20S Series (B:High voltage)
$V_{bus}$	Max. 750 Vdc
V <sup>+</sup> <sub>peak. to ground</sub>	< 1000 $V_p$ (phase to ground)  @ PWM frequency
$V_{peak.\ to\ ground}^-$	< 1000 $V_p$ (phase to ground)  @ PWM frequency
Voltage gradient $ dV/dt $	$< 11kV/\mu s$ (instantaneous) If it is difficult to obtain instantaneous voltage gradient, the following formula can be used to estimate (Figure 5.2.1.2):
	$ dV/dt  =  (90\%V_{nn} - 10\%V_{n})/t_{r} $




Figure 5.2.1.4 Voltage oscillation schematic (750 V\_DC controller)

### 5.2.2 Connecting iron-core/ironless motors


The temperature sensor system cable is routed as standard through the motor's extension cable. Both cables are therefore connected to the motor plug.

Note: Check the technical information and approval drawing for pin assignment!

### 5.2.3 Connecting the linear positioning measurement system

### **ACAUTION**

Danger of EMC interference in the encoder signal!





- ◆ Make sure that the encoder cable has been shielded correctly!
- Ensure that the shielding is in full contact across the connectors!
- Ensure that the pairs of wires with the sin/cos signal are shielded separately!

### **ACAUTION**

Danger of injury!



- ♦ An incorrectly connected distance measuring system may cause uncontrolled carriage movements which can lead to injuries or might damage the linear axis.
- ◆ Only qualified personnel may connect the distance measuring system!

- (1). The linear positioning measurement system is installed ready for operation in the linear motor system.
- (2). Check the technical information and approval drawing for pin assignment!

Table 5.2.3.1 Connector

Туре	Pole configuration		
D-Sub 15-pin (Male)	52 16 40	1	

Table 5.2.3.2 Pin assignment

	D-Sub 15-pin			
Pin no.	Magnetic		Optical	
	E	D	Α	K
1	-	SIN-	V1-	-
2	0V	CON-	V2-	0V
3	-	REF+	V0+	-
4	Z-	5V	5V	Z-
5	B-	-	5V	B-
6	A-	-	-	A-
7	5V	-	-	5V
8	-	-	-	5V
9	-	SIN+	V1+	0V
10	-	CON+	V2+	-
11	-	REF-	V0-	-
12	Z+	0V	0V	Z+
13	B+	-	0V	B+
14	A+	-	-	A+
15	-	-	-	-
Plug housing	Shielding	Shielding	Shielding	Shielding

Table 5.2.3.3 Linear encoder parameter

E : Digital 1µm magnetic encoder			
Resolution	1 μm		
Scale pitch	1 mm		
Signal	digital, TTL 5V		
D : analog ma	agnetic encoder		
Resolution	1 μm		
Scale pitch	1 mm		
Signal	analog,1 Vpp sin/cos		
A : analog o	ptical encoder		
Resolution	0.1 µm		
Scale pitch	40 μm		
Signal	analog,1 Vpp sin/cos		
K : Digital 0.1µm optical encoder			
Resolution	0.1 um		
Scale pitch	40 μm		
Signal	digital, TTL 5V		

### 5.2.4 Connecting the limit switch

The optical or inductive proximity switches in design as limit switches are installed ready for operation in LMSSA2X.

- (1). Check the technical information and approval drawing for the position of limit switches.
- (2). Check the technical information and approval drawing for pin assignment!

### HIWIN. MIKROSYSTEM

MM18UE01-2404

Assembly and connection

Standard Dual-Axis Linear Motor Stage User Manual

(This page is intentionally left blank.)

# 6. Commissioning

6.	Commission	Commissioning		
	6.1	Switch on LMSSA2X	6-2	
	6.2	Programming	6-4	

#### 6.1 Switch on LMSSA2X

### **ADANGER**

Danger from strong magnetic fields!



Strong magnetic fields around linear motor systems pose a health risk to a person with implants (e.g. cardiac pacemakers) that are affected by magnetic fields.

Anyone with implants that are affected by magnetic fields should maintain a safe distance of at least 500 mm from linear motor systems (trigger threshold for static magnetic fields of 0.5 mT as per directive 2013/35/EU).

# **MARNING**

Risk of crushing from strong forces of attraction!

Strong magnetic forces may attract steel or iron objects from the linear motor system and cause crushing!



- ◆ No heavy (> 1 kg) or large (> 0.01 m²) steel or iron objects should be held by hand into the immediate surrounding area (50 mm) of the magnet track!
- Use suitable tools only.

## **MARNING**

Risk of crushing from moving forcer housing!



The forcer housing may cause damage to parts through its movement at the end position of the machine.

◆ The operator should provide protective equipment to prevent from reaching into the danger area of the machine!

### **WARNING**



Risk of burns!

The motor heats up during operation so touching the motor can lead to burns!

◆ Provide protective devices and warning notices at the motor!

# **ACAUTION**

Risk of physical damage to watches and magnetic storage media.



Strong magnetic forces may destroy watches and magnetizable data storage media near to the linear motor system!

◆ Do not bring watches or magnetizable data storage media into close to (<300 mm) the linear motor systems!

### **ACAUTION**

Damage of the linear motor system!

Danger of material damage through uncontrolled movements of the forcer housing in the case of a power cut!



- ♦ Ensure that the dampers are fitted in the end positions on both sides of the linear motor system!
- No heavy load on the cover!
- No moving the forcer housing!

Note: The operator should provide a controller according to EN ISO 12100 that prevents the machine from being started up unintentionally after power is restored, troubleshooting or the machine is stopped.

### HIWIN. MIKROSYSTEM

MM18UE01-2404

Commissioning

Standard Dual-Axis Linear Motor Stage User Manual

Step	eps to switch on LMSSA2X.			
(1).	Switch off the controller.			
(2).	Pull out the motor cable.			
(3).	Connect positioning measurement system cable.			
(4).	Switch on the controller.			
(5).	Check the positioning measurement system (see separate assembly instructions for the drive and positioning measurement system).			
(6).	Switch off the controller.			
(7).	Connect the motor cable.			
(8).	Switch on the controller.			
(9).	Perform test run at slow speed.			
(10).	Perform test under usage conditions.			

# 6.2 Programming

The programming of the linear motor system depends on the controller and drive used. Check the user manual for the controller and drive!

# 7. Maintenance and cleaning

7.	Maii	ntenance	e and cleaning	7-1
	7.1	M	faintenance	7-2
		7.1.1	Linear motor	7-6
		7.1.2	Positioning measurement system	7-6
		7.1.3	Electromechanical components	7-6
		7.1.4	Linear guideways	7-7
		7.1.5	Cleaning	7-12
		7.1.6	Test run	7-12

#### 7.1 Maintenance

## **ADANGER**

Danger from electrical voltage!



Before and during maintenance and cleaning, dangerous currents may flow.

Work may only be carried out by a qualified electrician and with the power supply disconnected!

◆ Before carrying out work on the linear motor system, disconnect the power supply and protect it from being switched back on!

### **ADANGER**

Danger from strong magnetic fields!



Strong magnetic fields around linear motor systems pose a health risk to a person with implants (e.g. cardiac pacemakers) that are affected by magnetic fields.

Anyone with implants that are affected by magnetic fields should maintain a safe distance of at least 500 mm from linear motor systems (trigger threshold for static magnetic fields of 0.5 mT as per directive 2013/35/EU).

# **MARNING**

Risk of crushing from moving parts!



The forcer housing may cause damage to parts through its movement at the end position of the machine.

◆ The operator should provide protective equipment to prevent from reaching into the danger area of the machine!

### **WARNING**

Risk of burns!



The motor heats up during operation and thus touching the motor can lead to burns!

After disconnecting the drive amplifier from the power supply, wait at least 5 minutes before removing the cover and touching the motor.

### **MARNING**



Unauthorized repairs on the system

Unauthorized work on the system creates the risk of injuries and may invalidate the warranty.

The system must only be serviced by specialist personnel!

# **ACAUTION**

Risk of physical damage to watches and magnetic storage media.



Strong magnetic forces may destroy watches and magnetizable data storage media near to the linear motor systems!

◆ Do not bring watches or magnetizable data storage media into close to (<300 mm) of linear motor systems!

Note: Use only suitable and non-hazardous agents. Please check the manufacturer's safety data sheets.

Remove the cover or bellows before maintenance:

#### Upper cover:

- (1). Loose the screws on the upper cover.
- (2). Remove the cover carefully.




Figure 7.1.1 Exploded view of the cover - here for LMSSA2X

#### Lower cover:

(1). Loosen the screw on the end cover of the lower cover and remove the cover.




Figure 7.1.2 Exploded view of the cover – here for LMSSA2X

- (2). Loosen the screw on the lower cover.
- (3). Carefully remove the lower cover.




Figure 7.1.3 Exploded view of the cover – here for LMSSA2X

Table 7.1.1 Remove / mounting the cover

Туре	Type Cover type Screw Siz		Torque (kgf-cm)
LMSSA2X-10S100-13S200	S	M4	3.3
LMSSA2X-13S100-20S300	S	M4	3.3

- During maintenance:
  - (1). Secure LMSSA2X against being switched on without authorization.
  - (2). Disconnect the power supply of LMSSA2X.
  - (3). Secure LMSSA2X against being switched back on without authorization.




Figure 7.1.4 Example of a warning sign

- Installed the cover after maintenance:
  - (1). Position the lower cover on LMSSA2X.
  - (2). Tighten the screws on the cover.
  - (3). Put on the cover and tighten the screws of the cover at the end of the lower cover.
  - (4). Position the upper cover on LMSSA2X.
  - (5). Tighten the screws on the cover.

#### 7.1.1 Linear motor

- Ensure that no parts are located between the forcer and the magnet track!
- The linear motor operates maintenance-free.

#### 7.1.2 Positioning measurement system

#### 7.1.2.1 Magnetic positioning measurement system

■ Ensure that no dirt particles are located between the encoder and the measuring scale!

The magnetic positioning measurement system works on a non-contact basis and thus requires no maintenance. Check the magnetic positioning measurement system regularly for soiling, cleaning this when necessary. Otherwise, accumulating dirt particles will detach under the constant pressure of the cover plate.

#### 7.1.2.2 Optical positioning measurement system

■ Ensure that no extra particles caught between the encoder and the measuring scale! Only use soft cloth for cleaning to avoid scratching the measuring scale!

The optical positioning measurement system works on a non-contact basis and thus requires no maintenance. Regularly check the measuring scale for dirt and clean if necessary, as otherwise the surface of the measuring scale may become scratched and may no longer function correctly.

### 7.1.3 Electromechanical components

The energy chain and the cable have a limited lifetime. However, the lifetime cannot be calculated exactly due to ambient conditions and drive performance. The following components should therefore be regularly checked for wear and correct position, and should be replaced if necessary (wearing parts are not covered by the warranty):

- Cable in the energy chain (e.g. signs of abrasion on the cable insulation)
- Cable plug connections
- Distance between the limit switch shelter and sensors (common cause of malfunction of the limit/reference switch)

In critical production situations, make sure that there is a stock of wearing parts!

#### 7.1.4 Linear guideways

#### 7.1.4.1 Lubrication

As with rolling bearings, the rails of linear motor systems require a sufficient supply of lubricant. This lubrication reduces wear, protects against dirt and deposits, prevents corrosion and extends service life. Please read the instructions of the lubricant manufacturer.

Check the miscibility of different lubricants. Lubricants of the same classification (e.g. CL) and similar viscosity (maximum difference of one class) are miscible. Greases are miscible when their base oil and thickening types are the same. The viscosity of the base oil must be similar and the NGLI class may be different by a maximum of one grade.

- Ensure that old grease, dirt and chippings are removed from the profile rails before lubrication.
- Only use lubricants that are in accordance with DIN 51825, KP2K of the consistency class NGLI2.
- Ensure that only lubricants without solid lubricant particles (e.g. graphite or MoS2) are used!
- Further information about lubrication and selection of approved lubricants can be found in the user manual for linear guideways at www.hiwin.tw.




Figure 7.1.4.1.1 Grease nipples on linear guideways

#### Note:

- (1). Relubricating interval every 200-600 operating hours or 1000 km.
- (2). Relubricating grease quantity varies from different type. (See table 7.1.4.1.7)
- (3). Relubrication as standard through grease nipple (See figure 7.1.4.1.1) with standard grease guns.

#### ■ MGN Block grease maintenance kit:

A syringe is used to apply lubricant to the ports. The standard is a fully synthetic lubricant with a main constituent. Synthetic hydrocarbons (PAO). The viscosity class the oil is 680(ISO VG680).



Figure 7.1.4.1.2 MGN Block grease maintenance kit

Table 7.1.4.1.1 grease syringe

品號	名稱	規格	示意圖
940303200002	Syringe	10 cc	-10 -10 -10 -10 -10 -10 -10 -10 -10 -10
940301800006	Syringe Needle	20 1/2"45。	

Table 7.1.4.1.2 MOBIL VACTRA NO.2

Grade	ISO 68
Copper Strip Corrosion, 3 h, 100 C, Rating, ASTM D130	1B
FZG Scuffing, Fail Load Stage, A/8.3/90, ISO 14635-1	13
Flash Point, Cleveland Open Cup, °C, ASTM D92	228
Kinematic Viscosity @ 40 C, mm2/s, ASTM D445	68
Pour Point, °C, ASTM D97	-18

### ■ QH Block grease maintenance kit:




圖. 7.1.4.1.3 QH Block grease maintenance kit

Table 7.1.4.1.3 grease gun

Model no.	GN-80M	GN-400C
Dimensi on	(10B) 222 (20)	(108) 320 (20)
Specific ation	(1). Working pressure:15Mpa (2). Output:0.5~0.6 c.c./Stroke (3). Weight:520(g) grease excluded Grease reload :70g flexible tube or 120ml bulk loading	(1). Working pressure:15Mpa (2). Output:0.8~0.9 c.c./Stroke (3). Weight:1150(g) grease excluded Grease reload:14 o.z. cartridge pipe or 440ml bulk loading

Table 7.1.4.1.4 G04 Basic properties

Color		Beige
Base Oil		Ester/PAO
Consistency Enhancer		Lithium soap
Service Temperature(°C)		-35~120
NLGI-grade [0.1mm]		260-280
Viscosity [cst]	40°C	Viscosity [cst]
	100°C	6
Drop Point(°C)		>225

Table 7.1.4.1.7 Lubricant quantities for the linear guideway of LMSSA2X

Туре	Block	Lubricant	Relubrication quantity [cm³]
LMCCAOV 400400 400000	上軸:MGN9	MOBIL VACTRA NO.2	0.06
LMSSA2X-10S100-13S200	下軸:QH15	G04	0.3
LMCCA2V 12C100 20C200	上軸:QH15	G04	0.3
LMSSA2X-13S100-20S300	下軸:QH15	G04	0.3

### 7.1.4.2 Relubrication intervals for grease lubrication

Among other conditions, the relubrication intervals depend on the P/C load ratio, where P stands for the dynamically equivalent load and C stands for the dynamic load rating.

The relubrication intervals can possibly be shortened under the following conditions. In such cases, please consult HIWIN:v>3m/s, a>30m/s^2, contact with media, temperatures<20 $^{\circ}$ C or > 30 $^{\circ}$ C, soiled ambient conditions.




Figure 7.1.4.2.1 Relubrication intervals with grease lubrication, one-sided and two-sided long-term lubrication unit for MG.




Figure 7.1.4.2.2 Relubrication intervals with grease lubrication, one-sided and two-sided long-term lubrication unit for QH.

#### 7.1.5 Cleaning

Dirt can settle and accumulate over time on unprotected profile rails. Profile rails must therefore be regularly checked for dirt and cleaned if necessary. Stage can start motion after cleaning the excessive grease:

- Clean the overflows on guideway and blocks
- Clean the optical encoder and scale
- Clean the stator.

#### Note:

- (1). Please apply IPA on wiper for cleaning. Do not apply the IPA on the scale directly.
- (2). Do not use Ethanol or any other solvent to clean up optical scale.
- (3). There is strong magnetic force between LMSA motor's forcer and stators. When cleaning the motor, the forcer and stator can't be too close to each other.
- (4). LMC stator is not suitable on the following maintenance procedure. If the stator has been attracted with each other, please contact HIWIN staff to assist it
- (5). If the stage is used under unideal environment, cleaning on stators should be performed regularly.
- (6). Stators and forcers (iron materials) can make powerful suction, which would hurt fingers and palms seriously. Don't let magnetic items get too close to avoid magnet attract. (E.g. Knife, tools.)

#### 7.1.6 **Test run**

After lubricating, please cycle run the stage for over 10 minutes before regular usage, which could evenly distribute the grease between the block and guideway. This could also release the saturation pressure and avoid the grease continuing to overflow and accumulating between the block and the guideway.

# 8. Disposal

8.	Disposal .		8-	1
	8.1	Waste disposal	8-:	2

# 8.1 Waste disposal

# **ACAUTION**

Danger caused by environmentally hazardous substances!

The danger to the environment depends on the type of substance used.



Clean contaminated parts thoroughly before disposal!

Clarify the requirements for safe disposal with disposal companies and, where appropriate, with the competent authorities!

Table 8.1.1 Disposal

Fluids		
Lubricants	dispose of as hazardous waste in an environmentally friendly way	
Soiled cleaning cloths	dispose of as hazardous waste in an environmentally friendly way	
Linear motor system		
Cabling, electrical components	dispose of as electrical waste	
PP components (e.g. cable chain)	dispose of separately	
Steel components (e.g. guideways)	dispose of separately	
Aluminum components (e.g. base)	dispose of separately	

# 9. Troubleshooting

9.	Troublesho	poting	. 9-1
	9.1	Troubleshooting	. 9-2

#### Troubleshooting

# 9.1 Troubleshooting

Table 9.1.1 Fault table

Symptom	Cause	Action		
Motor does not start	Power supply cables disconnected	Check connections. Plug contacts may be compressed, repair if necessary.  The connectors have seals, which means that a certain screw connection resistance must be overcome.		
	Fuse has tripped via motor protection	Check motor protection for the right settings. Fix defects if necessary		
	Encoder counting direction incorrect	Change the sin and cos pair of wires in the encoder plug		
Upon restart, the drive reports a fault during commutation	Forcer housing is too close to the limit switch/limit stop	Disconnect power supply to axis and move forcer housing manually into the center of the axis.		
	Additional drive resistance	Change parameters in the drive amplifier		
		See fault during commutation		
Axis overspeeds upon restart	Commutation incorrect	Check commutation parameters in the drive, activate speed monitoring!		
	EMC interference with the encoder signal	Check the shielding of the connectors and cables		
Axis overspeeds in positioning mode	Programming error in the position transfer, invalid acceleration ordered	Activate security settings in the drive amplifier, such as speed monitoring, permissible position errors etc.		
	Rated power exceeded as duty cycle is too long	Adapt load cycle to the rated power of the motor		
	Cooling insufficient	Fix cooling air power supply or open cooling air passages. Retrofit external fan if necessary		
Motor heats up too much	Forcer housing is difficult to move	Check lubrication of the guideways, foreign bodies in the moving range.		
(measure temperature)	Ambient temperature is too high	Check permissible temperature range		
	Load cycle has been modified	Calculate load cycle and adapt accordingly		
	Drive amplifier motor commutation does not function properly	Adapt commutation parameters of the drive amplifier		
Operating noise from the forcer	Relubrication required otherwise risk of bearing damage	Lubrication or consultation with HIWIN MIKROSYSTEM		
The axis generates cracking	EMC interference in the encoder signal	Encoder cables must be used separately with shielded sin and cos signal pairs		
noises when it is subject to control	Commutation incorrect	Optimize commutation parameters.		

# HIWIN. MIKROSYSTEM

MM18UE01-2310

Standard Dual-Axis Linear Motor Stage User Manual

Troubleshooting

The forcer jerks while moving and generates operating noise that is not caused by the profile guideways	EMC interference in the encoder signal. Encoder cable plug connection defective. Pin bent in plug	Place motor cable and/or encoder cable shield in full contact with the grounding terminal of the amplifier, check pin in plug.
Position discrepancies after several hours of operation		Use mains filter to stabilize voltage

# HIWIN. MIKROSYSTEM

MM18UE01-2404

Troubleshooting

Standard Dual-Axis Linear Motor Stage User Manual

(This page is intentionally left blank.)

# 10. Declaration of Incorporation

10.	Declaration of Incor	poration	10-	1
-----	----------------------	----------	-----	---

**Declaration of Incorporation** 

Standard Dual-Axis Linear Motor Stage User Manual

#### **Declaration of Incorporation**

according to EC directive 2006/42/EC on machinery (Annex II 1. B)

#### Name and address of the manufacturer:

HIWIN MIKROSYSTEM CORP. No.6, Jingke Central Rd., Taichung Precision Machinery Park, Taichung 408226, Taiwan

#### Description and identification of the partly completed machine:

Product:

Linear Motor System

Type:

LMX. LMG. LMAP. NPS. LMSSA. BS. LMSSA2X

Year of manufacture:

from 2024

It is hereby declared that the following essential requirements of the Machinery Directive 2006/42/EC have been fulfilled.

1.1, 1.3, 1.4, 1.5, 1.6, 1.7

Moreover, it is declared that the relevant technical documentation specified under Annex VII Part B has been compiled.

It is hereby explicitly declared that the partly completed machine complies with all of the pertinent conditions in the following EC Directives.

2006/42/EC 2014/30/EU 2014/35/EU

Mounting and connecting instructions defined in catalogues and technical construction files must be respected by the user. They are based on the following standards:

EN ISO 12100:2010 EN 60204-1:2018 EN 61000-6-2:2005 EN 61000-6-4:2007 / A1:2011

The manufacturer or the authorized person undertakes to transmit, in response to a reasoned request by the national authorities, the relevant documentation on the partly completed machinery.

This is without prejudice to the intellectual property rights of the manufacturer!

Important note! The partly completed machinery may not be commissioned until it has been ascertained that the machinery into which this partly completed machinery is to be incorporated is compliant with the provisions of this Directive.

Taichung 40852, Taiwan	Kou-I, Szu	
14.08, 2024	General Manager	Syn
(Place, Date)	(Surname, first name, and function of signatory)	(Signature)

# 11. Appendix

11.	Appe	endix		11-1
	11.1	Glo	ossary	11-2
	11.2	Uni	it conversion	11-5
	11.3	Tol	lerances and hypotheses	11-6
		11.3.1	Tolerances	11-6
		11.3.2	Hypotheses	11-6
	11.4	Su	pplementary formula	11-7
		11.4.1	Start Motor Sizing	11-7
		11.4.2	Linear Motor Sizing Example	11-13
		11.4.3	Sizing a Regen Resistor	11-14
	11.5	Op	otional accessories	11-20
	11.6	Cu	stomer request form	11-21

# 11.1 Glossary

#### Accuracy

This, or actually the better terminology, the inaccuracy, corresponds to the deviation between target and actual position. The accuracy along an axis is defined as the remaining difference of target and actual position, after other linear deviations are excluded. Such systematic or linear deviations can be caused by cosine error, angle deviation, ball screw error, thermal expansion, etc. For all target positions of interest in an application, it is calculated with the following formula:

Maximum of sum of systematic target—actual-difference+ 2 sigma (standard deviation) Please do not confuse accuracy with repeatability.

#### Acceleration

This is the speed change per time unit, i.e, acceleration = speed / time or a = v / t.

#### Acceleration time

This is defined as the time a drive requires from start until achieving target speed.

#### ■ Attraction force (F<sub>a</sub>)

This is created between the primary and secondary parts of the ironcore linear motors which must be provided by the guide.

#### ■ Back EMF constant(K<sub>V</sub>)

This is the ratio of the back EMF voltage (rms) to the motor rotational speed or linear speed (rpm or m/s). The back EMF is the electromagnetic force, which is created at the movement of the coil in the magnetic field of permanent magnets, e.g. in a servo motor.

#### $\blacksquare$ Continuous force ( $F_c$ )

Continuous force are also called nominal torque and nominal force. This is the force that linear motors can produce in continuous operation when continuous current of 100% load rate (duty cycle) is applied to the motor coil.

#### ■ Continuous current (I<sub>c</sub>)

Continuous current is defined as the maximum allowed current into each coil under continuous operation, and is also called nominal current. It is characterized when the motor warms up and stay at 80 ° C.

#### Eccentricity

This is the deviation of the center point of rotation of rotary tables from their position during rotation. It is created by centering and bearing tolerances.

#### Force

Force (in linear movements) is given for defined conditions, e.g., as continuous force or torque at:

- (1). 20 ° C ambient temperature
- (2). 80 ° C winding temperature
- (3). 100% rate of loading (duty cycle)

or as peak force or peak torque.

#### ■ Force constant (K<sub>f</sub>)

This is a coil specific constant. The motor output force can be calculated by multiplying the force constant of the motor by input current:  $F = I \times K_f$ 

#### Guide deviation

This is the deviation from the axis of stroke. It depends on horizontal straightness [also straightness] and vertical straightness [also flatness].

#### Horizontal straightness

Horizontal straightness is defined as the positioning error in Y-axis as the stage moves along X-axis, which is measured by laser interferometer system.

#### Motor constant (K<sub>m</sub>)

Motor constant designates the ratio of generated force and dissipation power, and represents the efficiency of the motor.

#### Peak current (I<sub>p</sub>)

Peak current is applied to coils for a short time to generate peak force. The maximum time for applying peak current is 1 second. After that, motor has to cool down to nominal operating temperature, before further peak current could be applied again.

#### ■ Peak torque, peak force (F<sub>n</sub>)

The peak torque [for rotary motion] or peak force [for linear motion] is the maximum force that a motor can generate for approximately one second with peak current  $I_p$ . While applying  $I_p$  into motor, it is operating near the non-linear range of motor. This is especially useful for acceleration and braking.

## **HIWIN** MIKROSYSTEM

MM18UE01-2404

Appendix

Standard Dual-Axis Linear Motor Stage User Manual

#### Resolution

Resolution is the smallest distance that the position measuring system can detect. The reachable step size is theoretically larger than resolution due to other additional factors.

#### Repeatability

Repeatability is the measure of how close a stage approach to a designated point in different runs. Repeatability should not be confused with absolute accuracy. A linear axis can have medium accuracy, but have good repeatability. Uni-directional repeatability can be measured in a way, that a target position is approached multiple times from an appropriately distance and the same approaching direction. In this way, the backlash will not have any effect. For measurement of bi—directional repeatability, the target position is approached from different directions, in which case the backlash will take effect.

#### Stiffness

Static stiffness stands for the mechanical resistance to deformation of a part or an assembly under external static payload. In the other hand, dynamic stiffness stands for the elastic resistance to deformation and movement of a part or an assembly under external dynamic payload (e.g. driving force).

#### Step size

The minimum step size is close to resolution. It is the smallest possible movement of a system. It depends on encoder, amplifier, mechanical structure, backlash, etc.

#### Vertical straightness

Vertical straightness is defined as the positioning error in Z-axis as the stage moves along X-axis, which is measured by laser interferometer system.

#### ■ Winding resistance R<sub>25</sub>

 $R_{25}$  is the winding resistance at 25° C. At 80° C, the winding resistance increases to approximately 1.2 x  $R_{25}$ .

#### Winding temperature (T)

This is the permitted winding temperature. The actual motor temperature is dependent on the installation, cooling and operating conditions and consequently can only be determined in a concrete case and cannot be calculated.

# 11.2 Unit conversion

To convert the unit in column B to the unit in column A, multiply by the corresponding figure in the table.

#### Mass

Table 11.2.1

		В					
		g	kg	lb	oz		
	g	1	0.001	0.0022	0.03527		
_	kg	1000	1	2.205	35.273		
Α	lb	453.59	0.45359	1	16		
	oz	28.35	0.02835	0.0625	1		

## Linear velocity

Table 11.2.2

	В						
		m/s	cm/s	mm/s	ft/s	in/s	
	m/s	1	100	1000	3.281	39.37	
	cm/s	0.01	1	10	3.281 x 10 <sup>-2</sup>	0.3937	
Α	mm/s	0.001	0.1	1	3.281 x 10 <sup>-3</sup>	3.937 x 10 <sup>-2</sup>	
	ft/s	0.3048	30.48	304.8	1	12	
	in/s	0.0254	2.54	25.4	8.333 x 10 <sup>-2</sup>	1	

#### ■ Force

Table 11.2.3

			В					
			N	lb	OZ			
	N	1	0.2248	3.5969				
	Α	lb	4.4482	1	16			
		OZ	0.2780	0.0625	1			

#### ■ Length

Table 11.2.4

			В					
		m	cm	mm	ft	in		
	m	1	100	1000	3.281	39.37		
	cm	0.01	1	10	3.281 x 10 <sup>-2</sup>	0.3937		
Α	mm	0.001	0.1	1	3.281 x 10 <sup>-3</sup>	3.937 x 10 <sup>-2</sup>		
	ft	0.3048	30.48	304.8	1	12		
	in	0.0254	2.54	25.4	8.333 x 10 <sup>-2</sup>	1		

#### Temperature

Table 11.2.5

		E	3
		°F	
^	°C	1	(°F - 32) x 5 / 9
A	°F	(°C x 9 / 5) + 32	1

# 11.3 Tolerances and hypotheses

#### 11.3.1 Tolerances

Table 11.3.1.1 Tolerances

Tolerances (mm)								
<6	6-30	30-120	120-300	300-600	600-1200	1200-2400	>2400	
±0.1	±0.2	±0.3	±0.4	±0.5	±0.8	±1.0	±1.5	

# 11.3.2 Hypotheses

Operating staff are trained in the safe operation practices for linear motor systems and have read and understood this user manual in full. Maintenance staff maintain and repair the linear motor systems in such a way that they pose no danger to people, property or the environment.

# 11.4 Supplementary formula

## 11.4.1 Start Motor Sizing

The following contents describe how to choose proper motor according to speed, moving distance, and payload inertia. The basic process for sizing a motor is:

- (1). Decide motion profile and required parameters
- (2). Calculate peak and continuous force
- (3). Select motor

#### **Symbols**

X : Move distance (mm)
 T : Move time (sec)
 a : Acceleration (mm/s²)
 V : Velocity (mm/s)

M<sub>I.</sub>: Payload (kg)

g: Gravitation acceleration (mm/s<sup>2</sup>)

F<sub>P</sub>: Peak force (N)

F<sub>c</sub> : Continuous force (N)

F<sub>a</sub>: Attraction force between stator and forcer (N) applicable for LMSSA series

F<sub>i</sub>: Inertia force (N)

 $\begin{array}{lll} K_P & : & \text{Force constant (N/Arms)} \\ I_P & : & \text{Peak current (Arms)} \\ I_e & : & \text{Effective current (Arms)} \\ I_C & : & \text{Continuous current (Arms)} \\ V_0 & : & \text{Starting velocity (mm/s)} \end{array}$ 

Standard Dual-Axis Linear Motor Stage User Manual

#### STEP 1 Decide motion velocity profile and required parameters

In order to determine the correct motor for a particular application it is necessary to be familiar with the motion equation.

## Motion equation

Basic kinematics equations are described as follows:

$$V = V_0 + aT$$

$$X = V_0 T + \frac{1}{2} a T^2$$

Where V is velocity, a is acceleration, T is move time and X is move distance.

You can choose two of the four parameters (V, a, T and X) as your designed parameters, then the last two parameters can be calculated by above equations.

#### Motion velocity profile

#### (1). 1/3-1/3-1/3 trapezoid profile

If the distance (X) and move time [T) have been given, the most common and efficient velocity profile for point-to-point motion is the "1/3-1/3" trapezoid curve because it provides the optimal move by minimizing the power required to complete the move. It breaks the time of the acceleration, Strokeing, and deceleration into three segments as shown below.




Figure 11.4.1.1 Trapezoid profile

$$V_{max} = 1.5 \times \frac{X}{T} \text{ (Because X} = \frac{V}{2} \times \frac{T}{3} + V \times \frac{T}{3} + \frac{V}{2} \times \frac{T}{3} \text{)}$$

$$a_{max} = \frac{V_{max}}{T/3} = \frac{4.5X}{T^2}$$

Note: Herein the parameters are described as motion equation.

#### (2). 1/2-1/2 triangle profile

If X and T are given, another common motion profile is the 1/2-1/2 triangle profile. The motion is divided into two parts, namely acceleration and deceleration. The second motion velocity profile is shown as follows.





Figure 11.4.1.2 Triangle profile

$$V_{max} = 2 \times \frac{X}{T}$$

$$a_{max} = \frac{4X}{T^2} \label{eq:amax}$$

#### (3). Some useful equations

Table 11.4.1.1



The acceleration required in the first motion velocity profile is bigger than that in the second motion velocity profile; therefore, the required motor size is bigger. When choosing second motion velocity profile, the chosen motor size is smaller, however, we need to verify the DC bus of driver is bigger enough, due to the higher velocity  $(V_{\rm max})$ .

#### STEP 2 Determine peak force and effective force

The peak force can be calculated by the follow equation

$$F_P = M_L \times a_{max} + (M_L \times g + F_a) \times \mu = F_i + F_f$$

Where  $F_i$  is inertia force while  $F_f$  is friction force, and  $\mu$  is friction factor.

In most cases, motions are cyclic point-to-point movements. Assuming a cyclic motion shown in the

following profile with a pause time of t4 second, the effective force can be calculated as following formula:




Figure 11.4.1.3 Profile

The peak current  $I_P$  and effective current  $I_e$  can be calculated by using motor force constant  $K_f$ .

$$I_{p} = \frac{F_{p}}{K_{f}}$$

$$I_{e} = \frac{F_{e}}{K_{f}}$$

#### ■ STEP 3 Select motor by peak force and verify the current supply of motor

From the HIWIN catalog, you can check the specifications of motor and choose an applicable motor by peak force, and then you can verify the current supply if it is fitted the specification as follows.

$$I_p = \frac{F_p}{K_f} < I_p \text{ (from specification of chosen motor)}$$

$$I_e = \frac{F_e}{K_f} < I_c$$
 (from specification of chosen motor)

Regarding effective and continuous current, the ratio of  $I_e/I_c$  had better be less than 0.7 to attain some margin.

## 11.4.2 Linear Motor Sizing Example

For example, if Payload is 5 kg (moving mass of mechanism is 1 kg and payload is 4 kg), friction factor U is 0 01, distance is 500 mm, move time is 400ms and dwell time is 350ms.

At first, we can calculate the  $V_{max}$ ,  $a_{max}$ ,  $F_p$  and  $F_e$  by the formulas described above (choose the first motion velocity profile and LMSA Series)

= 41.92(N)

$$\begin{split} V_{max} &= 1.5 \times \frac{X}{T} = 1.5 \times \frac{0.5}{0.4} = 1.875 (\text{m/sec}) \\ a_{max} &= \frac{4.5 \times X}{T^2} = \frac{4.5 \times 0.5}{(0.4)^2} = 14.06 (\text{m/sec}^2) \\ F_p &= M_L \times a_{max} + (M_L \times g + F_a) \times \mu \\ &= 5 \times 14.06 + 5 \times 9.81 \times 0.01 = 70.3 + 0.49 = 70.79 (\text{N}) \\ F_e &= \sqrt{\frac{[(70.3 + 0.49)^2 + 0.49^2 + (70.3 - 0.49)^2] \times 0.1333}{0.4 + 0.35}} \end{split}$$

Standard Dual-Axis Linear Motor Stage User Manual

In this case, we can choose motor of type LMSA11 which can provide up to 289(N) of peak force and continuous force 103(N), and the force constant is 48.6 N/A(rms). Then the current supply of motor can be determined as follows

$$\begin{split} I_p &= \frac{F_p}{K_f} = \frac{70.79}{48.6} = 1.46 (\text{Arms}) < 6.3 (\text{Arms}) \\ I_e &= \frac{F_e}{K_f} = \frac{41.92}{48.6} = 0.86 (\text{Arms}) < 2.1 (\text{Arms}) \\ \frac{I_e}{I_c} &= \frac{0.86}{2.1} \times 100\% = 40.9 < 70\% \end{split}$$

## 11.4.3 Sizing a Regen Resistor

#### 11.4.3.1 Gather required information

To calculate the power and resistance of the regen resistor requires information about the amplifier and the motor. For all applications, gather the following information:

- Detail of motion profile, including acceleration and velocity
- Amplifier model number
- Applied line voltage to amplifier
- Toque/force constant of the motor
- Resistance (line-to-line) of the motor windings

For rotary motor applications, gather additional information.

- Payload inertia seen by the motor
- Inertia of the motor

For linear motor applications, gather additional information

Moving mass

# 11.4.3.2 Observe the properties of each deceleration during a complete cycle of operation

For each deceleration during the motion cycle, determine:

- Speed at the start of the deceleration
- Speed at the end of the deceleration
- Time over which the deceleration takes place

Standard Dual-Axis Linear Motor Stage User Manual

#### 11.4.3.3 Calculate energy returned for each deceleration

The energy returned during each deceleration can be calculated by the following formulas.

Linear motor:

$$E_{\rm dec} = \frac{1}{2} M_{\rm t} (V_1^2 - V_2^2)$$

E<sub>dec</sub>(joules): Energy returned by the deceleration

M<sub>t</sub>(kg):Moving mass

V<sub>1</sub>(meters /sec): Velocity at the start of deceleration

V<sub>2</sub>(meters /sec): Velocity at the end of deceleration

#### 11.4.3.4 Determine the amount of energy dissipated by the motor

Calculate the amount of energy dissipated by the motor due to current flow through the motor winding resistance using the following formula.

$$P_{\text{motor}} = \frac{3}{4} R_{\text{winding}} \left( \frac{F}{K_t} \right)^2$$

P<sub>motor</sub>(watts): Power dissipated in the motor

R<sub>winding</sub>(ohm): Line to Line resistance of the motor coil

F(N): Force need to decelerate the motor

K<sub>t</sub>(N/Amp): Torque constant for the motor

$$E_{motor} = P_{motor} T_{decel}$$

E<sub>motor</sub>(joules): Energy dissipated in the motor

T<sub>decel</sub>(seconds) :Time of deceleration

#### 11.4.3.5 Determine the amount of energy returned to the amplifier

Calculate the amount of energy that will be returned to the amplifier for each deceleration using the following formula.

$$E_{returned} = E_{dec} - E_{motor}$$

E<sub>returned</sub>(joules): Energy returned to the amplifier

E<sub>dec</sub>(joules): Energy returned by the deceleration

E<sub>motor</sub>(joules): Energy dissipated in the motor

#### 11.4.3.6 Determine if energy returned exceeds amplifier capacity

Compare the amount of energy returned to the amplifier in each deceleration with the amplifier's absorption capacity. The following formula is used to determine the energy that can be absorbed by the amplifier.

$$W_{\text{capacity}} = \frac{1}{2}C(V_{\text{regen}}^2 - (1.414V_{\text{mains}})^2)$$

W<sub>capacity</sub>(joules):The energy that can be absorbed by the bus capacitor

C(farads):Bus capacitance

 $V_{regen}^{\square}(volts)$ :Voltage at which the regen circuit turns on

V<sub>mains</sub>(volts):Mains voltage (AC) applied to the amplifier

Standard Dual-Axis Linear Motor Stage User Manual

#### 11.4.3.7 Calculated energy to be dissipated for each deceleration

For each deceleration where the energy exceeds the amplifier's capacity, using the following formula to calculate the energy that must be dissipated by the regen resistor.

$$E_{regen} = E_{returned} - E_{amp}$$

 $E_{regen}$ (joules):Energy that must be dissipated in the regen resistor

E<sub>returned</sub>(joules): Energy delivered back to the amplifier from the motor

E<sub>amp</sub>(joules):Energy that the amplifier will absorb

#### 11.4.3.8 Calculate pulse power of each deceleration that exceeds amplifier capacity

For each deceleration where energy must be dissipated by the regen resistor, use the following formula to calculate the pulse power that will be dissipated by the regen resistor.

$$P_{\text{pulse}} = E_{\text{regen}} - T_{\text{decel}}$$

P<sub>pulse</sub>(watts): Pulse power

E<sub>regen</sub>(joules):Energy that must be dissipated in the regen resistor

T<sub>decel</sub>(seconds): Time of deceleration

#### 11.4.3.9 Calculate resistance needed to dissipate the pulse power

Using the maximum pulse power from the previous calculation, calculate the resistance value of the regen resistor required to dissipate the maximum pulse power.

$$R = V_{\text{regen}}^2 / P_{\text{pulse max}}$$

R(ohms): Resistance

 $P_{pulse\;max}$ : The maximum pulse power

 $V_{regen}^{\square} :$  The voltage at which the regen circuit turns on

Choose a standard value of resistance less than the calculated value. The value must also be greater than the minimum regen resistor value specified by the amplifier supplier.

# 11.5 Optional accessories

#### Encoder extension cable

Drive	Encoder signal	Hall sensor	Article number (2m)	Article number (4m)
E1	Analog	Υ	HE00EJVDA200	HE00EJVDA400
E1	Analog	N	HE00EK1DA200	HE00EK1DA400
E1	Digital	Y	HE00EKTDA200	HE00EKTDA400
E1/E2	Digital	N	HE00EJ6DF200	HE00EJ6DF400
E1	Absolute	N	HE00EKSDA200	HE00EKSDA400
E2	Analog	Y	HE00VJQ85800	HE00VJQ85900
E2	Analog	N	HE00VJQ85600	HE00VJQ85700
E2	Digital	Y	HE00VJQ87200	HE00VJQ87400
E2	Digital	N	HE00VJQ84200	HE00VJQ84400
E2	Absolute	N	HE00EKDDE200	HE00EKDDE400

# 11.6 Customer request form

Company Na	me* :	_ Indu	stry*:			Filled/	${\sf Confirmed}_{oldsymbol{\_}}$	/					
Equipment* :	Ap <sub> </sub>	plicatio	n* :	D	ate :	Βι	ıdget :						
*Please fill all	the requ	ired fi	eld ①	)~ <b>6</b>									
① Stage Stru	cture (mı	ultiple	choi	ces acce	oted	) <b>*</b>							
Si	ngle Axis	Cross 7	able	Gantry		Bridge	Ball Screw	SBH	Series	DL	F Series	Custom	
Туре		<b>S</b>	8		The state of the s					V		【 Please click the option on P3 or provide a sketch image 】	
Click													
②Stage Insta	allation (r	multip	le ch	oices acc	ept	ed) <mark>*</mark>							
Options : AH	orizontal	<b>®</b> Up	side-	down ©	) Wa	ll-mount	ed 🔘 Verti	cal (E	)Othe	ers			
Ex: U <sub>I</sub> □	oper Axis	Lov	ver Axi	is V	ertica	al Axis	Rotary Axis □		Oth	ner		Other	
③ Operation	Environr	nent (	<u> </u>	(multip	ole c	hoices a	ccepted) *						
Options	☐ <b>(A)</b> Gene	ral	□Вт	emp. Range		_	n room w/ const		ı <b>p.*</b> (pleas	е	□ <b>(</b> ) Va	cuum	
Spec	°c ±1°c	°C ±1°C				Class@°c ±1°c					Torr o	r_mbar	
4 Input Volta	age *												•
□ 110V	1		[	□ 220V			□ 380V				Other:	V	•
<b>⑤</b> Motor Sizi	ng (multi	iple ch	oices	s accepte	ed) (l	Please fil	l "NA" if	not a	ssigne	ed)	*		
	□Uppe	er Axis	□Lo	ower Axis	□\	/ertical Axis	Rotary	Axis		Othe	r	□Other	
Axis Name													
Forcer Qtys													
Motion Type	□ LM □	∃BS		M □ BS	□∟	_M □ BS			□LM	□В	S [	□LM □BS	
Payload(kg)/size							_(_L x <u>_W</u>	)					
Stroke(mm)							±°						
Velocity(m/s)							rad/s						
Acceleration(m/s <sup>2</sup>	)						rad/s²						_
Movement	□P to P□	∃Scan	□Pto	o P⊡Scan	□Р	to P⊟Scan	□P to P□S	can	□P to P	P⊟Sc	an [	□P to P□Scan	_
PM System													
Repeatability(um)	±		±		±		±_arc se	С	±		= =	<u>+</u>	_
Accuracy(um)	±		±		±		±_arc se	С	±		=	±	

## **HIWIN** MIKROSYSTEM

MM18UE01-2404

					- 1	•	
Α	n	n	Δ	n	М.	ıv	
$\overline{}$	v	v	C.		u	ın	

Standard Dual-Axis Linear Motor Stage User Manual

© Project Information \*

Surface Finish	□Standard Surface Finishing □Black						
Electric Control	DVas (Dlagge Fill the Floatric Central System Inquiry Form) DNa						
System	□Yes (Please Fill the Electric Control System Inquiry Form) □No						
Source Inspection	□Yes (On-site Inspection) □No						
Packaging Method	□None □Pallet □Wooden Box □HIWIN Standard						

Remark: 1. Fields marked\* are required (P1). For other requirement, please kindly fill P2~P4

- 2. For special requirement, please kindly fill option  $\mathbf{0}$  to show with sketch with some explanation.
- $\bigcirc$   $\bigcirc$   $\bigcirc$  are optional fields, please fill them if required  $\bigcirc$
- Advanced Accuracy Requirements: (If required but not defined, please fill "HIWIN besign")

	Upper Axis	Lower Axis	Vertical Axis	Rotary Axis	Other	Other				
Note: For application of laser, optical inspection, exposureetc. industry, please fill the geometric accuracy										
information as bel	information as below:									
Vertical Straightness (um)	±	±	±	±	±	±				
Horizontal Straightness (um)	±	±	±	±	±	±				
Pitch (arc sec)	±	±	±	±	±	±				
Yaw (arc sec)	±	±	±	±	±	±				
Servo jitter(um)	±	±	±	±	±	±				
Note: For applic	ation of low spe	ed scanning, ple	ase fill the velocit	ty ripple spec as	s below:					
Velocity ripple	%@	%@	%@	%@	%@	%@				
Note: For application	mm/s	mm/s oint to point, please	mm/s	rad/s	mm/s	mm/s				
Note. For application										
Settling time	ms@ um	ms@ um	ms@ um	ms@ rad	ms@ um	ms@ _um				
® Optional A		uiii	uiii	Tau	uiii	uiii				
	Upper Axis	Lower Axis	Vertical Axis	Rotary Axis	Other	Other				
Dust-proof	□Cover □Bellow	□Cover □Bellow	☑Cover □Bellow		□Cover □Bellow	□Cover □Bellow				
Extension Cable	M	□ <u></u> M	□ <u></u> M	□M	□ <u></u> M	□M				
Cable Chain										
Note: For applic	Note: For application of clean room, please kindly fill the routing information below. Choose 1 from option (A)									

# **HIWIN** MIKROSYSTEM

MM18UE01-2404


**Appendix** 

~ ①										
*Routing Information	_	ⓐ $\Box$ N/A ⓑ $\Box$ TBA ⓒ $\Box$ Please Refer Attachment ⑤ Spare Room for: $\Box$ Wires Ø $\_*$ _pcs $\Box$ Tubes Ø $\_*$ _pcs $\Box$ Other Cables Ø $\_*$ _pcs								
Optiona	Optional Frame / Structure:									
	Stage Star Fram	9	Machine Housing Material	Door / Panel Material	Damper	Platform Base Material	Other			
Туре	□Steel Welded □Aluminum Extrusion □Other		d □Steel Welded □Coated Steel □Aluminum Sheet □xtrusion □Acrylic Sheet □Other □Other		□Passive □Active	□Granite □Casting □Other				
🕡 Specia	l Require	ments	5:							
Special Drive Requirement			cified Firmware Versic tion Trigger / Vision o	<del></del>	lbus Communic	cation:				
Special Application										
Special PM Syste	em									
Other Requireme	ent									

□Drawing No.:\_\_\_\_ □O/C:

Reference of existing case

Standard Dual-Axis Linear Motor Stage User Manual



If there is special requirement on motion profile, please select one of above structure or provide sketch image.

# **Electric Control System:**

Fields marked * are	e required.					
	Input	□110V □220V (Single phase) □220V (Three-phase)		□Socket	Input Voltage :V  Qty :pc(s)	
*Dower Cyclere	Voltage	□Other:V □HIWIN design	Optional Parts	□I/O Terminal	Input Qty □NPN □PNP □Dry Contact	
*Power System	Connector Type	□H Type (Input Current<15A) □T Type (Input Current<15A) □Bare Wire □Other:			Output Qty:  □NPN □PNP □Dry Contact  Output CurrentmA	
	UPS	□YesKVA □No		□None		
		Installation Method:  □Vertical □Horizontal	HIWIN Document	arts list(.pdf) □N/A		
*Control Panel	□Electric Cabinet (Outside System)	□Drawer Type  Material and Surface  Treatment: □Stainless Steel □Aluminum □Coated □Non-Coated  Size: L:mm W:mm  H: mm  Distance From System: m	Screen	□Touchscreen Qty : Size :inches □Non-touchscreen Qty : Size :inches □None		
	□Wiring Panel		*Industrial		d Certification : □CE □UL □Other: ·	
	(Inside System)		Specification		r Wiring Method: : er-supplied SOP □HIWIN	
	□HIWIN De	esign	*Designated	□List of Designated Parts(.pdf) (.xls) □None		
	□None		Parts		ustomer-supplied Designated f) (.xls) □None	
*Emergency Stop Function		System (Retain Control Power) ystem (Retain Control Power) esign	Alarm	□Safety L □Other:_	ght   Buzzer  ight Curtains  None  choices accepted)	

# HIWIN. MIKROSYSTEM

Appendix

MM18UE01-2404

Special Requirements :	

Standard Dual-Axis Linear Motor Stage User Manual